

# ILS2K EtherNet/IP

## Integrated Drive

### User Guide

Original instructions

08/2020



---

The information provided in this documentation contains general descriptions and/or technical characteristics of the performance of the products contained herein. This documentation is not intended as a substitute for and is not to be used for determining suitability or reliability of these products for specific user applications. It is the duty of any such user or integrator to perform the appropriate and complete risk analysis, evaluation and testing of the products with respect to the relevant specific application or use thereof. Neither Schneider Electric nor any of its affiliates or subsidiaries shall be responsible or liable for misuse of the information contained herein. If you have any suggestions for improvements or amendments or have found errors in this publication, please notify us.

You agree not to reproduce, other than for your own personal, noncommercial use, all or part of this document on any medium whatsoever without permission of Schneider Electric, given in writing. You also agree not to establish any hypertext links to this document or its content. Schneider Electric does not grant any right or license for the personal and noncommercial use of the document or its content, except for a non-exclusive license to consult it on an "as is" basis, at your own risk. All other rights are reserved.

All pertinent state, regional, and local safety regulations must be observed when installing and using this product. For reasons of safety and to help ensure compliance with documented system data, only the manufacturer should perform repairs to components.

When devices are used for applications with technical safety requirements, the relevant instructions must be followed.

Failure to use Schneider Electric software or approved software with our hardware products may result in injury, harm, or improper operating results.

Failure to observe this information can result in injury or equipment damage.

© 2020 Schneider Electric. All rights reserved.

---

# Table of Contents

---



	<b>Safety Information</b> .....	7
	<b>About the Book</b> .....	9
<b>Chapter 1</b>	<b>Introduction</b> .....	13
	Overview of Integrated Drive .....	14
	Components and Interfaces .....	15
	Nameplate .....	17
	Type Code .....	18
<b>Chapter 2</b>	<b>Technical Data</b> .....	19
	Environmental Conditions .....	20
	Mechanical Data .....	22
	Electrical Data .....	24
	Electromagnetic Compatibility .....	26
	Shaft-Specific Data .....	27
	Data for Safety-Related Function STO .....	28
	Conditions for UL 508C and CSA .....	29
<b>Chapter 3</b>	<b>Engineering</b> .....	31
3.1	Electromagnetic Compatibility (EMC) .....	32
	Electromagnetic Compatibility (EMC) .....	32
3.2	Power Supply .....	34
	External Power Supply Units .....	35
	Wiring Information .....	36
3.3	Functional Safety .....	37
	Definitions .....	38
	Function .....	39
	Requirements for Using the Safety-Related Function STO .....	40
	Application Examples STO .....	42
3.4	EtherNet/IP Fieldbus .....	44
	General .....	45
	Messaging and Message Types .....	47
3.5	EtherNet/IP Communication .....	48
	Communication via I/O Messages .....	49
	Output Assembly, Instance 103 .....	50
	Input Assembly, Instance 113 .....	51
	Handshake via the Bit "MT" (Mode Toggle) .....	53
<b>Chapter 4</b>	<b>Installation</b> .....	55
4.1	Mechanical Installation .....	56
	Before Mounting .....	57
	Mounting the Integrated Drive .....	58
4.2	Electrical Installation .....	60
	Overview of Procedure .....	61
	Connection Overview .....	63
	Connection Via Cable Entry .....	64
	Connection Via Industrial Connectors .....	67
	Connection of CN1 - $V_{dc}$ Supply Voltage .....	68
	Connection of CN2 - Fieldbus .....	70
	Connection of CN3 - RS485 .....	72
	Connection of CN4 - 24 V Signal Interface .....	74
	Connection of CN5 - Safety-Related Function STO .....	76
	Connection of Accessories for 24 V Signals and Safety-Related Function STO .....	78
4.3	Verifying Installation .....	80
	Verifying Installation .....	80

<b>Chapter 5</b>	<b>Commissioning</b>	<b>81</b>
5.1	Overview	82
	General	83
	Preparation	85
5.2	Fieldbus Integration	86
	Setting the IP Address	87
	Web Server	90
5.3	Commissioning Procedure	92
	Setting Limit Values	93
	Digital Inputs and Digital Outputs	95
	Verifying the Signals of the Limit Switches	96
	Verifying the Safety-Related Function STO	97
	Holding Brake (Option)	98
	Direction of Movement	100
5.4	Parameter Management	101
	Resetting the User Parameters	102
	Restoring Factory Settings	103
<b>Chapter 6</b>	<b>Operation</b>	<b>105</b>
	Access Channels	106
	Movement Range	107
	Scaling	108
	Parameterization of the Signal Input Functions and the Signal Output Functions	110
<b>Chapter 7</b>	<b>Operating States and Operating Modes</b>	<b>113</b>
7.1	Operating States	114
	State Diagram and State Transitions	115
	Indicating the Operating State via Signal Outputs	118
	Indication of the Operating State via Fieldbus	119
	Changing the Operating State via Signal Inputs	120
	Changing the Operating State via Fieldbus	121
7.2	Indicating, Starting and Changing an Operating Mode	122
	Indicating the Operating Mode	123
	Starting and Changing an Operating Mode	124
7.3	Operating Mode Jog	125
	Overview	126
	Parameterization	129
	Additional Settings	130
7.4	Operating Mode Profile Velocity	131
	Overview	132
	Parameterization	133
	Additional Settings	134
7.5	Operating Mode Profile Position	135
	Overview	136
	Parameterization	138
	Additional Settings	139
7.6	Operating Mode Homing	140
	Overview	141
	Parameterization	143
	Reference Movement to a Limit Switch	146
	Reference Movement to the Reference Switch in Positive Direction	147
	Reference Movement to the Reference Switch in Negative Direction	148
	Reference Movement to the Index Pulse	149
	Position Setting	150
	Additional Settings	151

<b>Chapter 8</b>	<b>Functions for Operation</b>	<b>153</b>
8.1	Functions for Target Value Processing	154
	Motion Profile for the Velocity	155
	Stopping a Movement with Halt	158
	Stopping a Movement with Quick Stop	159
	Setting a Signal Output via Parameter	160
	Position Capture Via Signal Input	161
8.2	Functions for Monitoring Movements	163
	Hardware Limit Switches	164
	Reference Switch	166
	Software Limit Switches	167
8.3	Functions for Monitoring Internal Device Signals	169
	Temperature Monitoring	170
	Stall Detection	171
<b>Chapter 9</b>	<b>Examples</b>	<b>173</b>
	Wiring Example	173
<b>Chapter 10</b>	<b>Diagnostics and Troubleshooting</b>	<b>175</b>
10.1	Diagnostics via LEDs	176
	Operating State LEDs	177
	Fieldbus Status LEDs	178
10.2	Diagnostics via the Fieldbus	179
	Fieldbus Communication Error Diagnostics	180
	Most Recent Detected Error - Status Bits	181
	Most Recent Detected Error - Error Code	183
	Error Memory	184
	Error Response to Incorrect Realtime Ethernet Data	186
	Synchronous Errors	187
10.3	Error Messages	188
	Description of Error Messages	189
	Table of Error Messages	190
<b>Chapter 11</b>	<b>Parameters</b>	<b>195</b>
	Representation of the Parameters	196
	List of Parameters	198
<b>Chapter 12</b>	<b>Accessories and Spare Parts</b>	<b>217</b>
	Accessories and Spare Parts	217
<b>Chapter 13</b>	<b>Service, Maintenance, and Disposal</b>	<b>219</b>
	Service Addresses	220
	Maintenance	221
	Replacing the Product	223
	Shipping, Storage, Disposal	224
<b>Glossary</b>		<b>225</b>
<b>Index</b>		<b>229</b>

---



## Important Information

### NOTICE

Read these instructions carefully, and look at the equipment to become familiar with the device before trying to install, operate, service, or maintain it. The following special messages may appear throughout this documentation or on the equipment to warn of potential hazards or to call attention to information that clarifies or simplifies a procedure.



The addition of this symbol to a “Danger” or “Warning” safety label indicates that an electrical hazard exists which will result in personal injury if the instructions are not followed.



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

### **DANGER**

**DANGER** indicates a hazardous situation which, if not avoided, **will result in** death or serious injury.

### **WARNING**

**WARNING** indicates a hazardous situation which, if not avoided, **could result in** death or serious injury.

### **CAUTION**

**CAUTION** indicates a hazardous situation which, if not avoided, **could result in** minor or moderate injury.

### **NOTICE**

**NOTICE** is used to address practices not related to physical injury.

### PLEASE NOTE

Electrical equipment should be installed, operated, serviced, and maintained only by qualified personnel. No responsibility is assumed by Schneider Electric for any consequences arising out of the use of this material.

A qualified person is one who has skills and knowledge related to the construction and operation of electrical equipment and its installation, and has received safety training to recognize and avoid the hazards involved.

### QUALIFICATION OF PERSONNEL

Only appropriately trained persons who are familiar with and understand the contents of this manual and all other pertinent product documentation are authorized to work on and with this product. These persons must have sufficient technical training, knowledge and experience and be able to foresee and detect potential hazards that may be caused by using the product, by modifying the settings and by the mechanical, electrical and electronic equipment of the entire system in which the product is used.

The qualified person must be able to detect possible hazards that may arise from parameterization, modifying parameter values and generally from mechanical, electrical, or electronic equipment.

The qualified person must be familiar with the standards, provisions, and regulations for the prevention of industrial accidents, which they must observe when designing and implementing the system.

---

## INTENDED USE

The products described in or affected by the present document are, along with software, accessories and options, motors with an integrated drive. The products are intended for industrial use according to the instructions, directions, examples, and safety information contained in the present user guide and other supporting documentation.

The product may only be used in compliance with all applicable safety regulations and directives, the specified requirements and the technical data.

Prior to using the products, you must perform a risk assessment in view of the planned application. Based on the results, the appropriate safety-related measures must be implemented.

Since the products are used as components in an overall machine or process, you must ensure the safety of persons by means of the design of this overall machine or process.

Operate the products only with the specified cables and accessories. Use only genuine accessories and spare parts.

Any use other than the use explicitly permitted as described herein is prohibited and may result in unanticipated hazards.



## At a Glance

### Document Scope

This manual describes technical characteristics, installation, commissioning, operation, and maintenance of the integrated drive ILS2K.

### Validity Note

This manual is valid for the standard products listed in the type code, see chapter Type Code (*see page 18*).

For product compliance and environmental information (RoHS, REACH, PEP, EOLI, etc.), go to [www.schneider-electric.com/green-premium](https://www.schneider-electric.com/green-premium).

The technical characteristics of the devices described in the present document also appear online. To access the information online, go to the Schneider Electric home page <https://www.se.com/www/en/download/>.

The characteristics that are described in the present document should be the same as those characteristics that appear online. In line with our policy of constant improvement, we may revise content over time to improve clarity and accuracy. If you see a difference between the document and online information, use the online information as your reference.

### Product Related Information

The use and application of the information contained herein require expertise in the design and programming of automated control systems.

Only you, the user, machine builder or integrator, can be aware of all the conditions and factors present during installation and setup, operation, repair and maintenance of the machine or process.

You must also consider any applicable standards and/or regulations with respect to grounding of all equipment. Verify compliance with any safety information, different electrical requirements, and normative standards that apply to your machine or process in the use of this equipment.

The motor itself generates voltage when the motor shaft is rotated.

## DANGER

### ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH

- Disconnect all power from all equipment including connected devices prior to removing any covers or doors, or installing or removing any accessories, hardware, cables, or wires.
- Place a "Do Not Turn On" or equivalent hazard label on all power switches and lock them in the non-energized position.
- Block the motor shaft to prevent rotation prior to performing any type of work on the drive system.
- Replace and secure all covers, accessories, hardware, cables, and wires and confirm that a proper ground connection exists before applying power to the unit.
- Use only the specified voltage when operating this equipment and any associated products.

**Failure to follow these instructions will result in death or serious injury.**

If the power stage is disabled unintentionally, for example as a result of power outage, errors or functions, the motor is no longer decelerated in a controlled way. Overload, errors or incorrect use may cause the holding brake to no longer operate properly and may result in premature wear.

## WARNING

### UNINTENDED EQUIPMENT OPERATION

- Verify that movements without braking effect cannot cause injuries or equipment damage.
- Verify the function of the holding brake at regular intervals.
- Do not use the holding brake as a service brake.
- Do not use the holding brake for safety-related purposes.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

Drive systems may perform unanticipated movements because of incorrect wiring, incorrect settings, incorrect data or other errors.

## WARNING

### UNINTENDED MOVEMENT OR MACHINE OPERATION

- Carefully install the wiring in accordance with the EMC requirements.
- Do not operate the product with undetermined settings and data.
- Perform comprehensive commissioning tests that include verification of configuration settings and data that determine position and movement.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

## WARNING

### LOSS OF CONTROL

- The designer of any control scheme must consider the potential failure modes of control paths and, for certain critical control functions, provide a means to achieve a safe state during and after a path failure. Examples of critical control functions are emergency stop and overtravel stop, power outage and restart.
- Separate or redundant control paths must be provided for critical control functions.
- System control paths may include communication links. Consideration must be given to the implications of unanticipated transmission delays or failures of the link.
- Observe all accident prevention regulations and local safety guidelines.<sup>1</sup>
- Each implementation of this equipment must be individually and thoroughly tested for proper operation before being placed into service.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

<sup>1</sup> For additional information, refer to NEMA ICS 1.1 (latest edition), "Safety Guidelines for the Application, Installation, and Maintenance of Solid State Control" and to NEMA ICS 7.1 (latest edition), "Safety Standards for Construction and Guide for Selection, Installation and Operation of Adjustable-Speed Drive Systems" or their equivalent governing your particular location.

Machines, controllers, and related equipment are usually integrated into networks. Unauthorized persons and malware may gain access to the machine as well as to other devices on the network/fieldbus of the machine and connected networks via insufficiently secure access to software and networks.

## WARNING

### UNAUTHORIZED ACCESS TO THE MACHINE VIA SOFTWARE AND NETWORKS

- In your risk assessment, take into account all hazards that result from access to and operation on the network/fieldbus and develop an appropriate cyber security conceptual framework.
- Verify that the hardware infrastructure and the software infrastructure into which the machine is integrated, as well as all organizational measures and rules covering access to this infrastructure, take into account the results of the hazard and risk analysis.
- Implement your cyber security framework according to the best practices and standards of IT security and cyber security, such as ISO/IEC 27000 series, Common Criteria for Information Technology Security Evaluation, ISO/IEC 15408, IEC 62351, ISA/IEC 62443, NIST Cybersecurity Framework, Information Security Forum - Standard of Good Practice for Information Security.
- Verify the effectiveness of your IT security and cyber security systems using appropriate, proven methods.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

Schneider Electric adheres to industry best practices in the development and implementation of control systems. This includes a "Defense-in-Depth" approach to secure an Industrial Control System. This approach places the controllers behind one or more firewalls to restrict access to authorized personnel and protocols only.

## WARNING

### UNAUTHENTICATED ACCESS AND SUBSEQUENT UNAUTHORIZED MACHINE OPERATION

- Evaluate whether your environment or your machines are connected to your critical infrastructure and, if so, take appropriate steps in terms of prevention, based on Defense-in-Depth, before connecting the automation system to any network.
- Limit the number of devices connected to a network to the minimum necessary.
- Isolate your industrial network from other networks inside your company.
- Protect any network against unintended access by using firewalls, VPN, or other, proven security measures.
- Monitor activities within your systems.
- Prevent subject devices from direct access or direct link by unauthorized parties or unauthenticated actions.
- Prepare a recovery plan including backup of your system and process information.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

For more information on organizational measures and rules covering access to infrastructures, refer to ISO/IEC 27000 series, Common Criteria for Information Technology Security Evaluation, ISO/IEC 15408, IEC 62351, ISA/IEC 62443, NIST Cybersecurity Framework, Information Security Forum - Standard of Good Practice for Information Security.

For reasons of Internet security, TCP/IP forwarding is disabled by default. Therefore, you must manually enable TCP/IP forwarding. However, doing so may expose your network to possible cyberattacks if you do not take additional measures to protect your enterprise. In addition, you may be subject to laws and regulations concerning cybersecurity.

## WARNING

### UNAUTHENTICATED ACCESS AND SUBSEQUENT NETWORK INTRUSION

- Observe and respect any and all pertinent national, regional and local cybersecurity and/or personal data laws and regulations when enabling TCP/IP forwarding on an industrial network.
- Isolate your industrial network from other networks inside your company.
- Protect any network against unintended access by using firewalls, VPN, or other, proven security measures.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

Consult the [Schneider Electric Cybersecurity Best Practices](#) for additional information.

Use the latest firmware version. Visit <https://www.se.com> or contact your Schneider Electric representative for information on firmware updates that may involve Ethernet connections.

## Terminology Derived from Standards

The technical terms, terminology, symbols and the corresponding descriptions in this manual, or that appear in or on the products themselves, are generally derived from the terms or definitions of international standards.

In the area of functional safety systems, drives and general automation, this may include, but is not limited to, terms such as *safety*, *safety function*, *safe state*, *fault*, *fault reset*, *malfunction*, *failure*, *error*, *error message*, *dangerous*, etc.

Among others, these standards include:

Standard	Description
IEC 61131-2:2007	Programmable controllers, part 2: Equipment requirements and tests.
ISO 13849-1:2015	Safety of machinery: Safety related parts of control systems. General principles for design.
EN 61496-1:2013	Safety of machinery: Electro-sensitive protective equipment. Part 1: General requirements and tests.
ISO 12100:2010	Safety of machinery - General principles for design - Risk assessment and risk reduction
EN 60204-1:2006	Safety of machinery - Electrical equipment of machines - Part 1: General requirements
ISO 14119:2013	Safety of machinery - Interlocking devices associated with guards - Principles for design and selection
ISO 13850:2015	Safety of machinery - Emergency stop - Principles for design
IEC 62061:2015	Safety of machinery - Functional safety of safety-related electrical, electronic, and electronic programmable control systems
IEC 61508-1:2010	Functional safety of electrical/electronic/programmable electronic safety-related systems: General requirements.
IEC 61508-2:2010	Functional safety of electrical/electronic/programmable electronic safety-related systems: Requirements for electrical/electronic/programmable electronic safety-related systems.
IEC 61508-3:2010	Functional safety of electrical/electronic/programmable electronic safety-related systems: Software requirements.
IEC 61784-3:2016	Industrial communication networks - Profiles - Part 3: Functional safety fieldbuses - General rules and profile definitions.
2006/42/EC	Machinery Directive
2014/30/EU	Electromagnetic Compatibility Directive
2014/35/EU	Low Voltage Directive

In addition, terms used in the present document may tangentially be used as they are derived from other standards such as:

Standard	Description
IEC 60034 series	Rotating electrical machines
IEC 61800 series	Adjustable speed electrical power drive systems
IEC 61158 series	Digital data communications for measurement and control – Fieldbus for use in industrial control systems

Finally, the term *zone of operation* may be used in conjunction with the description of specific hazards, and is defined as it is for a *hazard zone* or *danger zone* in the *Machinery Directive (2006/42/EC)* and *ISO 12100:2010*.

**NOTE:** The aforementioned standards may or may not apply to the specific products cited in the present documentation. For more information concerning the individual standards applicable to the products described herein, see the characteristics tables for those product references.

---

# Chapter 1

## Introduction

---


### What Is in This Chapter?

This chapter contains the following topics:

Topic	Page
Overview of Integrated Drive	14
Components and Interfaces	15
Nameplate	17
Type Code	18

## Overview of Integrated Drive

### Lexium Integrated Drive



The Lexium integrated drive consists of a stepper motor and an integrated drive. The product integrates interfaces, control electronics, a holding brake (optional) and the power stage.

Minimum wiring as well as a comprehensive portfolio of options and accessories allows you to implement compact, high-performance drive solutions for a wide range of power requirements.


### Features

Overview of some of the features:

- Fieldbus interface for EtherNet/IP.
- The drive is commissioned via a PC with the commissioning software “Lexium CT” or the fieldbus.
- Two Drive Profiles are supported:
  - “Generic Profile” (CIP)
  - “Drive Profile Lexium” (manufacturer-specific)
- Four digital 24 V signals. Each of these signals can be used as an input or output.
- The integrated safety-related function Safe Torque Off (STO) as per IEC 61800-5-2 allows for a stop with stop category 0 as per IEC 60204-1 without external power contactors.

## Components and Interfaces

### Overview



- 1 3-phase stepper motor
- 2 Electronics housing
- 3 Insert for sealing (accessory)
- 4 Insert with cable entry (accessory)
- 5 I/O insert with industrial connectors (accessory)
- 6 Switches for settings
- 7 Cover with connector for functional ground, to be removed for installation
- 8 Cover with industrial connector for Vdc supply voltage and IN/OUT fieldbus connection and with connector for functional ground (optional)
- 9 Electrical interfaces

### Motor

The motor is a brushless three-phase stepper motor.

### Electronics

The electronic system comprises control electronics and power stage.

The drive can be parameterized and controlled via the fieldbus interface.

Four digital 24 V signals are also available. Each of these signals can be used as an input or output.

### Holding Brake

The integrated drive is available with an optional integrated holding brake. The holding brake is controlled automatically.

### Vdc Supply Voltage

The Vdc supply voltage supplies the control electronics and the power stage.

### Fieldbus Interface

The integrated drive features an EtherNet/IP fieldbus interface.

The fieldbus interface is used for parameterizing and controlling the drive. The fieldbus interface allows the integrated drive to be operated on a fieldbus via a master controller, for example, a logic controller.

### Communication Interface RS-485

The RS-485 interface is used for commissioning the drive by means of the commissioning software.

The firmware can be updated via the RS-485 interface. Contact your Schneider Electric service representative for any firmware update.

### 24 Vdc Signal Interface

Four digital 24 Vdc signals are available. Each of these signals can be used as an input or output.

The 24 Vdc signals are available to the master controller.



## Type Code

### Overview

Item	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
Type code (example)	I	L	S	2	K	5	7	1	P	B	1	A	0	•	•

Item	Meaning
1 ... 3	<b>Product family</b> ILS = Stepper motor
4	<b>Supply voltage</b> 2 = 24 ... 48 Vdc
5	<b>Fieldbus interface</b> K = EtherNet/IP
6 ... 7	<b>Size</b> 57 = 57 mm 85 = 85 mm
8	<b>Length</b> 1 = 1 stack 2 = 2 stacks 3 = 3 stacks
9	<b>Winding</b> P = Medium speed of rotation/medium torque T = High speed of rotation/medium torque
10	<b>Connection version</b> B = Printed circuit board connector C = Industrial connector
11	<b>Index pulse</b> 1 = With index pulse
12	<b>Holding brake</b> A = Without holding brake F = With holding brake
13	<b>Gearbox</b> 0 = Without gearbox
14 ... 15	<b>Reserved</b>

If you have questions concerning the type code, contact your Schneider Electric representative.

### Designation Customized Version

In the case of a customized version, position 9 of the type code is an "S". The subsequent number defines the customized version. Example: IL•••••S1234--

Contact your local Schneider Electric service representative if you have questions concerning customized versions.

---

# Chapter 2

## Technical Data

---

### What Is in This Chapter?

This chapter contains the following topics:

Topic	Page
Environmental Conditions	20
Mechanical Data	22
Electrical Data	24
Electromagnetic Compatibility	26
Shaft-Specific Data	27
Data for Safety-Related Function STO	28
Conditions for UL 508C and CSA	29

## Environmental Conditions

### Environmental Conditions for Operation

Characteristic	Unit	Value
Chemically active substances as per IEC 60721-3-3, operation		3C1
Ambient temperature (no icing, non-condensing) <sup>(1)</sup>	°C (°F)	0 ... 40 (32 ... 104)
Ambient temperature with current derating of 2 % per one degree Celsius (per 1.8 degrees Fahrenheit) <sup>(1)</sup>	°C (°F)	40 ... 55 (104 ... 131)
Relative humidity	%	15 ... 85
Installation altitude <sup>(2)</sup>	m (ft)	< 1000 (< 3281)
Installation altitude <sup>(2)</sup> if all of the following conditions are met: <ul style="list-style-type: none"> <li>• 45 °C (113 °F) maximum ambient temperature</li> <li>• Reduction of the continuous power by 1% per 100 m (328 ft) above 1000 m (3281 ft)</li> </ul>	m (ft)	1000 ... 2000 (3281 ... 6562)
Installation altitude <sup>(2)</sup> above mean sea level if all of the following conditions are met: <ul style="list-style-type: none"> <li>• 40 °C (104 °F) maximum ambient temperature</li> <li>• Reduction of the continuous power by 1% per 100 m (328 ft) above 1000 m (3281 ft)</li> </ul>	m (ft)	2000 ... 3000 (6562 ... 9843)
<b>(1)</b> Limit values with flanged motor (for example, steel plate 300 x 300x10 mm).		
<b>(2)</b> The installation altitude is defined in terms of altitude above mean sea level.		

### Environmental Conditions for Transportation and Storage

The environment during transportation and storage must be dry and free from dust.


Characteristic	Unit	Value
Chemically active substances as per IEC 60721-3-2, transportation		3C1
Chemically active substances as per IEC 60721-3-1, storage		3C1
Ambient temperature (no icing, non-condensing)	°C (°F)	-25 ... 70 (-13 ... 158)
Relative humidity (non-condensing)	%	5 ... 80

### Vibration and Shock

Characteristic	Value
Vibration, sinusoidal	Type test with 10 runs as per IEC 60068-2-6 0.15 mm (10 Hz ... 60 Hz) 20 m/s <sup>2</sup> (60 Hz - 500 Hz)
Shock, semi-sinusoidal	Type test with 3 shocks in each direction as per IEC 60068-2-27 150 m/s <sup>2</sup> (11 ms)

### IP Degree of Protection

The integrated drive has the following IP degree of protection as per IEC 60529:



Item	Component	Degree of protection
1	Shaft bushing Shaft bushing with GBX gearbox (accessory)	IP41 <sup>(1)</sup> IP54
2	Housing, except shaft bushing	IP54

**(1)** In the case of mounting position IM V3 (shaft vertical, shaft end upward), the degree of protection is IP 40. The degree of protection does not relate to mounted components such as, for example, a gearbox.


The total degree of protection is determined by the component with the lowest degree of protection.

### Pollution Degree

Characteristic	Value
Pollution degree	2

## Mechanical Data


### Dimensions of Integrated Drives with Size 57



- 1 Insert with cable entry (accessory)
- 2 Insert kit (accessory)
- 3 Industrial connector (option)

Dimension	Unit	ILS••57...		
		1P•1A0	2P•1A0	3P•1A0
Total length L	mm (in)	101.9 (4.01)	115.9 (4.56)	138.9 (5.47)
Shaft diameter D	mm (in)	6.35 (0.25)	6.35 (0.25)	8 (0.31)

Dimensions for Integrated Drives with Size 85




- 1 Insert with cable entry (accessory)
- 2 Insert kit (accessory)
- 3 Industrial connector (option)

Dimension	Unit	ILS•85...					
		1•1A0	1•1F0	2•1A0	2•1F0	3•1A0	3•1F0
Total length L	mm (in)	140.6 (5.53)	187.3 (7.37)	170.6 (6.72)	217.3 (8.56)	200.6 (7.90)	247.3 (9.74)
Shaft diameter D	mm (in)	12 (0.47)	12 (0.47)	12 (0.47)	12 (0.47)	14 (0.55)	14 (0.55)

## Electrical Data

### Overview of Connectors



Connection	Assignment
CN1	Connectors for Vdc supply voltage
CN2	Fieldbus interface for EtherNet/IP
CN3	Commissioning interface
CN4	24 V signal interface
CN5	Connector for the safety-related function STO
CN6	Jumper for activating and deactivating the safety-related function STO

### CN1: Vdc Supply Voltage

Characteristic	Unit	ILS••57•	ILS••851, ILS••852	ILS••853
Nominal voltage	Vdc	24 / 48	24 / 48	24 / 48
Minimum voltage		18	18	18
Maximum voltage		55.2	55.2	55.2
Ripple at nominal voltage	Vpp	≤3.6	≤3.6	≤3.6
Maximum input current	A			
Winding type P		3.5	5	5
Winding type T		-	-	6
Overvoltage category	-	III at input of power supply unit, II at output of power supply unit (as per IEC 61800-5-1)		
Capacitance at VDC to 0VDC (for inrush current)	µF	1500	1500	1500
Fuse rating of fuse to be connected upstream	A	≤15	≤15	≤15
Type of fuse or circuit breaker to be connected upstream	-	<ul style="list-style-type: none"> <li>• Circuit-breaker (type Multi 9 - C60BP, M9F42115 by Schneider Electric, 15 A, tripping characteristic C), or</li> <li>• Blade fuse (FKS, 15 A maximum), or</li> <li>• Fuse (5 x 20 mm, 10 A, slow-blow)</li> </ul>		
PELV	-	Required		
Galvanic isolation	-	No		

### CN2: Fieldbus Interface

The EtherNet/IP signals comply with the IEEE 802.3 standard.

Characteristic	Unit	Value
Transmission rate	MBit	10 / 100
Transmission protocol	-	EtherNet/IP

Characteristic	Unit	Value
Galvanic isolation	-	Yes

### CN3: Commissioning Interface

The RS485 signals comply with the RS485 standard.

Characteristic	Unit	Value
Transmission rate	kBaud	9.6 / 19.2 / 38.4
Transmission protocol	-	Modbus RTU
Galvanic isolation	-	No

### CN4: 24 V Signals

The signal inputs are not protected against reverse polarity.

Characteristic	Unit	Value
Logic 0 ( $U_{low}$ )	V	-3 ... 4.5
Logic 1 ( $U_{high}$ )	V	15 ... 30
Input current at 24 Vdc	mA	2
Debounce time LIO1 ... LIO4	ms	1.25 ... 1.5
Debounce time LIO1 and LIO2 <sup>(1)</sup>	ms	0.01
Jitter LIO1 and LIO2	ms	<2
Galvanic isolation	-	No
<b>(1) When the function "Fast Position Capture" is used</b>		

The internal 24 V power supply and the signal outputs are short-circuit protected.

Characteristic	Unit	Value
Nominal voltage	V	24
Voltage range	V	23 ... 25
Maximum current +24VDC_OUT	mA	200
Maximum current per output	mA	100
Maximum total current	mA	200
Suitable for inductive loads	mH	1000
Voltage drop at 50 mA load	V	≤1
Galvanic isolation	-	No

### CN5 and CN6: Safety-Related Function STO

Jumper CN6 to deactivate the safety-related function STO.

Characteristic	Unit	Value
Voltage for logic level 0	V	-3 ... 4.5
Voltage for logic level 1	V	15 ... 30
Input current $\overline{STO\_A}$ at 24 Vdc	mA	≤10
Input current $\overline{STO\_B}$ at 24 Vdc	mA	≤3
Debounce time	ms	1
Detection of difference between level of $\overline{STO\_A}$ and level of $\overline{STO\_B}$	s	>1
Response time of safety-related function STO	ms	<50
Permissible duration of test pulses from upstream devices	ms	<1
PELV	-	Required
Galvanic isolation	-	No

## Electromagnetic Compatibility

### Electromagnetic Compatibility (EMC)

Characteristic	Value
Emission	Category C2 as per IEC 61800-3 Compliant with IEC 61000-6-4
Immunity	Use permissible in second environment as per EN 61800-3

**NOTE:** The emission category is independent of immunity. For example, if a power drive system has emission category 2, this does not imply that it is only suitable for the first environment.

The equipment described in the present document is not intended for use in domestic, residential environments and may not provide adequate protection to radio reception in such environments.

### WARNING

#### INSUFFICIENT ELECTROMAGNETIC COMPATIBILITY

- Verify compliance with all EMC regulations and requirements applicable in the country in which the device is to be operated and with all EMC regulations and requirements applicable at the installation site.
- Do not install and operate the devices described in the present document in residential environments.
- Implement all required radio interference suppression measures and verify their effectiveness.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

**NOTE:** Compliance of the product described in the present manual with Directive 2014/30/EU of the European Parliament and the Council (EMC Directive) is declared with reference to the harmonized standard EN 61800-3 “Adjustable speed power drive systems - Part 3: EMC requirements and specific test methods”. With regard to equipment of category 2, this harmonized standard and the Directive itself oblige manufacturers to include the following statement in their product documentation: “In a domestic environment this product may cause radio interference in which case supplementary mitigation measures may be required.”

## Shaft-Specific Data

### Overview

If the maximum permissible forces at the motor shaft are exceeded, this will result in premature wear of the bearing or shaft breakage.

<b>⚠ WARNING</b>
<b>UNINTENDED EQUIPMENT OPERATION DUE TO MECHANICAL DAMAGE TO THE MOTOR</b>
<ul style="list-style-type: none"> <li>• Do not exceed the maximum permissible axial and radial forces at the motor shaft.</li> <li>• Protect the motor shaft from impact.</li> <li>• Do not press output components onto the shaft unless the shaft has a thread that can be used for pressing on.</li> </ul>
<b>Failure to follow these instructions can result in death, serious injury, or equipment damage.</b>

### Mounting Output Components

If the shaft has a thread, use it to press on the component to be mounted. This way there is no axial force acting on the rolling bearing.


It is also possible to shrink-fit, clamp, or glue the component to be mounted.

### Shaft Load

The following conditions apply:

- The permissible force applied during pressing on must not be exceeded.
- The maximum permissible radial force and the maximum permissible axial force must not be applied simultaneously.
- Nominal bearing service life in operating hours at a probability of failure of 10% ( $L_{10h} = 20000$  hours)
- Mean speed of rotation  $n = 60$  RPM
- Ambient temperature = 40 °C (104 °F)
- Nominal torque = Duty type S1, 100% duty cycle

The following figure shows the points of application of forces:



The following table shows the maximum radial and axial forces:

Characteristic	Unit	Value					
		ILS2•571	ILS2•572	ILS2•573	ILS2•851	ILS2•852	ILS2•853
Maximum radial force $F_R$ at 100% duty cycle and $X = 10.5$ mm (0.41 in)	N (lbf)	24 (5.40)	24 (5.40)	50 (11.24)	100 (22.48)	100 (22.48)	110 (24.73)
Maximum axial force $F_A$ at 100% duty cycle, tension	N (lbf)	100 (22.48)	100 (22.48)	100 (22.48)	170 (38.22)	170 (38.22)	170 (38.22)
Maximum axial force $F_A$ at 100% duty cycle, compression	N (lbf)	8.4 (1.89)	8.4 (1.89)	8.4 (1.89)	30 (6.74)	30 (6.74)	30 (6.74)

## Data for Safety-Related Function STO

### Data for Safety-Related Calculations and Maintenance Plan

The safety-related function must be triggered at regular intervals. The interval depends on, among other things, the risk assessment for the overall system. The minimum interval is one year (high demand mode as per IEC 61508).

Use the following data of the safety-related function STO for the maintenance plan of your machine and for the calculations for functional safety:

Lifetime of the safety-related function STO (IEC 61508) <sup>(1)</sup>	Years	20
SFF (IEC 61508) Safe Failure Fraction	%	47
HFT (IEC 61508) Hardware Fault Tolerance Type A subsystem	-	1
Safety Integrity Level (IEC 61508) Safety Integrity Level Claim Limit (IEC 62061)	-	SIL2 SILCL2
PFH (IEC 61508) Probability of Dangerous Hardware Failure per Hour	1/h	$5.223 \cdot 10^{-9}$
PL (ISO 13849-1) Performance Level	-	d (category 3)
MTTF <sub>d</sub> (ISO 13849-1) Mean Time to Dangerous Failure	Years	1995
DC (ISO 13849-1) Diagnostic Coverage	%	90
Demand Mode (IEC 61508)	-	High Demand Mode (safety-related function must be triggered at least once per year)
<b>(1)</b> Refer to the chapter Lifetime Safety-Related Function STO ( <i>see page 222</i> ).		

Contact your local Schneider Electric representative for additional data, if required.

---

## Conditions for UL 508C and CSA

### Description

If the product is used to comply with UL 508C, the following conditions must also be met:

### PELV Power Supply

Use only power supply units that are approved for overvoltage category III.

### Motor Overload Protection

This equipment provides Solid State Motor Overload Protection at 200 % of maximum FLA (Full Load Ampacity).

### Fuses

The product was tested with a UL-listed 15 A circuit breaker. The product must be fused either with a UL-listed circuit breaker or a fuse for "Branch Circuit Protection" as per UL 248 with a maximum current of 15 A and DC rating.

### Wiring

Use at least 60/75 °C copper conductors.



---

# Chapter 3

## Engineering

---

### What Is in This Chapter?

This chapter contains the following sections:

Section	Topic	Page
3.1	Electromagnetic Compatibility (EMC)	32
3.2	Power Supply	34
3.3	Functional Safety	37
3.4	EtherNet/IP Fieldbus	44
3.5	EtherNet/IP Communication	48

# Section 3.1

## Electromagnetic Compatibility (EMC)

### Electromagnetic Compatibility (EMC)

#### EMC-Compliant Wiring

This product meets the EMC requirements according to the standard EN 61800-3 if the measures described in this manual are implemented during installation.

Signal interference can cause unexpected responses of the drive system and of other equipment in the vicinity of the drive system.

<b>⚠ WARNING</b>
<b>SIGNAL AND EQUIPMENT INTERFERENCE</b>
<ul style="list-style-type: none"> <li>● Install the wiring in accordance with the EMC requirements described in the present document.</li> <li>● Verify compliance with the EMC requirements described in the present document.</li> <li>● Verify compliance with all EMC regulations and requirements applicable in the country in which the product is to be operated and with all EMC regulations and requirements applicable at the installation site.</li> </ul>
<b>Failure to follow these instructions can result in death, serious injury, or equipment damage.</b>

<b>⚠ WARNING</b>
<b>ELECTROMAGNETIC DISTURBANCES OF SIGNALS AND DEVICES</b>
Use proper EMI shielding techniques to help prevent unintended device operation in accordance with the standard IEC 61800-3.
<b>Failure to follow these instructions can result in death, serious injury, or equipment damage.</b>

Refer to the chapter Electromagnetic Compatibility (*see page 26*) for technical data on EMC.

**NOTE:** The emission category is independent of immunity. For example, if a power drive system has emission category 2, this does not imply that it is only suitable for the first environment.

The equipment described in the present document is not intended for use in domestic, residential environments and may not provide adequate protection to radio reception in such environments.

<b>⚠ WARNING</b>
<b>INSUFFICIENT ELECTROMAGNETIC COMPATIBILITY</b>
<ul style="list-style-type: none"> <li>● Verify compliance with all EMC regulations and requirements applicable in the country in which the device is to be operated and with all EMC regulations and requirements applicable at the installation site.</li> <li>● Do not install and operate the devices described in the present document in residential environments.</li> <li>● Implement all required radio interference suppression measures and verify their effectiveness.</li> </ul>
<b>Failure to follow these instructions can result in death, serious injury, or equipment damage.</b>

#### Shielded Cables

EMC measures	Objective
Connect large surface areas of cable shields, use cable clamps and ground straps.	Reduces emissions.
Ground shields of digital signal wires at both ends by connecting them to a large surface area or via conductive connector housings.	Reduces interference affecting the signal wires, reduces emissions

## Cable Installation

EMC measures	Objective
Do not route fieldbus cables and signal wires in a single cable duct together with lines with DC and AC voltages of more than 60 V. (Fieldbus cables, signal lines and analog lines may be in the same cable duct) Use separate cable ducts at least 20 cm (7.87 in) apart.	Reduces mutual interference
Keep cables as short as possible. Do not install unnecessary cable loops, use short cables from the central grounding point in the control cabinet to the external ground connection.	Reduces capacitive and inductive interference.
Use equipotential bonding conductors in the following cases: wide-area installations, different voltage supplies and installation across several buildings.	Reduces current in the cable shield, reduces emissions.
Use fine stranded equipotential bonding conductors.	Diverts high-frequency interference currents.
If motor and machine are not conductively connected, for example by an insulated flange or a connection without surface contact, you must ground the motor with a ground strap or a ground wire. The conductor cross section must be at least 10 mm <sup>2</sup> (AWG 6).	Reduces emissions, increases immunity.

## Section 3.2

### Power Supply

---

#### What Is in This Section?

This section contains the following topics:

Topic	Page
External Power Supply Units	35
Wiring Information	36

## External Power Supply Units

### General Information

#### WARNING

##### UNINTENDED EQUIPMENT OPERATION

- Use power supply units that meet the PELV (Protective Extra Low Voltage) requirements.
- Connect the 0 Vdc outputs of all power supply units to FE (functional earth/functional ground), for example, for the VDC supply voltage and for the 24 Vdc voltage for the safety-related function STO.
- Interconnect all 0 Vdc outputs (reference potentials) of all power supply units used for the drive.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

The motor regenerates energy during deceleration and when external driving forces act on the motor shaft. This can increase the  $v_{DC}$  voltage up to 60 Vdc. The DC bus can absorb a limited amount of energy via the capacitors. If the capacity of the capacitors is exceeded, this results in overvoltage on the DC bus. Overvoltage on the DC bus causes the power stage to be disabled. The motor is no longer actively decelerated.

#### WARNING

##### LOSS OF CONTROL DUE TO REGENERATION CONDITION

- Verify that the integrated drive can absorb the entire energy generated during deceleration by performing test runs under maximum load conditions.
- Install an external Braking Resistor Controller (UBC60) if the integrated drive cannot absorb the entire energy generated under maximum load conditions.
- Verify that all equipment is properly isolated from high Vdc voltage for which it is not rated, or use properly rated equipment.
- Only use power supply units that can withstand the voltage that may be present during regeneration conditions.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

Refer to the chapter Accessories ([see page 217](#)) for a braking resistor controller. Refer to the user guide of the braking resistor controller for additional details.

Reverse polarity of the  $v_{dc}$  supply voltage leads to a short-circuit.

#### NOTICE

##### INCORRECT POLARITY

Verify correct polarity of the Vdc supply voltage before applying power.

**Failure to follow these instructions can result in equipment damage.**

The external power supply unit must be rated for the power requirements of the drive. Refer to the chapter Electrical Data ([see page 24](#)) for the input current.

### Fusing

Install the fusing specified in the chapter Electrical Data ([see page 24](#)).

## Wiring Information

### Description

The reference potential of interfaces without galvanic isolation is internally connected via 0VDC. If the negative connection (0VDC) between the power supply and the drive is interrupted, the current of the power stage flows via the negative connection of the interfaces without galvanic isolation.

### WARNING

#### LOSS OF CONTROL

- Do not interrupt the negative connection between the power supply unit and the drive, for example, by means of a switch or a fuse.
- Connect the reference potential of interfaces with galvanic isolation to 0VDC.
- Do not connect the reference potential of interfaces without galvanic isolation to 0VDC.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

Wiring the product:

- Keep the voltage drop on the supply cables for the  $v_{dc}$  supply voltage to less than 1 V. The reference potential of some interfaces are connected to 0VDC. At higher potential differences, the communication and control signals can be disturbed.  
Decentralized power supply units for  $v_{DC}$  close to the drives are advisable if the drives are installed at greater distances from each other. Connect 0VDC of the individual power supply units with the largest possible conductor cross section.
- Do not connect any other power supply in parallel with the internal 24 V power supply (+24VDC\_OUT). This may cause overloads of the internal 24 V power supply.

### Equipotential Bonding Conductors

Potential differences can result in excessive currents on the cable shields. Use equipotential bonding conductors to reduce currents on the cable shields. The equipotential bonding conductor must be rated for the maximum current.

---

## Section 3.3

### Functional Safety

---

#### What Is in This Section?

This section contains the following topics:

Topic	Page
Definitions	38
Function	39
Requirements for Using the Safety-Related Function STO	40
Application Examples STO	42

## Definitions

### Integrated Safety-Related Function "Safe Torque Off" STO

The integrated safety-related function STO (IEC 61800-5-2) allows for a category 0 stop as per IEC 60204-1 without external power contactors. It is not necessary to interrupt the supply voltage for a category 0 stop. This reduces the system costs and the response times.

### Category 0 Stop (IEC 60204-1)

In stop category 0 (Safe Torque Off, STO), the drive coasts to a stop (provided there are no external forces operating to the contrary). The safety-related function STO is intended to help prevent an unintended start-up, not stop a motor, and therefore corresponds to an unassisted stop in accordance with IEC 60204-1.

In circumstances where external influences are present, the coast down time depends on physical properties of the components used (such as weight, torque, friction, etc.), and additional measures such as external safety-related brakes may be necessary to help prevent any hazard from materializing. That is to say, if this means a hazard to your personnel or equipment, you must take appropriate measures.

 <b>WARNING</b>
<b>UNINTENDED EQUIPMENT OPERATION</b>
<ul style="list-style-type: none"><li>● Make certain that no hazards can arise for persons or material during the coast down period of the axis/machine.</li><li>● Do not enter the zone of operation during the coast down period.</li><li>● Ensure that no other persons can access the zone of operation during the coast down period.</li><li>● Use appropriate safety interlocks where personnel and/or equipment hazards exist.</li></ul>
<b>Failure to follow these instructions can result in death, serious injury, or equipment damage.</b>

### Category 1 Stop (IEC 60204-1)

For stops of category 1 (Safe Stop 1, SS1), you can initiate a controlled stop via the control system, or through the use of specific functional safety-related devices. A Category 1 Stop is a controlled stop with power available to the machine actuators to achieve the stop.

The controlled stop by the control/safety-related system is not safety-relevant, nor monitored, and does not perform as defined in the case of a power outage or if an error is detected. This has to be implemented by means of an external safety-related switching device with safety-related delay.

## Function

### General

The safety-related function STO integrated into the product can be used to implement an "EMERGENCY STOP" (IEC 60204-1) for category 0 stops. With an additional, approved EMERGENCY STOP safety relay module, it is also possible to implement category 1 stops.

### Function Principle

The safety-related function STO is triggered via two redundant signal inputs. The wiring of the two signal inputs must be separate.

The safety-related function STO is triggered if the level at one of the two signal inputs is 0. The power stage is disabled. The motor can no longer generate torque and coasts down without braking. An error of error class 3 is detected.

If, within one second, the level of the other output also becomes 0, the error class remains 3. If, within one second, the level of the other output does not become 0, the error class changes to 4.

## Requirements for Using the Safety-Related Function STO

### General

The safety-related function STO (Safe Torque Off) does not remove power from the DC bus. The safety-related function STO only removes power to the motor. The DC bus voltage and the mains voltage to the drive are still present.

 <b>DANGER</b>
<b>ELECTRIC SHOCK</b>
<ul style="list-style-type: none"><li>• Do not use the safety-related function STO for any other purposes than its intended function.</li><li>• Use an appropriate switch, that is not part of the circuit of the safety-related function STO, to disconnect the drive from the mains power.</li></ul>
<b>Failure to follow these instructions will result in death or serious injury.</b>

After the safety-related function STO is triggered, the motor can no longer generate torque and coasts down without braking.

 <b>WARNING</b>
<b>UNINTENDED EQUIPMENT OPERATION</b>
Install a dedicated, external safety-related brake if coasting does not meet the deceleration requirements of your application.
<b>Failure to follow these instructions can result in death, serious injury, or equipment damage.</b>

### Logic Type

The inputs for the safety-related function STO (inputs  $\overline{STO\_A}$  and  $\overline{STO\_B}$ ) can only be wired for positive logic.

### Holding Brake and Safety-Related Function STO

When the safety-related function STO is triggered, the power stage is immediately disabled. Applying the holding brake requires a certain amount of time. In the case of vertical axes or external forces acting on the load, you may have to take additional measures to bring the load to a standstill and to keep it at a standstill when the safety-related function STO is used, for example, by using a service brake.

 <b>WARNING</b>
<b>FALLING LOAD</b>
Ensure that all loads come to a secure standstill when the safety-related function STO is used.
<b>Failure to follow these instructions can result in death, serious injury, or equipment damage.</b>

If the suspension of hanging / pulling loads is a safety objective for the machine, then you can only achieve this objective by using an appropriate external brake as a safety-related measure.

 <b>WARNING</b>
<b>UNINTENDED AXIS MOVEMENT</b>
<ul style="list-style-type: none"><li>• Do not use the internal holding brake as a safety-related measure.</li><li>• Only use certified external brakes as safety-related measures.</li></ul>
<b>Failure to follow these instructions can result in death, serious injury, or equipment damage.</b>

**NOTE:** The drive does not provide its own safety-related output to connect an external brake to use as a safety-related measure.

## Unintended Restart

<b>⚠ WARNING</b>
<p><b>UNINTENDED EQUIPMENT OPERATION</b></p> <ul style="list-style-type: none"> <li>• Verify that your risk assessment covers all potential effects of automatic or unintended enabling of the power stage, for example, after power outage.</li> <li>• Implement all measures such as control functions, guards, or other safety-related functions, required to reliably protect against all hazards that may result from automatic or unintended enabling of the power stage.</li> <li>• Verify that a master controller cannot enable the power stage in an unintended way.</li> </ul> <p><b>Failure to follow these instructions can result in death, serious injury, or equipment damage.</b></p>

<b>⚠ WARNING</b>
<p><b>UNINTENDED EQUIPMENT OPERATION</b></p> <p>Set the parameter <code>IO_AutoEnable</code> to "off" if the automatic enabling of the power stage presents hazards in your application.</p> <p><b>Failure to follow these instructions can result in death, serious injury, or equipment damage.</b></p>

## Degree of Protection when the Safety-Related Function STO is Used

You must ensure that conductive substances cannot get into the product (pollution degree 2). Moreover, conductive substances may cause the safety-related function to become inoperative.

<b>⚠ WARNING</b>
<p><b>INOPERABLE SAFETY-RELATED FUNCTION</b></p> <p>Ensure that conductive substances (water, contaminated or impregnated oils, metal shavings, etc.) cannot get into the drive.</p> <p><b>Failure to follow these instructions can result in death, serious injury, or equipment damage.</b></p>

## Protected Cable Installation

If short circuits and other wiring errors such as a cross circuit between the signals of the safety-related function STO can be expected in connection with safety-related signals, and if these short circuits and cross circuits are not detected by upstream devices, protected cable installation as per ISO 13849-2 is required.

In the case of an unprotected cable installation, the two signals (both channels) of a safety-related function may be connected to external voltage if a cable is damaged. If the two channels are connected to external voltage, the safety-related function is no longer operative.

ISO 13849-2 describes protected cable installation for cables for safety-related signals. The cables for the safety-related function STO must be protected against external voltage. A shield with ground connection helps to keep external voltage away from the cables for the signals of the safety-related function STO.

Ground loops can cause problems in machines. A shield connected at one end only is sufficient for grounding and does not create a ground loop.


- Use shielded cables for the signals of the safety-related function STO.
- Do not use the cable for the signals of the safety-related function STO for other signals.
- Connect one end of the shield.

## Application Examples STO

### Example of Category 0 stop

Use without EMERGENCY STOP safety relay module, category 0 stop.

Example of category 0 stop:



In this example, when an EMERGENCY STOP is activated, it leads to a category 0 stop.

The safety-related function STO is triggered via a simultaneous 0-level at both inputs (time offset of less than 1 s). The power stage is disabled and an error of error class 3 is detected. The motor can no longer generate torque.

If the motor is not already at a standstill when the safety-related function STO is triggered, it decelerates under the salient physical forces (gravity, friction, etc.) active at the time until presumably coasting to a standstill.

If coasting of the motor and its potential load is unsatisfactory as determined by your risk assessment, an external safety-related brake may also be required.

### **⚠ WARNING**

#### **UNINTENDED EQUIPMENT OPERATION**

Install a dedicated, external safety-related brake if coasting does not meet the deceleration requirements of your application.


**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

Refer to the chapter Holding Brake and Safety-Related Function STO ([see page 40](#)).

### Example of Category 1 stop

Use with EMERGENCY STOP safety relay module, category 1 stop.

Example of category 1 stop with external Preventa XPS-AV EMERGENCY STOP safety relay module:



In this example, when an EMERGENCY STOP is activated, it leads to a category 1 stop.

The EMERGENCY STOP safety relay module requests an immediate stop (undelayed) of the drive. After the time delay set in the EMERGENCY STOP safety relay module has elapsed, the EMERGENCY STOP safety relay triggers the safety-related function STO.

The safety-related function STO is triggered via a simultaneous 0-level at both inputs (time offset of less than 1 s). The power stage is disabled and an error of error class 3 is detected. The motor can no longer generate torque.

If coasting of the motor and its potential load is unsatisfactory as determined by your risk assessment, an external safety-related brake may also be required.

## **⚠ WARNING**

### **UNINTENDED EQUIPMENT OPERATION**

Install a dedicated, external safety-related brake if coasting does not meet the deceleration requirements of your application.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

Refer to the chapter Holding Brake and Safety-Related Function STO ([see page 40](#)).

## Section 3.4

### EtherNet/IP Fieldbus

---

#### What Is in This Section?

This section contains the following topics:

Topic	Page
General	45
Messaging and Message Types	47

## General

### ODVA

The ODVA is the proprietor of the specifications for the EtherNet/IP network and EtherNet/IP data terminal equipment. For more information on the ODVA see:

<http://www.odva.org>

### Number of Nodes

The number of nodes in an EtherNet/IP network is theoretically unlimited; it depends on the subnet size and on whether or not a CIP router is used. For example, 254 nodes are possible in a class C subnet.

### Cable Length

The maximum cable length is 100 m (328 ft) between EtherNet/IP terminal points and 90 m (295 ft) between infrastructure components. However, interference in industrial environments may require you to use shorter cables.

### Drive Profiles


The product supports the following drive profiles:

- "Generic Profile" (CIP)
- "Drive Profile Lexium" (manufacturer-specific)

### Communication Means

The product supports the following communication means:

Overview of communication means:



- Group 2 servers
- UCMM-enabled devices
- Class 1 connections via assemblies:
- Master-slave connections:
  - "Explicit Message"
  - "Polled I/O Connection"
  - "Fragmentation Protocol" support
  - Dynamic establishment of 2 "Explicit Connections" and one "I/O Connection"

The product identifies itself as CIP "Generic Device" (Device Type = 0 hex).

### Data Link Layer

The EtherNet/IP data link layer uses the transmission mechanisms as per IEEE 802.3 Standard Ethernet specification (edition 2002).

**Physical Layer**

Industrial EtherNet/IP specifies minimum requirements in terms of ambient conditions, cabling, and connectors, based on IEC, ANSI, TIA, and EIA standards.

The connectors required for Industrial EtherNet/IP include M12-4 connectors, D-coded. Use CAT5e or CAT6 cables for Industrial EtherNet/IP.

Copper media may be used only for distances up to 100 m (328 ft).

**Object Class, Instance, Attribute, Service**

The EtherNet/IP approach is object-oriented. CIP defines object classes; one or more instances (objects) can be derived from such object classes. The attributes of an object class or the instance derived from it contain the various parameters. Services are actions that are possible with these attributes.

**Example**

Class	Instance	Attribute	Attribute value	Service
Motor data	Motor_1	MaxSpeed	4000 RPM	Get
Motor data	Motor_2	MaxSpeed	3000 RPM	Get

**CIP Object Model**

The following object classes from the CIP object model are available:

Object class	Class ID	Instance ID
Identity Object	1 (01 hex)	1
Message Router Object	2 (02 hex)	1
Assembly Object	4 (04 hex)	103 = Output Assembly, consuming 113 = Input Assembly, producing
Connection Manager Object	6 (06 hex)	1= Explicit Message
Vendor-specific objects	101 ... 163 (65 ... A3 hex)	1
Port Object	244 (F4 hex)	1
TCP/IP Object	245 (F5 hex)	1
Ethernet Link Object	246 (F6 hex)	2

The vendor-specific object class IDs 101 to 163 correspond to the object dictionary (class ID = object group + 100). The attributes of a class correspond to the subindex entry within the object group.

**Communication Model**

EtherNet/IP uses the producer-consumer communication model. The nodes monitor the bus as to whether a data packet with the Identifier they support is available. Data packets that are sent by producers can only be received by the consumers of these packets.

**Groups of Connections**

EtherNet/IP is a connection-oriented network. Connections must be established and managed between two nodes. There are 4 connection groups with different priorities:

Group 1	Top-priority process data (highest priority)
Group 2	For master-slave connections
Group 3	For Explicit Messages
Group 4	Reserved group (lowest priority)

**EDS File (Electronic Data Sheet)**

The EDS file contains device-specific and vendor-specific descriptions of the parameters for a drive. The EDS file also contains the fieldbus-specific communication parameters.

## Messaging and Message Types

### General

EtherNet/IP is based on TCP/IP and UDP/IP technologies that are used without modification. TCP/IP is used for the transmission of Explicit Messages while UDP/IP is used for I/O Messages.

### Messaging and Message Types

EtherNet/IP defines several message types for communication. The drive uses the message types “Explicit Message” and “I/O Message”.

### Explicit Messages

Explicit Messaging connections are point-to-point connections between two network nodes that are used for transactions of the type request - response. The data field of Explicit Messages contains both protocol data and application-specific commands.

An Explicit Message (EtherNet/IP-specific or vendor-specific) is used to read or write an individual parameter.

The parameter is accessed by means of Class.Instance.Attribute as per CIP.

### I/O Messages

I/O Messages, also referred to as Implicit Messages, are transmitted via UDP/IP. I/O Message connections are often established as One-to-Many relationships in the producer-consumer multicast model of EtherNet/IP. The data fields of I/O Messages contain no protocol information, but only time-critical I/O data. I/O Messages are considerably smaller than Explicit Messages, thus allowing for faster processing. These messages are used to transport application-specific I/O data over the network at regular intervals. The meaning of the data is defined at the time the connection is established. I/O Messages can contain so-called Assemblies of several parameters that can be transmitted with a single message. The parameters for configuring EtherNet/IP communication are described in chapter Commissioning (*see page 81*).

### Command Processing: Transmit Data and Receive Data

The master sends a command to the drive system (slave) to execute a motion command, activate functions or request information from the slave. The slave executes the command and acknowledges it with a response message that may contain an error message if an error has been detected.

The master can send new commands as soon as it has received acknowledgment concerning the current command. Acknowledgment information and error messages are included in the transmitted data in bit-coded form. The master must then continuously monitor for completion of the command by evaluating the acknowledgment from the slave. I/O messages are a special case. I/O messages are not acknowledged by the slave.

---

## Section 3.5

### EtherNet/IP Communication

---

#### What Is in This Section?

This section contains the following topics:

Topic	Page
Communication via I/O Messages	49
Output Assembly, Instance 103	50
Input Assembly, Instance 113	51
Handshake via the Bit "MT" (Mode Toggle)	53

---

## Communication via I/O Messages

### Overview

An I/O Message is used for realtime exchange of process data. Transmission is very fast because the data is sent without administration data and a transmission acknowledgment from the recipient is not required.

The master can control the operating states of the slave by means of I/O Message, for example, enable and disable the power stage, trigger a Quick Stop, reset detected errors and activate operating modes.

Changing operating states and activating operating modes must be done separately. An operating mode can only be activated in the operating state "Operation Enabled".

### Output, Input

Output and Input refer to the direction of data transmission from the perspective of the master.

- Output: Commands from the master to the slave
- Input: Status messages from the slave to the master

### Assembly

I/O Messages contain a collection (Assembly) of different parameters that are transmitted with a single message.

The following Assemblies are available:

- Output Assembly, instance 103
- Input Assembly, instance 113

### Polled I/O Connection

The Assemblies are used in a Polled I/O Connection. A Polled I/O Connection is initiated by the master with a Poll Command. The Slave responds with a Poll Response.

## Output Assembly, Instance 103

### Overview

Memory map for Output Assembly data.

Byte	Name	Parameter address CIP
0	Attribute (Subindex)	Parameter channel
1	Command (AK)	
2 ... 3	Class (Index)	
4 ... 7	Data	
8 ... 11	Ref_32	-
12 ... 13	Ref_16	-
14	modeControl	-
15	driveControl	-
16 ... 19	RAMPacc	CIP 106.1.10
20 ... 23	RAMPdecel	CIP 106.1.11
24 ... 39	Reserved	-

### Bytes "Attribute" and "Command", Word "Class" and Double Word "Data"

The bytes "Attribute" and "Command", the word "Class" and the double word "Data" are used to read and write parameters (parameter channel).

### Double Word "Ref\_32" and Word "Ref\_16"

The two double words "Ref\_32" and the word "Ref\_16" are used to set two operating mode-specific values. The meaning is described in the chapters covering the individual operating modes.

### Byte "modeControl"

The word "modeControl" is used to set the operating mode.

Refer to the chapter Starting and Changing an Operating Mode ([see page 124](#)) for a detailed description of the bits.

### Byte "driveControl"

The word "driveControl" is used to set the operating state.

Refer to the chapter Changing the Operating State via Fieldbus ([see page 121](#)) for a detailed description of the bits.

### Double Words "RAMPacc" and "RAMPdecel"

The two double words "RAMPacc" and "RAMPdecel" are used to set the acceleration and the deceleration. They correspond to the parameters of the same name.

## Input Assembly, Instance 113

### Overview

Memory map for Input Assembly data.

Byte	Name	Parameter address CIP
0	Attribute (Subindex)	Parameter channel
1	Command (AK)	
2 ... 3	Class (Index)	
4 ... 7	Data	
8 ... 9	Special Functions	-
10 ... 11	ActionWord	-
12	Digital IO	-
13	modeStat	-
14 ... 15	driveStat	-
16 ... 19	_p_actusr	CIP 130.1.13
20 ... 23	_n_act	CIP 130.1.8
24 ... 39	Reserved	-

### Bytes "Attribute" and "Command", Word "Class" and Double Word "Data"

The bytes "Attribute" and "Command", the word "Class" and the double word "Data" are used to read and write parameters (parameter channel).

### Word "Special Functions"

The word "Special Functions" is used to indicate the state of the counter of the capture inputs.

Bit	Meaning
0	Bit 0 of the counter of the capture input 1.
1	Bit 1 of the counter of the capture input 1.
2	Bit 0 of the counter of the capture input 2.
3	Bit 1 of the counter of the capture input 2.
4 ... 15	Reserved

### Word "ActionWord"

The word "ActionWord" is used to provide information on the motor and profile generator.

Bit	Meaning
0 ... 5	Reserved
6	MOTZ: Motor at a standstill
7	MOTP: Motor movement in positive direction
8	MOTN: Motor movement in negative direction
9	PWIN: Inside position deviation window
10	Reserved
11	TAR0: Profile generator at standstill
12	DEC: Profile generator decelerates
13	ACC: Profile generator accelerates
14	CNST: Profile generator moves at constant velocity
15	Reserved

### Byte "Digital IO"

The byte "Digital IO" is used to indicate the state of the digital signal inputs.

Bit	Signal	Factory setting
0	LIO1	Signal input function Input Positive Limit Switch (LIMP)
1	LIO2	Signal input function Input Negative Limit Switch (LIMN)
2	LIO3	Signal input function Input Free Available
3	LIO4	Signal input function Input Reference Switch (REF)
4	$\overline{\text{STO\_A}}$	Signal $\overline{\text{STO\_A}}$ of safety-related function STO
5	$\overline{\text{STO\_B}}$	Signal $\overline{\text{STO\_B}}$ of safety-related function STO
6 ... 7	-	Reserved

### Byte "modeStat"

The byte "modeStat" is used to indicate the current operating mode.

Refer to the chapter Indicating the Operating Mode (*see page 123*) for a detailed description of the bits.

### Word "driveStat"

The current operating state is indicated with the "driveStat" word.

Refer to the chapter Indication of the Operating State via Fieldbus (*see page 119*) for a detailed description of the bits.

### Double Word "\_p\_actusr"

The double word "\_p\_actusr" indicates the actual position. The value corresponds to the parameter `_p_actusr`.

### Double Word "\_n\_act"

The double word "\_n\_act" indicates the actual velocity. The value corresponds to the parameter `_n_act`.

## Handshake via the Bit "MT" (Mode Toggle)

### Mode Toggle


Synchronized processing can be carried out with the transmit data in the word "dmControl" bit "MT" (Mode Toggle) and the receive data in the word "mfStat", bit "ME" (Mode Error) and bit "MT" (Mode Toggle). Synchronized processing means that the master waits for feedback messages from the slave so it can respond appropriately.

The bit "MT" (Mode Toggle) is effective with a rising edge and a falling edge.

### Example 1: Positioning

The master starts a movement. At points in time  $t_1$ ,  $t_2$  ..., the master verifies the responses from the slave. It waits for the end of the movement. The end is identified by bit "x\_end" = 1.

Mode Toggle Handshake:




- 1 Master starts movement with "Mode Toggle" = 1
- 2 Slave signals that movement is running with "Mode Toggle" = 1; at the same time "x\_end" = 0
- 3 Slave signals "movement terminated" with "x\_end" = 1

### Example 2: Short-Distance Movement

The master starts a movement whose duration is shorter than the request cycle of the master. At point in time  $t_1$ , the movement is already terminated. Bit "x\_end" does not allow the master to detect whether the movement has already been terminated or has not yet started. However, it can identify this with the bit "MT" (Mode Toggle).

Mode Toggle Handshake, short-distance movement:



- 1 Master starts movement with "Mode Toggle" = 1
- 2 Slave signals that movement is running with "Mode Toggle" = 1; at the same time "x\_end" = 0
- 3 Slave signals "movement terminated" with "x\_end" = 1



---

# Chapter 4

## Installation

---

### What Is in This Chapter?

This chapter contains the following sections:

Section	Topic	Page
4.1	Mechanical Installation	56
4.2	Electrical Installation	60
4.3	Verifying Installation	80

# Section 4.1

## Mechanical Installation

---

### What Is in This Section?

This section contains the following topics:

Topic	Page
Before Mounting	57
Mounting the Integrated Drive	58

## Before Mounting

### General

An engineering phase is mandatory prior to mechanical and electrical installation. See chapter Engineering (*see page 31*) for basic information.

 <b>DANGER</b>
<p><b>ELECTRIC SHOCK OR UNINTENDED EQUIPMENT OPERATION</b></p> <ul style="list-style-type: none"> <li>• Keep foreign objects from getting into the product.</li> <li>• Verify the correct seating of seals and cable entries in order to avoid contamination such as deposits and humidity.</li> </ul> <p><b>Failure to follow these instructions will result in death or serious injury.</b></p>

Conductive foreign objects, dust or liquids may cause safety-related functions to become inoperative.

 <b>WARNING</b>
<p><b>LOSS OF SAFETY-RELATED FUNCTION CAUSED BY FOREIGN OBJECTS</b></p> <p>Protect the system against contamination by conductive substances.</p> <p><b>Failure to follow these instructions can result in death, serious injury, or equipment damage.</b></p>

The metal surfaces of the product may exceed 70 °C (158 °F) during operation.

 <b>CAUTION</b>
<p><b>HOT SURFACES</b></p> <ul style="list-style-type: none"> <li>• Avoid unprotected contact with hot surfaces.</li> <li>• Do not allow flammable or heat-sensitive parts in the immediate vicinity of hot surfaces.</li> <li>• Verify that the heat dissipation is sufficient by performing a test run under maximum load conditions.</li> </ul> <p><b>Failure to follow these instructions can result in injury or equipment damage.</b></p>

### Inspecting the Product

- Verify the product version by means of the Type Code (*see page 18*) on the Nameplate (*see page 17*).
- Prior to mounting, inspect the product for visible damage.

Damaged products may cause electric shock or unintended equipment operation.

 <b>DANGER</b>
<p><b>ELECTRIC SHOCK OR UNINTENDED EQUIPMENT OPERATION</b></p> <ul style="list-style-type: none"> <li>• Do not use damaged products.</li> <li>• Keep foreign objects (such as chips, screws or wire clippings) from getting into the product.</li> </ul> <p><b>Failure to follow these instructions will result in death or serious injury.</b></p>

Contact your local Schneider Electric representative if you detect any damage whatsoever to the products.

### Mounting Surface for Flange

The integrated drive features four holes for mounting it to a flange.

The mounting surface must be plane, stable, clean, deburred, low-vibration, and grounded. Functional grounding must be established either via the mounting flange or via the functional ground connection.

Verify that the mounting surface meets all requirements in terms of dimensions and tolerances. See chapter Mechanical Data (*see page 22*).

Painted surfaces have an insulating effect. Verify that the motor flange is mounted in such a way as to allow for good electrical and thermal conductivity.

## Mounting the Integrated Drive

### General

Motors can generate strong local electrical and magnetic fields. This can cause interference in sensitive devices.

<b>⚠ WARNING</b>
<b>ELECTROMAGNETIC FIELDS</b>
<ul style="list-style-type: none"><li>• Keep persons with electronic medical implants, such as pacemakers, away from the motor.</li><li>• Do not place electromagnetically sensitive devices in the vicinity of the motor.</li></ul>
<b>Failure to follow these instructions can result in death, serious injury, or equipment damage.</b>

Electrostatic discharge to the shaft may cause incorrect operation of the encoder system and result in unanticipated motor movements and damage to the bearing.

<b>⚠ WARNING</b>
<b>UNINTENDED MOVEMENT CAUSED BY ELECTROSTATIC DISCHARGE</b>
Use conductive components such as antistatic belts or other suitable measures to avoid static charge by motion.
<b>Failure to follow these instructions can result in death, serious injury, or equipment damage.</b>

If the permissible environmental conditions are not respected, external substances from the environment may penetrate the product and cause unintended movement or equipment damage.

<b>⚠ WARNING</b>
<b>UNINTENDED EQUIPMENT OPERATION</b>
<ul style="list-style-type: none"><li>• Verify that the environmental conditions are respected.</li><li>• Keep liquids from getting to the shaft bushing.</li><li>• Do not clean the product with a pressure washer.</li></ul>
<b>Failure to follow these instructions can result in death, serious injury, or equipment damage.</b>

Motors are very heavy relative to their size. The great mass of the motor can cause injuries and damage.

<b>⚠ WARNING</b>
<b>HEAVY AND/OR FALLING PARTS</b>
<ul style="list-style-type: none"><li>• Use a suitable crane or other suitable lifting gear for mounting the motor if required by the weight of the motor.</li><li>• Use the necessary personal protective equipment (for example, protective shoes, protective glasses and protective gloves).</li><li>• Mount the motor so that it cannot come loose (use of securing screws with appropriate tightening torque), especially in cases of fast acceleration or continuous vibration.</li></ul>
<b>Failure to follow these instructions can result in death, serious injury, or equipment damage.</b>

<b>⚠ CAUTION</b>
<b>IMPROPER APPLICATION OF FORCES</b>
<ul style="list-style-type: none"><li>• Do not use the motor as a step to climb into or onto the machine.</li><li>• Do not use the motor as a load-bearing part.</li><li>• Use hazard labels and guards on your machine to help prevent the improper application of forces on the motor.</li></ul>
<b>Failure to follow these instructions can result in injury or equipment damage.</b>


## Clearances and Ventilation

When selecting the position of the device, take into account the following:

- No minimum clearances are required for installation. However, free convection must be possible.
- Avoid heat accumulations.
- Do not mount the device close to heat sources.
- Do not mount the device on flammable materials.
- The heated airflow from other devices and components must not heat up the air used for cooling the device.
- If the thermal limits are exceeded during operation, the power stage of the drive is disabled (overtemperature).

## Mounting Positions

The following mounting positions defined by IEC 60034-7 are permissible:



- IM B5: Motor shaft horizontal
- IM V1: Motor shaft vertical, shaft end to the bottom
- IM V3: Motor shaft vertical, shaft end to the top

## Mounting

When the integrated drive is mounted to the mounting surface, it must be accurately aligned axially and radially and make even contact with the mounting surface. No uneven mechanical forces must be applied when the mounting screws are tightened.

See chapter Technical Data ([see page 19](#)) for data, dimensions and degrees of protection (IP).

## Mounting Output Components

If the maximum permissible forces at the motor shaft are exceeded, this will result in premature wear of the bearing or shaft breakage.

### **⚠ WARNING**

#### **UNINTENDED EQUIPMENT OPERATION DUE TO MECHANICAL DAMAGE TO THE MOTOR**

- Do not exceed the maximum permissible axial and radial forces at the motor shaft.
- Protect the motor shaft from impact.
- Do not exceed the maximum permissible axial force when pressing components onto the motor shaft.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

Output components such as pulleys and couplings must be mounted with suitable equipment and tools. Motor and output component must be accurately aligned both axially and radially. If the motor and the output component are not accurately aligned, this causes runout and premature wear.

The maximum axial and radial forces acting on the shaft must not exceed the maximum shaft load values specified ([see page 27](#)).

---

## Section 4.2

### Electrical Installation

---

#### What Is in This Section?

This section contains the following topics:

Topic	Page
Overview of Procedure	61
Connection Overview	63
Connection Via Cable Entry	64
Connection Via Industrial Connectors	67
Connection of CN1 - V <sub>dc</sub> Supply Voltage	68
Connection of CN2 - Fieldbus	70
Connection of CN3 - RS485	72
Connection of CN4 - 24 V Signal Interface	74
Connection of CN5 - Safety-Related Function STO	76
Connection of Accessories for 24 V Signals and Safety-Related Function STO	78

## Overview of Procedure

### General Information

#### **DANGER**

##### **ELECTRIC SHOCK OR UNINTENDED EQUIPMENT OPERATION**

Keep foreign objects (such as chips, screws or wire clippings) from getting into the product.

**Failure to follow these instructions will result in death or serious injury.**

#### **DANGER**

##### **ELECTRIC SHOCK CAUSED BY INSUFFICIENT GROUNDING**

- Verify compliance with all local and national electrical code requirements as well as all other applicable regulations with respect to grounding of the entire drive system.
- Ground the drive system before applying voltage.
- Do not use conduits as functional ground conductors; use a functional ground conductor inside the conduit.
- The cross section of the functional ground conductor must comply with the applicable standards.
- Do not consider cable shields to be functional ground conductors.

**Failure to follow these instructions will result in death or serious injury.**

#### **DANGER**

##### **ELECTRIC SHOCK CAUSED BY INCORRECT POWER SUPPLY UNIT**

- Use power supply units that meet the PELV (Protective Extra Low Voltage) requirements.
- Connect the negative outputs of all power supply units to PE (protective earth/protective ground), for example, for the VDC supply voltage and for the 24 Vdc voltage for the safety-related function STO.
- Interconnect all negative outputs (reference potentials) of all power supply units used for the integrated drive.

**Failure to follow these instructions will result in death or serious injury.**

#### **WARNING**

##### **UNINTENDED EQUIPMENT OPERATION**

Do not connect any wiring to reserved, unused connections, or to connections designated as No Connection (N.C.).

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

The VDC connection of the product does not have an inrush current limitation. If the voltage is applied by means of switching of contacts, damage to the contacts or contact welding may result.

#### **NOTICE**

##### **PERMANENT DAMAGE TO CONTACTS**

- Switch the power input (primary side) of the power supply unit.
- Do not switch the output voltage (secondary side) of the power supply unit.

**Failure to follow these instructions can result in equipment damage.**


The installation procedure must be performed without voltage present.

### Overview of the Procedure for Electrical Installation

Depending on the space conditions in your machine and other factors, you can first perform the mechanical installation (*see page 56*) of the integrated drive and then the electrical installation. However, it is also possible to first perform the electrical installation, then commission the integrated drive and finally mount the integrated drive in the machine.

## Connection Overview

### Overview of Printed Circuit Board Connectors



Connection	Assignment
CN1	Connector for Vdc supply voltage
CN2	Connector for fieldbus Ethernet/IP
CN3	Connector for commissioning interface (RS-485)
CN4	Connector for 24 Vdc signals
CN5	Connector for the safety-related function STO
CN6	Jumper for activating and deactivating the safety-related function STO


The integrated drive can be connected via cable entries or industrial connectors.

Refer to the chapter Connection Via Cable Entry ([see page 64](#)) or to the chapter Connection Via Industrial Connectors ([see page 67](#)) for details.

## Connection Via Cable Entry

### Mounting Cables to Cable Entries

Mounting cables to the cable entry:



- 1 Unshielded cables
- 2 Shielded cables

Step	Action
1	Trim the cable bushings so that the diameter of the opening matches the diameter of the cable. The specified degree of protection IP54 can only be achieved with properly trimmed cable bushings.
2	(A) Strip the jacket of the cables by a length of 70 mm (2.76 in).
3	(B) Shorten the shield to a length of 10 mm (0.4 in).
4	(C) Slide the shielding braid back over the cable jacket.
5	(D) Loosen the strain relief.
6	Push the cables through the strain relief.
7	Glue EMC shielding film around the shield.
8	Pull the cable back to the strain relief.
9	Fasten the strain relief.

### Mounting Connectors


The following table lists the parts and data required for mounting connectors. Connector housings and crimp contacts are included in the accessories kits. Refer to the chapter Accessories and Spare Parts (see page 217).

Connection	Conductor cross section [mm <sup>2</sup> ]	Stripping length [mm]	Manufacturer's crimp contact no.	Crimping tool	Connector manufacturer	Connector type
CN1	0.75 ... 1.5 (AWG 18 ... 16) 2.5 ... 4.0 (AWG 12)	5 ... 6	160773-6 341001-6	654174-1	Tyco Electronics	Positive Lock 1-926522-1
CN2	0.2 ... 0.6 (AWG 24 ... 20)	2.5 ... 3.0	43030-0007	63819-0000	Molex	Micro-Fit 3.0 43025-1200
CN3	0.2 ... 1.0 (AWG 24 ... 18)	3.0 ... 3.5	39-00-0060	63819-0901	Molex	Mini-Fit Jr. 39-01-2065
CN4	0.2 ... 0.6 (AWG 24 ... 20)	2.5 ... 3.0	43030-0007	63819-0000	Molex	Micro-Fit 3.0 43025-0600
CN5	0.34 ... 0.6 (AWG 20)	2.5 ... 3.0	43030-0007	63819-0000	Molex	Micro-Fit 3.0 43645-0200

### Assembling the Cables


Procedure:

Step	Action
1	Strip the ends of the wires.
2	Attach cable lugs and crimp contacts. Verify that you use the correct crimp contacts and the matching crimping tool.
3	Slide the cable lugs and crimp contacts straight into the connector until they snap in place.




- 1 CN1 Supply voltage  $V_{dc}$
- 2 CN2 Fieldbus
- 3 CN3 Commissioning
- 4 CN4 24 V signal interface
- 5 Shield wire with EMC shield film

### Mounting the Cable Entry



Step	Action
1	Unscrew the cover of the connector housing.
2	Remove the shipping locks made of cardboard.

Step	Action
3	Set the parameter switches as they are difficult to access once the cables have been connected. For a description of the parameter switches, see chapter Fieldbus Integration ( <i>see page 86</i> ).
4	Connect the connectors of the assembled cables to the matching sockets. The connectors must snap in. Only pull the connector housing (not the cable).
5	<p>Plug the cable entry into one of the two cutouts provided. The side to be used for the cable entry depends on the space available in your system. The pointed corners of the cable entry must point in the direction of the cover of the connector housing. Degree of protection IP54 is not reached if the cable entry is mounted the other way around.</p> 
6	Close the cutout that is not used with a sealing insert for cutouts.
7	Finally, screw the cover of connector housing cover back into place with a tightening torque of 1.1 Nm (9.74 lbin). If screws are lost, use M3 x 12 as a replacement.

## Connection Via Industrial Connectors

### Overview

Interface	Connector used
Supply voltage $V_{DC}$	Hirschmann STASEI 200
Connector for fieldbus Ethernet/IP	Circular connector M12, 4 poles, D-coded
24 V signal inputs and outputs	Circular connector M8, 3-pin
Safety-related function STO	Circular connector M8, 4-pin

Refer to the chapter Accessories and Spare Parts ([see page 217](#)) for information on pre-assembled cables and connector kits.

## Connection of CN1 - Vdc Supply Voltage

### Description

The Vdc supply voltage is connected by means of printed circuit board connectors or industrial connectors. Use pre-assembled cables to reduce the risk of wiring errors. Verify that wiring, cables, and connected interfaces meet the PELV circuit requirements.

### Cable Specifications CN1 (Vdc Supply Voltage)


Characteristic	Unit	Value
Shield	-	Not required
Twisted pair	-	Not required
PELV	-	Required
Minimum conductor cross section	mm <sup>2</sup> (AWG)	0.75 (18)
Maximum connection cross section	mm <sup>2</sup> (AWG)	4.0 (12)

### Connector Specifications CN1 (Vdc Supply Voltage)

Two different crimp terminals are available for different conductor cross sections. It is possible to connect two wires via a single crimp terminal to daisy-chain multiple drives.


Characteristic	Value/Description
Connector housing	Tyco Electronics, Positive Lock 1-926522-1
Crimp terminal for conductor cross section 0.75 ... 1.5 (AWG 18 ... 16)	Tyco Electronics, Positive Lock 160773-6
Crimp terminal for conductor cross section 2.5 ... 4.0 (AWG 12)	Tyco Electronics, Positive Lock 341001-6
Stripping length	5 ... 6 mm (0.20 ... 0.24 in)
Crimping tool	Tyco Electronics, 654174-1

### Pin Assignments Printed Circuit Board Connector CN1 (Vdc Supply Voltage)



Designation	Description	Number <sup>(1)</sup>
VDC	Supply Voltage	1
0VDC	Reference potential VDC	2
<b>(1)</b> Number relates to pre-assembled cables		

### Pin Assignments Industrial Connector CN1 (Vdc Supply Voltage)



Pin	Signal	Description	Number <sup>(1)</sup>
1	VDC	Supply Voltage	1
2	0VDC	Reference potential $v_{dc}$	2
<b>(1)</b> Number relates to pre-assembled cables			

## Connection of CN2 - Fieldbus

### Description

The fieldbus interface allows you to network the drive as a slave in an Ethernet/IP network. The fieldbus is connected by means of printed circuit board connectors or industrial connectors. Use pre-assembled cables to reduce the risk of wiring errors. Verify that wiring, cables, and connected interfaces meet the PELV requirements.


### Cable Specifications CN2 (Fieldbus)

Characteristic	Unit	Value
Shield	-	Required
Shield grounded at both ends	-	Required
Twisted pair	-	Required
PELV	-	Required
Maximum cable length	m (ft)	100 (328)
Minimum conductor cross section	mm <sup>2</sup> (AWG)	0.25 (22)
Maximum connection cross section	mm <sup>2</sup> (AWG)	0.6 (20)

### Connector Specifications CN2 (Fieldbus)

Characteristic	Value/Description
Connector housing	Molex, Micro-Fit 3.0, 43025-1200
Crimp terminal	Molex, Micro-Fit 3.0, 43030-0007
Stripping length	2.5 ... 3.0 mm (0.10 ... 0.12 in)
Crimping tool	Molex, 63819-0000
Extraction tool	Molex, 11-03-0043

### Pin Assignments Printed Circuit Board Connector CN2 (Fieldbus)




Pin assignment port 0:

Pin	Signal	Description (drive end)
9	Tx+	Fieldbus Tx+
10	Tx-	Fieldbus Tx-
11	Rx+	Fieldbus Rx+
12	Rx-	Fieldbus Rx-

Pin assignment port 1:

Pin	Signal	Description (drive end)
3	Tx+	Fieldbus Tx+
4	Tx-	Fieldbus Tx-
5	Rx+	Fieldbus Rx+
6	Rx-	Fieldbus Rx-

**Pin Assignments Industrial Connector CN2 (Fieldbus)**



Pin assignment port 0:

Pin	Signal	Description (drive end)
1	Tx+	Fieldbus Tx+ (internally connected to pin CN2.9)
2	Tx-	Fieldbus Tx- (internally connected to pin CN2.10)
3	Rx+	Fieldbus Rx+ (internally connected to pin CN2.11)
4	Rx-	Fieldbus Rx- (internally connected to pin CN2.12)

Pin assignment port 1:

Pin	Signal	Meaning (from the perspective of the drive)
1	Tx+	Fieldbus Tx+ (internally connected to pin CN2.3)
2	Tx-	Fieldbus Tx- (internally connected to pin CN2.4)
3	Rx+	Fieldbus Rx+ (internally connected to pin CN2.5)
4	Rx-	Fieldbus Rx- (internally connected to pin CN2.6)

## Connection of CN3 - RS485

### Function

An RS485 interface is provided in addition to the fieldbus interface. The RS485 interface is also used to commission the drive.

You can also use the RS485 interface and the commissioning software to monitor the drive during operation. It is possible to establish simultaneous connections via the commissioning interface and the fieldbus.

Use pre-assembled cables to reduce the risk of wiring errors.

Verify that wiring, cables, and connected interfaces meet the PELV requirements.

### Cable Specifications CN3 (RS485)

Characteristic	Unit	Value
Shield	-	Required
Shield grounded at both ends	-	Required
Twisted pair	-	Required
PELV	-	Required
Maximum cable length	m (ft)	400 (1312)
Minimum conductor cross section	mm <sup>2</sup> (AWG)	0.25 (22)
Maximum connection cross section	mm <sup>2</sup> (AWG)	1.0 (18)

### Connector Specifications CN3 (RS485)

Characteristic	Value/Description
Connector housing	Molex, Mini-Fit Jr, 39-01-2065
Crimp terminal	Molex, Mini-Fit, 39-00-0060
Stripping length	3.0 ... 3.5 mm (0.12 ... 0.14 in)
Crimping tool	Molex, 63819-0901
Extraction tool	Molex, 11-03-0044

### Address and Baud Rate Setting


Each device on the network is identified by a unique, adjustable node address.

Factory setting:

- Address: 1
- Baud rate: 19200
- Data format: 8 bits  
Even Parity  
1 stop bit

The address and the baud rate of the RS485 interface can be set via the commissioning software.

## Pin Assignments CN3 (RS485)



Pin	Signal	Description	SUB-D <sup>(1)</sup>
2	+RS485	RS485 interface	7
5	-RS485	RS485 interface	2
4	RS485_0V	Internally connected to CN1 .0VDC	3

**(1)** Information relates to pre-assembled cables

## Connection of CN4 - 24 V Signal Interface

### Description

The drive has four configurable inputs and outputs.

An internal 24 V power supply for the sensor system is integrated. Do not connect the internal 24 V power supply to another power supply.

Use pre-assembled cables to reduce the risk of wiring errors.

Verify that wiring, cables, and connected interfaces meet the PELV requirements.

### Factory Settings

Factory settings of the digital inputs and digital outputs:

Signal	Signal input function
LIO1	Input Positive Limit Switch (LIMP)
LIO2	Input Negative Limit Switch (LIMN)
LIO3	Input Free Available
LIO4	Input Reference Switch (REF)

The assignments can be parameterized. Refer to the chapter Parameterization of the Signal Input Functions and the Signal Output Functions (*see page 110*) for details.


### Cable Specifications CN4 (24 V Signal Interface)

Characteristic	Unit	Value
Shield	-	Not required
Twisted pair	-	Not required
PELV	-	Required
Minimum conductor cross section	mm <sup>2</sup> (AWG)	0.2 (24)
Maximum connection cross section	mm <sup>2</sup> (AWG)	0.6 (20)

### Connector Specifications CN4 (24 V Signal Interface)

Characteristic	Value/Description
Connector housing	Molex, Micro-Fit 3.0, 43025-0600
Crimp terminal	Molex, Micro-Fit 3.0, 43030-0007
Stripping length	2.5 ... 3.0 mm (0.10 ... 0.12 in)
Crimping tool	Molex, 63819-0000
Extraction tool	Molex, 11-03-0043

### Pin Assignments CN4 (24 V Signal Interface)



Pin	Signal	Description
1	+24VDC_OUT	The 24 V power supply can be used to supply the sensor system (for example the limit switches)
2	LIO3	Input or output for use as required
3	LIO1	Input or output for use as required
4	0VDC	Internally connected to CN1 . 0VDC
5	LIO4	Input or output for use as required
6	LIO2	Input or output for use as required

## Connection of CN5 - Safety-Related Function STO

### Requirements

Incorrect usage may cause a hazard due to the loss of the safety-related function.

### WARNING

#### LOSS OF SAFETY-RELATED FUNCTION

Observe the requirements for using the safety-related function.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

Refer to chapter Functional Safety (*see page 37*) for information and requirements relating to the safety-related function STO.

The wiring of the safety-related function STO must meet all applicable requirements as per ISO 13849-1 and ISO 13849-2.

Verify that wiring, cables, and connected interfaces meet the PELV requirements.

Use pre-assembled cables to reduce the risk of wiring errors.

### Cable Specifications CN5 (STO)


Characteristic	Unit	Value
Shield	-	Required
Shield connected at one end	-	Required
Protected cable installation ( <i>see page 41</i> ) as per ISO 13849-2	-	Required
Minimum conductor cross section	mm <sup>2</sup> (AWG)	0.34 (20)
Maximum connection cross section	mm <sup>2</sup> (AWG)	0.6 (20)

The cable available as an accessory is a special cable that is only available with a connector. The shield of the cable is connected to the grounded housing of the drive via the metal connector. It is sufficient to connect one end of the cable to the grounded housing.

### Connector Specifications CN5 (STO)


Characteristic	Value/Description
Connector housing	Molex, Micro-Fit 3.0, 43645-0200
Crimp terminal	Molex, Micro-Fit 3.0, 43030-0007
Stripping length	2.5 ... 3.0 mm (0.10 ... 0.12 in)
Crimping tool	Molex, 63819-0000
Extraction tool	Molex, 11-03-0043

Pin Assignments CN5 (STO)



Pin	Signal	Description
CN5.1	STO_A	Safety-related function STO
CN5.2	STO_B	Safety-related function STO
CN6	-	Jumper connected: STO disabled (default) Jumper removed: STO enabled


Remove jumper CN6 before connecting in the connector for CN5 (mechanical lock).



## Connection of Accessories for 24 V Signals and Safety-Related Function STO

### Accessory "Insert kit, 3 x I/O"

The accessory makes the signals LIO1, LIO2 and LIO4 available outside of the drive via industrial connectors.




Pin 1 is internally connected to CN4.1 (+24VDC\_OUT).

Pin 3 is internally connected to CN4.4 (0VDC).

### Accessory "Insert kit, 2 x I/O, 1x STO in"

The accessory makes the signals LIO1, LIO2 and the signals of the safety-related function STO available outside of the drive via industrial connectors.




Pin 1 is internally connected to CN4.1 (+24VDC\_OUT).

Pin 3 is internally connected to CN4.4 (0VDC).


### Accessory "Insert kit, 1 x STO in, 1 x STO out"

The accessory makes the signals of the safety-related function STO available outside of the drive via industrial connectors.



### Accessory "Insert kit, 4 x I/O, 1x STO in, 1 x STO out"

The accessory makes the signals LIO1, LIO2, LIO3, LIO4 and the signals of the safety-related function STO available outside of the drive via industrial connectors.



Pin 1 is internally connected to CN4.1 (+24VDC\_OUT).

Pin 3 is internally connected to CN4.4 (0VDC).

## Section 4.3

### Verifying Installation

---

#### Verifying Installation

##### Overview

After you have completed the mechanical and electrical installation, verify correct installation of the overall drive system. The following table is not exhaustive. The points you need to consider in addition depend on, among other things, your application, your process definitions, and the standards and regulatory requirements applicable in the country of manufacture and at the installation site.

##### Verification of Correct Installation

Mechanical installation:

- Correct tightening torque of screw connections
- Correct mounting of output components
- Correct installation of the covers and seals to achieve the required degree of protection.

Electrical installation:

- Protective ground of power supply unit
- Functional ground of integrated drive
- Correct type and fuse rating of fuses
- Correct assembly of cables and connectors
- Correct routing and fastening of cables
- Correct installation and connection of cables
- Correct insulation of unused wires
- Effectiveness of mechanical locks of connectors
- Compliance of the overall installation with all local, regional, and national electrical safety codes and requirements at the eventual installation site of the equipment

Electromagnetic compatibility:

- Correct connection of shields
- Correct equipotential bonding
- Compliance of the overall installation with all local, regional, and national regulations and requirements concerning EMC at the eventual installation site of the equipment

Overall installation:

- Compliance with all specifications in the present document
- All items identified in risk assessment covered

---

# Chapter 5

## Commissioning

---

### What Is in This Chapter?

This chapter contains the following sections:

Section	Topic	Page
5.1	Overview	82
5.2	Fieldbus Integration	86
5.3	Commissioning Procedure	92
5.4	Parameter Management	101

# Section 5.1

## Overview

---

### What Is in This Section?

This section contains the following topics:

Topic	Page
General	83
Preparation	85

## General

### Overview

The safety-related function STO (Safe Torque Off) does not remove power from the DC bus. The safety-related function STO only removes power to the motor. The DC bus voltage and the mains voltage to the drive are still present.

### DANGER

#### ELECTRIC SHOCK

- Do not use the safety-related function STO for any other purposes than its intended function.
- Use an appropriate switch, that is not part of the circuit of the safety-related function STO, to disconnect the drive from the mains power.

**Failure to follow these instructions will result in death or serious injury.**

### WARNING

#### INEFFECTIVE SAFETY-RELATED FUNCTION AND/OR UNINTENDED EQUIPMENT OPERATION

- Commission the integrated drive before it is used for the first time and after each modification to parameter values, settings, and wiring.
- Commission or recommission the machine/process pursuant to all regulations, standards, and process definitions applicable to your machine/process.
- Verify that the commissioning procedure covers all items identified in your risk assessment.
- Verify correct operation and effectiveness of all functions by performing comprehensive tests for all operating states, the defined safe state, and all potential error situations.
- Document all modifications and the results of the commissioning procedure in compliance with all regulations, standards, and process definitions applicable to your machine/process.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

Unsuitable parameter values or unsuitable data may trigger unintended movements, trigger signals, damage parts and disable monitoring functions. Some parameter values or data do not become active until after a restart.

### WARNING

#### UNINTENDED EQUIPMENT OPERATION

- Only start the system if there are no persons or obstructions in the zone of operation.
- Do not operate the drive system with undetermined parameter values or data.
- Never modify a parameter value unless you fully understand the parameter and all effects of the modification.
- Restart the drive and verify the saved operational data and/or parameter values after modifications.
- Carefully run tests for all operating states and potential error situations when commissioning, upgrading or otherwise modifying the operation of the drive.
- Verify the functions after replacing the product and also after making modifications to the parameter values and/or other operational data.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

If the power stage is disabled unintentionally, for example as a result of power outage, errors or functions, the motor is no longer decelerated in a controlled way.

### WARNING

#### UNINTENDED EQUIPMENT OPERATION

Verify that movements without braking effect cannot cause injuries or equipment damage.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

When the product is operated for the first time, there is a risk of unanticipated movements caused by, for example, incorrect wiring or unsuitable parameter settings. Releasing the holding brake can cause an unintended movement, for example, a falling load in the case of vertical axes.

<b>⚠ WARNING</b>
<b>UNINTENDED MOVEMENT</b> <ul style="list-style-type: none"><li>• Verify that there are no persons or obstructions in the zone of operation when operating the system.</li><li>• Take appropriate measures to avoid hazards caused by falling or lowering loads or other unintended movements.</li><li>• Run initial tests without coupled loads.</li><li>• Verify that a functioning emergency stop push-button is within reach of all persons involved in running tests.</li><li>• Anticipate movements in unintended directions or oscillations of the motor.</li></ul> <b>Failure to follow these instructions can result in death, serious injury, or equipment damage.</b>

The product can be accessed via different types of access channels. Simultaneous access via multiple access channels or the use of exclusive access may cause unintended equipment operation.

<b>⚠ WARNING</b>
<b>UNINTENDED EQUIPMENT OPERATION</b> <ul style="list-style-type: none"><li>• Verify that simultaneous access via multiple access channels cannot cause unintended triggering or blocking of commands.</li><li>• Verify that the use of exclusive access cannot cause unintended triggering or blocking of commands.</li><li>• Verify that the required access channels are available.</li></ul> <b>Failure to follow these instructions can result in death, serious injury, or equipment damage.</b>

Rotating parts may cause injuries and may catch clothing or hair. Loose parts or parts that are out of balance may be ejected.

<b>⚠ WARNING</b>
<b>MOVING, UNGUARDED EQUIPMENT</b> <p>Verify that rotating parts cannot cause injuries or equipment damage.</p> <b>Failure to follow these instructions can result in death, serious injury, or equipment damage.</b>

<b>⚠ WARNING</b>
<b>FALLING PARTS</b> <p>Verify correct mounting of the drive with the specified tightening torque before taking up commissioning.</p> <b>Failure to follow these instructions can result in death, serious injury, or equipment damage.</b>

The metal surfaces of the product may exceed 70 °C (158 °F) during operation.

<b>⚠ CAUTION</b>
<b>HOT SURFACES</b> <ul style="list-style-type: none"><li>• Avoid unprotected contact with hot surfaces.</li><li>• Do not allow flammable or heat-sensitive parts in the immediate vicinity of hot surfaces.</li><li>• Verify that the heat dissipation is sufficient by performing a test run under maximum load conditions.</li></ul> <b>Failure to follow these instructions can result in injury or equipment damage.</b>

## Preparation


### Required Components

The following is required for commissioning:

- Commissioning software “Lexium CT”  
<https://www.se.com/ww/en/download/document/LexiumCTInstall/>
- Fieldbus converter for the commissioning software for connection via the commissioning interface
- Electronic Data Sheet file EDS  
[https://www.se.com/ww/en/download/document/Lexium\\_ILx2K\\_EthernetIP\\_EDS/](https://www.se.com/ww/en/download/document/Lexium_ILx2K_EthernetIP_EDS/)

### Interfaces

The following interfaces can be used for commissioning, parameterization and diagnostics:



- 1 PC with commissioning software “Lexium CT”
- 2 Fieldbus

Device settings can be duplicated. Stored device settings can be transferred to a device of the same type. Duplicating the device settings can be used if multiple devices are to have the same settings, for example, when devices are replaced.


### Commissioning Software

The commissioning software “Lexium CT” has a graphic user interface and is used for commissioning, diagnostics and testing settings.

- Comprehensive set of diagnostics tools for optimization and maintenance
- Long-term trace for evaluation of the performance
- Testing the input and output signals
- Tracking signals on the screen
- Archiving of device settings and recordings with export function for further processing in other applications

### Connecting a PC

A PC with commissioning software can be connected for commissioning. The PC is connected to a bidirectional USB/RS485 converter, see chapter Accessories and Spare Parts ([see page 217](#)).



## Section 5.2

### Fieldbus Integration

---

#### What Is in This Section?

This section contains the following topics:

Topic	Page
Setting the IP Address	87
Web Server	90

## Setting the IP Address

### Overview

Carefully manage the IP addresses because each device on the network requires a unique address. Having multiple devices with the same IP address can cause unintended operation of your network and associated equipment. Although some equipment, such as the present device, may detect duplicate IP addresses, other equipment may not.

### **⚠ WARNING**


#### UNINTENDED EQUIPMENT OPERATION

- Verify that all devices have unique addresses.
- Obtain your IP address from your system administrator.
- Confirm that the IP address of the drive is unique before placing the system into service.
- Do not assign the same IP address to any other equipment on the network.
- Update the IP address after resetting the drive to factory settings.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

**NOTE:** Verify that your system administrator maintains a record of all assigned IP addresses on the network and subnetwork, and inform the system administrator of all configuration changes performed.

The IP address of the drive can be set in the following ways:



- 1 IP address assignment via a DHCP/BOOTP server based on the MAC address with fall-back to the IP address stored in the nonvolatile memory (factory setting) ([see page 87](#))
- 2 Using the IP address stored in the nonvolatile memory ([see page 87](#))
- 3 IP address assignment via a DHCP/BOOTP server based on the MAC address ([see page 88](#))
- 4 IP address assignment via a DHCP server based on a "DeviceName" ([see page 88](#))
- 5 Deriving the IP address from the MAC address ([see page 89](#))

### IP Address Assignment via a DHCP/BOOTP Server Based on the MAC Address with Fall-Back to the IP Address Stored in the Nonvolatile Memory (Factory Setting)

The IP address is obtained from a DHCP server or a BOOTP server based on the MAC address of the drive.

The MAC address is shown in the drive housing next to the connectors.

Procedure:

Step	Action
1	Power off the drive.
2	Set the rotary switch S1 to the position C (factory setting). The setting of the rotary switch S2 is not relevant in this case.
3	Power on the drive.

The DHCP/BOOTP server must manage a list that associates each MAC address with an IP address so each device has unique IP address.

If an IP address cannot be obtained within a period of 120 seconds, the IP address stored in the nonvolatile memory ([see page 87](#)) is used.

The default IP address of the drive is **192.168.100.10**.

### Using the IP Address Stored in the Nonvolatile Memory

The IP address stored in the nonvolatile memory is used.

The IP address can be adjusted via the commissioning software or via the web server.

The default IP address of the drive is **192.168.100.10**.

The last byte of the IP address can be adjusted via the rotary switches.

Procedure for adjusting the last byte of the IP address via the rotary switches:

Step	Action
1	Power off the drive.
2	Set the rotary switch S1 to the position E (Clear IP). The setting of the rotary switch S2 is not relevant in this case.
3	Power on the drive.
4	Wait until the status LED indicates "No valid IP parameters after a Clear IP" (two flashes).
5	The IP address is set in the following way <b>xxx.xxx.xxx.yyy</b> . <b>xxx.xxx.xxx</b> is used from the IP address stored in the nonvolatile memory. <b>yyy</b> is the result of ten times the value of S2 plus the value of S1 ( <b>yyy = 10 * S2 + S1</b> ). Set the rotary switch S2 to a position from 0 to F. Set the rotary switch S1 to a position from 0 to 9. Valid values are from <b>1</b> to <b>159</b> .
6	After having set the desired IP address, wait until the status LED indicates "Ready without error" (Steady ON). If, after that, you modify the settings of the rotary switches to select a different IP address, the status LED indicates "No valid IP parameters after a Clear IP" (two flashes) again.
7	Power off the product when the status LED indicates "Ready without error" (Steady ON).
8	Set the rotary switch S1 to the position D (Stored). The setting of the rotary switch S2 is not relevant in this case.
9	Power on the drive.

**IP Address Assignment via a DHCP/BOOTP Server Based on the MAC Address**

The IP address is obtained from a DHCP server or a BOOTP server based on the MAC address of the drive.

The MAC address is shown in the drive housing next to the connectors.

Procedure:

Step	Action
1	Power off the drive.
2	Set the rotary switch S1 to the position A or B. The setting of the rotary switch S2 is not relevant in this case.
3	Power on the drive.

The DHCP/BOOTP server must manage a list that associates each MAC address with an IP address so each device has unique IP address.

**IP Address Assignment via a DHCP Server Based on a "DeviceName"**

The IP address is obtained from a DHCP server based on the "DeviceName" of the drive.

The DHCP server must support the "DeviceName" configuration.

The "DeviceName" of the drive can only be adjusted via the rotary switches.

Procedure:

Step	Action
1	Power off the drive.
2	The Device Name is the string "Lexium-ILx-" and a three-digit number. This number results from the setting of the two rotary switches: Ten times the value of S2 plus the value of S1. Device Name = "Lexium-ILx-" + (10 * S2 + S1) Set the rotary switch S2 to a position from 0 to F. Set the rotary switch S1 to a position from 0 to 9. Valid values are from <b>1</b> to <b>159</b> . For values from 1 to 9 two leading zeros "00" will be added. For values from 10 to 99 one leading zero "0" will be added.
3	Power on the drive.

### Deriving the IP Address from the MAC Address

The IP address is set in the following way **xxx.xxx.xxx.yyy**.

**xxx.xxx.xxx** is used from the IP address stored in the nonvolatile memory.

**yyy** is set depending on the last byte of the MAC address.

The MAC address is shown in the drive housing next to the connectors.

Procedure:

Step	Action
1	Power off the drive.
2	Set the rotary switch S1 to the position F. The setting of the rotary switch S2 is not relevant in this case.
3	Power on the drive.
4	Example 1: MAC address xx:xx:xx:xx:xx:06, the resulting IP address is xxx.xxx.xxx.6. Example 2: MAC address xx:xx:xx:xx:xx:A7, the resulting IP address is xxx.xxx.xxx.167. Exception 1: MAC address xx:xx:xx:xx:xx:00, the resulting IP address is xxx.xxx.xxx.1 Exception 2: MAC address xx:xx:xx:xx:xx:FF, the resulting IP address is xxx.xxx.xxx.254 The subnet mask is set to the default value 255.255.255.0. The gateway is set to the default value 192.168.100.254.

**NOTE:** With this setting, the same IP address may be assigned to different devices. For important safety information, see the Overview ([see page 87](#)) of this section.

## Web Server

### Overview

The drive features an integrated web server. The web server allows for configuration of the drive without the commissioning software.

<b>⚠ WARNING</b>
<b>UNINTENDED EQUIPMENT OPERATION</b>
<ul style="list-style-type: none"><li>● Define a secure password for the Web server, and do not allow unauthorized or otherwise unqualified personnel to use this feature.</li><li>● Ensure that there is a local, competent, and qualified observer present when operating on the controller from a remote location.</li><li>● You must have a complete understanding of the application and the machine/process it is controlling before attempting to adjust data, stopping an application that is operating, or starting the controller remotely.</li><li>● Take the precautions necessary to assure that you are operating on the intended controller by having clear, identifying documentation within the controller application and its remote connection.</li></ul>
<b>Failure to follow these instructions can result in death, serious injury, or equipment damage.</b>

**NOTE:** The web server must only be used by authorized and qualified personnel. A qualified person is one who has the skills and knowledge related to the construction and operation of the machine and the process controlled by the application and its installation, and has received safety training to recognize and avoid the hazards involved. No responsibility is assumed by Schneider Electric for any consequences arising out of the use of this feature.

### Connecting

The drive must have a valid IP address.

To connect, enter the IP address of the drive in the address bar of the browser.

When connecting to the web server for the first time, you need to specify a new password for the web server. To do so, enter the default password and your new password.

- Default password of the web server: **USER**

After you have set your new password, the web server displays the main page.

<b>⚠ WARNING</b>
<b>UNAUTHORIZED DATA ACCESS</b>
<ul style="list-style-type: none"><li>● Do not expose the device or device network to public networks and the Internet as much as possible.</li><li>● Immediately change the default password to a new secure password.</li><li>● Do not distribute passwords to unauthorized or otherwise unqualified personnel.</li><li>● Restrict access to unauthorized personnel.</li><li>● Use additional security layers like VPN for remote access and install firewall mechanisms.</li><li>● Validate the effectiveness of these measurements regularly and frequently.</li></ul>
<b>Failure to follow these instructions can result in death, serious injury, or equipment damage.</b>

**NOTE:** Choose a password that complies with all password requirements of your company and that follows best practices with regard to password strength.

This includes, but is not limited to:

- The password does not contain any personal or otherwise obvious information.
- The password consists of a mix of uppercase and lowercase letters, numbers, and special characters.
- The password length is at least ten characters.
- Follow all rules for keeping the password confidential.
- Do not disclose the password to any unauthorized persons.

### Parameter Values

Before you can read and write parameters, you have to sign in.

Use the following user name and your new password:

- User name: **USER**

Parameter values are entered in a way similar to the commissioning software.

- Click the **Write** button to send the settings to the drive.
- After that, click the **Save** button to save the settings to the nonvolatile memory of the drive.

### Web Server Functions

Menu	Function
Home	Start page.
Maintenance	Edit motor and communication parameters.
Diagnostics	View drive status and communication statistics.
Setup	Modify the password of the web server. The password of the web server can only be reset to the default value via the parameter <code>ResetWebPass</code> .
Documentation	Link to the <a href="#">Schneider Electric</a> website.

### Resetting the Password Via Parameter

The password of the web server can be reset via the parameter `ResetWebPass`.

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
<code>ResetWebPass</code>	Reset password of web server. Value 1: The password of the web server is reset to the default value. A new password must be set when a new connection is established. The parameter can only be written via Modbus RTU. Modified settings become active immediately. Available with firmware version $\geq V1.102$ .	- 0 - 1	UINT16 R/W - -	Modbus 6704 CIP 126.1.24

---

## Section 5.3

### Commissioning Procedure

---

#### What Is in This Section?

This section contains the following topics:

Topic	Page
Setting Limit Values	93
Digital Inputs and Digital Outputs	95
Verifying the Signals of the Limit Switches	96
Verifying the Safety-Related Function STO	97
Holding Brake (Option)	98
Direction of Movement	100

## Setting Limit Values

### Current Limitation

The factory setting for the current at standstill amounts to 70 % of the maximum motor current to allow for energy-efficient operation. In most applications, this current generates sufficient torque to hold the load when the motor is at a standstill. However, your application may require a higher motor current at standstill which you have to determine by performing test runs.

### WARNING

#### UNINTENDED EQUIPMENT OPERATION

Verify that the current set for motor standstill generates sufficient torque to reliably hold the load at standstill by performing test runs under maximum load conditions.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

The nominal motor current, the current for standstill, the current for constant movement, and the current for acceleration and deceleration can be parameterized.

- Use the parameter `SM_I_Nom` to set the maximum nominal motor current.
- Use the parameter `CTRLS_I_Stand%` to set the maximum motor current for standstill.
- Use the parameter `CTRLS_I_Ramp%` to set the maximum motor current for acceleration and deceleration.
- Use the parameter `CTRLS_I_Const%` to set the maximum motor current for constant movement.

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
<code>CTRLS_I_Stand%</code>	Percentage of phase current at standstill. 100 % correspond to the value in <code>SM_I_nom</code> . Modified settings become active immediately.	% 1 70 100	UINT16 R/W per. -	Modbus 5140 CIP 120.1.10
<code>CTRLS_I_Ramp%</code>	Percentage of phase current during acceleration/deceleration. 100 % correspond to the value in <code>SM_I_nom</code> . Modified settings become active immediately.	% 1 100 100	UINT16 R/W per. -	Modbus 5142 CIP 120.1.11
<code>CTRLS_I_Const%</code>	Percentage of phase current during constant movement. 100 % correspond to the value in <code>SM_I_nom</code> . Modified settings become active immediately.	% 1 100 100	UINT16 R/W per. -	Modbus 5144 CIP 120.1.12

### Limitation of the Reference Speed of Rotation

The reference speed of rotation can be limited.

- Use the parameter `RAMPn_max` to set the limitation of the reference speed of rotation.

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
RAMPn_max	<p>Maximum velocity of the motion profile for velocity. The parameter is active in the following operating modes:</p> <ul style="list-style-type: none"> <li>- Profile Position</li> <li>- Profile Velocity</li> <li>- Homing</li> <li>- Jog</li> </ul> <p>If a greater reference velocity is set in one of these operating modes, it is automatically limited to RAMPn_max. This way, commissioning at limited velocity is easier to perform. Setting can only be modified if power stage is disabled. Modified settings become active the next time the motor moves.</p>	RPM 60 13200 13200	UINT16 R/W per. -	Modbus 1554 CIP 106.1.9

The parameter is part of the motion profile for the velocity. Refer to chapter Motion Profile for the Velocity (*see page 155*) for further details.

### Setting the Deceleration Ramp for Quick Stop

The deceleration ramp for Quick Stop can be parameterized.

- Use the parameter RAMPquickstop to set the deceleration ramp for Quick Stop.

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
RAMPquickstop	<p>Deceleration ramp for Quick Stop. Deceleration ramp for a software stop or an error with error class 1 or 2. Modified settings become active the next time the motor moves.</p>	RPM/s 200 6000 3000000	UINT32 R/W per. -	Modbus 1572 CIP 106.1.18

Refer to chapter Stopping Movement with Quick Stop (*see page 159*) for further details

### Setting the Deceleration Ramp for Halt

The deceleration ramp for Halt can be parameterized.

- Use the parameter RAMPdecel to set the deceleration ramp for Halt.

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
RAMPdecel	<p>Deceleration of the motion profile for velocity. Modified settings become active the next time the motor moves.</p>	RPM/s 200 750 3000000	UINT32 R/W per. -	Modbus 1558 CIP 106.1.11

The parameter is part of the motion profile for the velocity. Refer to the chapter Stopping Movement with Halt (*see page 158*) and the chapter Motion Profile for the Velocity (*see page 155*) for further details.

## Digital Inputs and Digital Outputs

### Overview

The drive provides configurable digital inputs and digital outputs.

Signal input functions and signal output functions can be assigned to the digital inputs and digital outputs.

### WARNING

#### UNINTENDED EQUIPMENT OPERATION

- Verify that the wiring is appropriate for the factory settings and any subsequent parameterizations.
- Only start the system if there are no persons or obstructions in the zone of operation.
- Carefully run tests for all operating states and potential error situations when commissioning, upgrading or otherwise modifying the operation of the drive.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

The signal states of the digital inputs and digital outputs can be indicated via the fieldbus and the commissioning software.

### Factory Settings

Factory settings of the digital signal inputs/outputs:

Signal	Signal input function
LIO1	Input Positive Limit Switch (LIMP)
LIO2	Input Negative Limit Switch (LIMN)
LIO3	Input Free Available
LIO4	Input Reference Switch (REF)

Refer to the chapter Parameterization of the Signal Input Functions and the Signal Output Functions (*see page 110*) for information on assigning the digital input functions and the digital output functions you have wired during installation of the drive.

### Reading Signal States via the Fieldbus

The signal states are contained in the parameter `_IO_act` in a bit-coded way. The values “1” and “0” correspond to the signal state of the input or output.

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
<code>_IO_LIO_act</code>	Status of digital inputs/outputs. Coding of the individual signals: Bit 0: LIO1 Bit 1: LIO2 ...	- - - -	UINT16 R/- - -	Modbus 2090 CIP 108.1.21

## Verifying the Signals of the Limit Switches

### Description

The use of limit switches can help protect against some hazards (for example, collision with mechanical stop caused by incorrect reference values).

### WARNING

#### LOSS OF CONTROL

- Ensure that limit switches are installed as determined by your risk assessment.
- Verify correct connection of the limit switches.
- Verify that the limit switches are sufficiently distant from the mechanical end to allow an adequate stopping distance.
- Verify correct parameterization and function of the limit switches.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

- Set up the limit switches in such a way as to keep the motor from overtraveling the limit switches.
- Trigger the limit switches manually.  
If an error message is indicated, the limit switches were triggered.

Parameters can be used to release the limit switches and to set them up as normally closed contacts or normally open contacts. Refer to the chapter Limit Switches ([see page 164](#)) for details.

## Verifying the Safety-Related Function STO

### Operation with Safety-Related Function STO

If you want to use the safety-related function STO, carry out the following steps:

Step	Action
1	To help avoid unanticipated restart after restoration of power, the parameter <code>IO_AutoEnable</code> must be set to "off". Verify that the parameter <code>IO_AutoEnable</code> is set to "off".
2	Power off the power supply:
3	Verify that the signal wires connected to the inputs ( <code>STO_A</code> ) and ( <code>STO_B</code> ) are electrically isolated from each other.
4	Apply power to the drive.
5	Enable the power stage without starting a motor movement.
6	Trigger the safety-related function STO. If the power stage is disabled and the error message 1300 is indicated, the safety-related function STO was triggered. If a different error message is indicated, the safety-related function STO was not triggered.
7	Document the tests of and settings for the safety-related function STO in compliance with all applicable standards, regulations, and process definitions.

### Operation with Safety-Related Function STO

Operation without the safety-related function STO:

Step	Action
1	Verify that the jumper CN6 is connected.

## Holding Brake (Option)

### Holding Brake

The holding brake in the motor has the task of holding the motor position when the power stage is disabled. The holding brake is not a safety-related function. The holding brake is not a service brake.

<b>⚠ WARNING</b>
<b>UNINTENDED AXIS MOVEMENT</b>
<ul style="list-style-type: none"><li>• Do not use the internal holding brake as a safety-related measure.</li><li>• Only use certified external brakes as safety-related measures.</li></ul>
<b>Failure to follow these instructions can result in death, serious injury, or equipment damage.</b>

### Releasing the Holding Brake

When the power stage is enabled, current is applied to the motor. When current is applied to the motor, the holding brake is automatically released.

Releasing the holding brake requires a certain amount of time. This time value is contained in the electronic nameplate of the motor. Transition to the operating state **6 Operation Enabled** is only possible after this time has elapsed.

### Applying the Holding Brake

When the power stage is disabled, the holding brake is automatically applied.

However, applying the holding brake requires a certain amount of time. This time value is contained in the electronic nameplate of the motor. Current remains to be applied to the motor during this time.

Refer to the chapter Functional Safety (*see page 37*) for additional information on the behavior of the holding brake when the safety-related function STO is triggered.

### Releasing the Holding Brake Manually

Mechanical adjustments may require you to manually rotate the motor shaft.

Manual release of the holding brake is only possible in the operating states **3 Switch On Disabled**, **4 Ready To Switch On** or **9 Fault**.

When the product is operated for the first time, there is a risk of unanticipated movements caused by, for example, incorrect wiring or unsuitable parameter settings. Releasing the holding brake can cause an unintended movement, for example, a falling load in the case of vertical axes.

<b>⚠ WARNING</b>
<b>UNINTENDED MOVEMENT</b>
<ul style="list-style-type: none"><li>• Verify that there are no persons or obstructions in the zone of operation when operating the system.</li><li>• Take appropriate measures to avoid hazards caused by falling or lowering loads or other unintended movements.</li><li>• Run initial tests without coupled loads.</li><li>• Verify that a functioning emergency stop push-button is within reach of all persons involved in running tests.</li><li>• Anticipate movements in unintended directions or oscillations of the motor.</li></ul>
<b>Failure to follow these instructions can result in death, serious injury, or equipment damage.</b>

The parameter `BRK_release` can be used to release the holding brake via the fieldbus.

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
BRK_release	<p>Manual operation of the holding brake.  <b>0 / Close:</b> Automatic processing  <b>1 / Open:</b> Manual release of holding brake  The holding brake can only be manually released in the operating states Switch On Disabled or Ready To Switch On.</p> <p>If the power stage is enabled, the value is automatically set to 0.  Modified settings become active immediately.</p>	- 0 0 1	UINT16 R/W - -	Modbus 2068 CIP 108.1.10

## Direction of Movement

### Definition of Direction of Movement

In the case of a rotary motor, direction of movement is defined as follows: Positive direction is when the motor shaft rotates clockwise as you look at the end of the protruding motor shaft.

### Verifying the Direction of Movement Via the Commissioning Software

The direction of movement can be verified by starting a movement in the commissioning software.

Procedure:

Step	Action
1	Apply power to the drive.
2	Enable the power stage.
3	Start the operating mode Jog.
4	Use the ">" button to trigger a movement in positive direction. Observe the movement.
5	Use the "<" button to trigger a movement in negative direction. Observe the movement.

### Inverting the Direction of Movement

If your application requires an inversion of the direction of movement, you can parameterize the direction of movement.

- If inversion of direction of movement is not activated (parameter value "Clockwise"): Positive target values result in movements in positive direction.
- If inversion of direction of movement is activated (parameter value "Counter Clockwise"): Positive target values result in movements in negative direction.

The parameter `POSdirOfRotat` allows you to invert the direction of movement.

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
<code>POSdirOfRotat</code>	<p>Definition of direction of rotation.  <b>0 / Clockwise:</b> Clockwise  <b>1 / Counter Clockwise:</b> Counter-clockwise                      With positive reference values, the motor rotates clockwise (as you look at the end of the motor shaft at the flange).</p> <p>The limit switch which is reached with a movement in positive direction must be connected to the positive limit switch input and vice versa.                      Setting can only be modified if power stage is disabled.                      Modified settings become active the next time the product is powered on.</p>	- 0 0 1	UINT16 R/W per. -	Modbus 1560 CIP 106.1.12

---

## Section 5.4

### Parameter Management

---

#### What Is in This Section?

This section contains the following topics:

Topic	Page
Resetting the User Parameters	102
Restoring Factory Settings	103

## Resetting the User Parameters

### Description

The user parameters are reset by means of the parameter `PARuserReset`.

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
<code>PARuserReset</code>	<p>Reset user parameters. Bit 0: Reset persistent user parameters to default values. The parameters are reset with the exception of:</p> <ul style="list-style-type: none"> <li>- Communication parameters</li> <li>- Definition of the direction of rotation</li> <li>- Signal selection position interface</li> <li>- I/O functions</li> </ul> <p>Bits 1 and 2: Reserved</p> <p>The new settings are not saved to the nonvolatile memory. Setting can only be modified if power stage is disabled. Modified settings become active the next time the power stage is enabled.</p>	- 0 - 7	UINT16 R/W - -	Modbus 1040 CIP 104.1.8

## Restoring Factory Settings

### Description

The parameter values, both active and those saved in nonvolatile memory, are lost in this process.

### ***NOTICE***

#### **LOSS OF DATA**

Perform a backup of the drive parameters prior to restoring factory settings (factory established parameter values).

**Failure to follow these instructions can result in equipment damage.**

The commissioning software allows you to save the parameter values set for a drive as a configuration file. The factory settings can be restored via the commissioning software.

Disconnect the drive from the fieldbus before you restore the factory settings.

Carefully manage the IP addresses because each device on the network requires a unique address. Having multiple devices with the same IP address can cause unintended operation of your network and associated equipment. Although some equipment, such as the present device, may detect duplicate IP addresses, other equipment may not.

### **WARNING**

#### **UNINTENDED EQUIPMENT OPERATION**

- Verify that all devices have unique addresses.
- Obtain your IP address from your system administrator.
- Confirm that the IP address of the drive is unique before placing the system into service.
- Do not assign the same IP address to any other equipment on the network.
- Update the IP address after resetting the drive to factory settings.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

**NOTE:** Verify that your system administrator maintains a record of all assigned IP addresses on the network and subnetwork, and inform the system administrator of all configuration changes performed.

### Factory Settings via Commissioning Software

Use the menu items **Configuration** → **Factory Settings** in the commissioning software to restore the factory settings.

The new settings become active after a power cycle of the drive.



---

# Chapter 6

## Operation

---

### What Is in This Chapter?

This chapter contains the following topics:

Topic	Page
Access Channels	106
Movement Range	107
Scaling	108
Parameterization of the Signal Input Functions and the Signal Output Functions	110

## Access Channels

### Description

The product can be accessed via different types of access channels. Simultaneous access via multiple access channels or the use of exclusive access may cause unintended equipment operation.

**⚠ WARNING**

**UNINTENDED EQUIPMENT OPERATION**

- Verify that simultaneous access via multiple access channels cannot cause unintended triggering or blocking of commands.
- Verify that the use of exclusive access cannot cause unintended triggering or blocking of commands.
- Verify that the required access channels are available.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

The product can be addressed via different access channels. Access channels are:

- Fieldbus
- Commissioning software
- Digital signal inputs
- Web server

Only one access channel can have exclusive access to the product. An exclusive access can be provided via different access channels:

- Via a fieldbus:  
Exclusive access is provided to a fieldbus by blocking the other access channels with the parameter `AccessLock`.
- Via the commissioning software:  
The commissioning software receives exclusive access via the switch “Exclusive access” in position “On”.

When the drive is powered on, there is no exclusive access via an access channel.


The signal input functions “Halt”, “Fault Reset”, “Enable”, “Positive Limit Switch (LIMP)”, “Negative Limit Switch (LIMN)” and “Reference Switch (REF)” as well as the signals of the safety-related function STO (`STO_A` and `STO_B`) are available during exclusive access.

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
<code>AccessLock</code>	<p>Locking other access channels. Value 0: Allow control via other access channels Value 1: Lock control via other access channels</p> <p>With this parameter, the fieldbus can lock active access to the device via the following access channels: - Input signals - Commissioning software</p> <p>Processing of the input signal HALT cannot be locked. Modified settings become active immediately.</p>	- 0 - 1	UINT16 R/W - -	Modbus 316 CIP 101.1.30

## Movement Range

### Size of the Movement Range

The movement range is the maximum possible range within which a movement can be made to a position.  
Movement range in user-defined units with the factory scaling:



- A -1073741824 user-defined units (usr)
- B 1073741823 user-defined units (usr)

### Availability

The movement range is relevant in the following operating modes:

- Jog
- Profile Position
- Homing

### Zero Point of the Movement Range

The zero point is the point of reference for absolute movements in the operating mode Profile Position.

### Valid Zero Point

The zero point of the movement range is set by means of a reference movement or by position setting.  
A reference movement and position setting can be performed in the operating mode Homing.

In the case of a movement beyond the movement range (for example, a relative movement), the zero point becomes invalid.

### Movement Beyond the Movement Range

The response to a movement beyond the movement range depends on the operating mode and the type of movement.

The following responses are possible:

- In the case of a movement beyond the movement range, the movement range restarts.
- In the case of a movement with a target position outside of the movement range, position setting to 0 is performed before the movement is started.

Responses in operating mode Jog:

- Continuous movement: The movement range restarts.
- Step movement: Internal position setting to 0.


Responses in operating mode Profile Position:

- Relative movement: Internal position setting to 0.
- Absolute movement: An absolute movement beyond the movement range is not possible.

## Scaling

### Overview

Scaling converts user-defined units into internal units of the drive, and vice versa.



### User-Defined Units

Values for positions are specified in user-defined unit **usr**.

Modifying the scaling modifies the ratio between user-defined units and internal units. After a modification to the scaling, one and the same value of a parameter specified in a user-defined unit causes a different movement than before the modification. A modification of the scaling affects all parameters whose values are specified in user-defined units.

## ⚠ WARNING

### UNINTENDED MOVEMENT

- Verify all parameters with user-defined units before modifying the scaling factor.
- Verify that a modification of the scaling factor cannot cause unintended movements.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

### Scaling Factor

The scaling factor is the relationship between the number of motor revolutions and the required user-defined units (**usr**).

Calculation of the scaling factor:

$$\frac{\text{Number of revolutions of the motor}}{\text{Number of user-defined units [usr]}}$$

A new scaling factor is activated when you specify the numerator value.

With a scaling factor of  $< 1 / 32768$ , a movement outside of the movement range cannot be performed.

The internal resolution used by the drive is 32768 increments per revolution.

The following parameter values must be adapted in addition to the user-defined values to obtain the same movement of the motor after modifying the scaling factor: **HMoutdisusr**, **HMdisusr**, **HMp\_homeusr**, **HMsrchdisusr**, **JOGstepusr**, **SPVswLimPusr** and **SPVswLimNusr**.

The following factory settings are used:

- One motor revolution corresponds to 16384 user-defined units

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
POSscaleNum	<p>Position scaling: Numerator. Scaling factor is defined as:</p> <p>Motor revolutions</p> <p>----- User-defined units [usr]</p> <p>A new scaling is activated when the numerator value is set.</p> <p>User-defined limit values may be reduced due to the calculation of an internal factor. Setting can only be modified if power stage is disabled. Modified settings become active immediately.</p>	<p>revolution</p> <p>1 1 2147483647</p>	<p>INT32 R/W per. -</p>	<p>Modbus 1552 CIP 106.1.8</p>
POSscaleDenom	<p>Position scaling: Denominator. Refer to numerator (POSscaleNum) for a description.</p> <p>A new scaling is activated when the numerator value is set. Setting can only be modified if power stage is disabled.</p>	<p>usr</p> <p>1 16384 2147483647</p>	<p>INT32 R/W per. -</p>	<p>Modbus 1550 CIP 106.1.7</p>

## Parameterization of the Signal Input Functions and the Signal Output Functions

### Description

Signal input functions and signal output functions can be assigned to the digital inputs and digital outputs.

**⚠ WARNING**

**UNINTENDED EQUIPMENT OPERATION**

- Verify that the wiring is appropriate for the factory settings and any subsequent parameterizations.
- Only start the system if there are no persons or obstructions in the zone of operation.
- Carefully run tests for all operating states and potential error situations when commissioning, upgrading or otherwise modifying the operation of the drive.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

### Factory Settings

Factory settings of the digital inputs and digital outputs:

Signal	Signal input function
LIO1	Input Positive Limit Switch (LIMP)
LIO2	Input Negative Limit Switch (LIMN)
LIO3	Input Free Available
LIO4	Input Reference Switch (REF)

### Parameterization

Available signal input functions:

Signal input function	Description in chapter
Input Free Available	Available as required. Via parameter <code>_IO_LIO_act</code> , the signal input can be read.
Input Fault Reset	Changing the Operating State via Signal Inputs <a href="#">(see page 120)</a>
Input Enable	Changing the Operating State via Signal Inputs <a href="#">(see page 120)</a>
Input Halt	Stopping Movement with Halt <a href="#">(see page 158)</a>
Input Jog Positive	Operating Mode Jog <a href="#">(see page 125)</a>
Input Jog Negative	Operating Mode Jog <a href="#">(see page 125)</a>
Input Jog Fast/Slow	Operating Mode Jog <a href="#">(see page 125)</a>
Input Reference Switch (REF)	Reference Switch <a href="#">(see page 166)</a>
Input Positive Limit Switch (LIMP) <sup>(1)</sup>	Limit Switches <a href="#">(see page 164)</a>
Input Negative Limit Switch (LIMN) <sup>(2)</sup>	Limit Switches <a href="#">(see page 164)</a>
<b>(1)</b> Only available with LIO1	
<b>(2)</b> Only available with LIO2	

Available signal output functions:

Signal output function	Description in chapter
Output Free Available	Setting a Signal Output via Parameter <a href="#">(see page 160)</a>
Output No Fault	Indicating the Operating State via Signal Inputs <a href="#">(see page 118)</a>
Output Active	Indicating the Operating State via Signal Inputs <a href="#">(see page 118)</a>

The following parameters can be used to parameterize the digital inputs and digital outputs:

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
IOfunct_LIO1	<p>Function Input/Output LIO1.</p> <p><b>1 / Input Free available:</b> Available as required</p> <p><b>2 / Input Fault reset:</b> Reset fault (local control mode only)</p> <p><b>3 / Input Enable:</b> Enable (local control mode only)</p> <p><b>4 / Input Halt:</b> Halt</p> <p><b>9 / Input Jog positive:</b> Jog positive</p> <p><b>10 / Input Jog negative:</b> Jog negative</p> <p><b>11 / Input Jog fast/slow:</b> Jog fast/slow</p> <p><b>20 / Input Reference switch (REF):</b> Reference switch (REF)</p> <p><b>21 / Input Positive limit switch (LIMP):</b> Positive limit switch (LIMP)</p> <p><b>101 / Output Free available:</b> Available as required</p> <p><b>102 / Output No fault:</b> No fault</p> <p><b>103 / Output Active:</b> Ready</p> <p>Setting can only be modified if power stage is disabled.</p> <p>Modified settings become active the next time the product is powered on.</p>	- - - -	UINT16 R/W per. -	Modbus 1826 CIP 107.1.17
IOfunct_LIO2	<p>Function Input/Output LIO2.</p> <p><b>1 / Input Free available:</b> Available as required</p> <p><b>2 / Input Fault reset:</b> Reset fault (local control mode only)</p> <p><b>3 / Input Enable:</b> Enable (local control mode only)</p> <p><b>4 / Input Halt:</b> Halt</p> <p><b>9 / Input Jog positive:</b> Jog positive</p> <p><b>10 / Input Jog negative:</b> Jog negative</p> <p><b>11 / Input Jog fast/slow:</b> Jog fast/slow</p> <p><b>20 / Input Reference switch (REF):</b> Reference switch (REF)</p> <p><b>22 / Input Negative limit switch (LIMN):</b> Negative limit switch (LIMN)</p> <p><b>101 / Output Free available:</b> Available as required</p> <p><b>102 / Output No fault:</b> No fault</p> <p><b>103 / Output Active:</b> Ready</p> <p>Setting can only be modified if power stage is disabled.</p> <p>Modified settings become active the next time the product is powered on.</p>	- - - -	UINT16 R/W per. -	Modbus 1828 CIP 107.1.18
IOfunct_LIO3	<p>Function Input/Output LIO3.</p> <p><b>1 / Input Free available:</b> Available as required</p> <p><b>2 / Input Fault reset:</b> Reset fault (local control mode only)</p> <p><b>3 / Input Enable:</b> Enable (local control mode only)</p> <p><b>4 / Input Halt:</b> Halt</p> <p><b>9 / Input Jog positive:</b> Jog positive</p> <p><b>10 / Input Jog negative:</b> Jog negative</p> <p><b>11 / Input Jog fast/slow:</b> Jog fast/slow</p> <p><b>20 / Input Reference switch (REF):</b> Reference switch (REF)</p> <p><b>101 / Output Free available:</b> Available as required</p> <p><b>102 / Output No fault:</b> No fault</p> <p><b>103 / Output Active:</b> Ready</p> <p>Setting can only be modified if power stage is disabled.</p> <p>Modified settings become active the next time the product is powered on.</p>	- - - -	UINT16 R/W per. -	Modbus 1830 CIP 107.1.19

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
IOfunct_LIO4	Function Input/Output LIO4. <b>1 / Input Free available:</b> Available as required <b>2 / Input Fault reset:</b> Reset fault (local control mode only) <b>3 / Input Enable:</b> Enable (local control mode only) <b>4 / Input Halt:</b> Halt <b>9 / Input Jog positive:</b> Jog positive <b>10 / Input Jog negative:</b> Jog negative <b>11 / Input Jog fast/slow:</b> Jog fast/slow <b>20 / Input Reference switch (REF):</b> Reference switch (REF) <b>101 / Output Free available:</b> Available as required <b>102 / Output No fault:</b> No fault <b>103 / Output Active:</b> Ready Setting can only be modified if power stage is disabled. Modified settings become active the next time the product is powered on.	- - - -	UINT16 R/W per. -	Modbus 1832 CIP 107.1.20

---

# Chapter 7

## Operating States and Operating Modes

---

### What Is in This Chapter?

This chapter contains the following sections:

Section	Topic	Page
7.1	Operating States	114
7.2	Indicating, Starting and Changing an Operating Mode	122
7.3	Operating Mode Jog	125
7.4	Operating Mode Profile Velocity	131
7.5	Operating Mode Profile Position	135
7.6	Operating Mode Homing	140

# Section 7.1

## Operating States

---

### What Is in This Section?

This section contains the following topics:

Topic	Page
State Diagram and State Transitions	115
Indicating the Operating State via Signal Outputs	118
Indication of the Operating State via Fieldbus	119
Changing the Operating State via Signal Inputs	120
Changing the Operating State via Fieldbus	121


## State Diagram and State Transitions

### State Diagram

When the product is powered on and when an operating mode is started, the product goes through a number of operating states.

The state diagram (state machine) shows the relationships between the operating states and the state transitions.

The operating states are internally monitored and influenced by monitoring functions.



### Operating States

Operating state	Description
1 Start	Electronics are initialized
2 Not Ready To Switch On	The power stage is not ready to switch on
3 Switch On Disabled	Not possible to enable the power stage
4 Ready To Switch On	The power stage is ready to switch on.
5 Switched On	Power stage is switched on
6 Operation Enabled RUN/HALT	Power stage is enabled Selected operating mode is active
7 Quick Stop Active	"Quick Stop" is being executed
8 Fault Reaction Active	Error response is active
9 Fault	Error response terminated Power stage is disabled

**Error Class**

The errors are classified according to the following error classes:

Error class	State transition	Error response	Resetting the error message
0	-	No interruption of the movement	Function "Fault Reset"
1	T11	Stop the movement with "Quick Stop"	Function "Fault Reset"
2	T13, T14	Stop the movement with "Quick Stop" and disable the power stage when the motor has come to a standstill	Function "Fault Reset"
3	T13, T14	Disable the power stage immediately without stopping the movement first	Function "Fault Reset"
4	T13, T14	Disable the power stage immediately without stopping the movement first	Power cycle

**Error Response**

The state transition T13 (error class 2, 3 or 4) initiates an error response as soon as an error is detected to which the device must respond.

Error class	Response
2	Movement is stopped with "Quick Stop". After standstill the holding brake is applied (if available). After the holding brake is applied the power stage is disabled.
3, 4 or safety-related function STO	Power stage is immediately disabled

An error can be detected by a temperature sensor, for example. The drive stops the movement and triggers an error response. Subsequently, the drive transitions to the operating state 9 Fault.

**Resetting an Error**

The function "Fault Reset" resets an error.

In the event of a "Quick Stop" triggered by a detected error of class 1 (operating state 7 Quick Stop Active), a "Fault Reset" causes a direct transition to operating state 6 Operation Enabled.

**State Transitions**

State transitions are triggered by an input signal, a fieldbus command or as a response to a monitoring function.

State transition	Operating state	Condition / event <sup>(1)</sup>	Response
T0	1-> 2	<ul style="list-style-type: none"> <li>Device electronics successfully initialized</li> </ul>	
T1	2-> 3	<ul style="list-style-type: none"> <li>Parameter successfully initialized</li> </ul>	
T2	3-> 4	<ul style="list-style-type: none"> <li>No undervoltage and Encoder successfully tested and Actual velocity: &lt;1000 RPM and <math>\overline{STO\_A}</math> and <math>\overline{STO\_B}</math> = +24 V</li> </ul>	
T3	4-> 5	<ul style="list-style-type: none"> <li>Request for enabling the power stage</li> </ul>	
T4	5-> 6	<ul style="list-style-type: none"> <li>Automatic transition</li> </ul>	Power stage is enabled. User parameters are verified. Holding brake is released (if available).
T7	4-> 3	<ul style="list-style-type: none"> <li>Undervoltage</li> <li>STO signals = 0 V</li> <li>Actual velocity: &gt;1000 RPM (for example by external driving force)</li> </ul>	-
T9	6-> 3	<ul style="list-style-type: none"> <li>Request for disabling the power stage</li> </ul>	Power stage is immediately disabled.
T10	5-> 3	<ul style="list-style-type: none"> <li>Request for disabling the power stage</li> </ul>	

**(1)** In order to trigger a state transition it is sufficient if one condition is met

State transition	Operating state	Condition / event <sup>(1)</sup>	Response
T11	6 -> 7	<ul style="list-style-type: none"> <li>• Error of error class 1</li> </ul>	Movement is stopped with "Quick Stop".
T12	7 -> 3	<ul style="list-style-type: none"> <li>• Request for disabling the power stage</li> </ul>	Power stage is immediately disabled, even if "Quick Stop" is still active.
T13	x -> 8	<ul style="list-style-type: none"> <li>• Error of error classes 2, 3 or 4</li> </ul>	Error response is carried out ( <i>see page 116</i> ).
T14	8 -> 9	<ul style="list-style-type: none"> <li>• Error response terminated (error class 2)</li> <li>• Error of error classes 3 or 4</li> </ul>	
T15	9 -> 3	<ul style="list-style-type: none"> <li>• Function: "Fault Reset"</li> </ul>	Error is reset (cause of error must have been corrected).
T16	7 -> 6	<ul style="list-style-type: none"> <li>• Function: "Fault Reset"</li> </ul>	In the event of a "Quick Stop" triggered by a detected error of class 1, a "Fault Reset" causes a direct transition to the operating state <b>6</b> Operation Enabled.
<b>(1)</b> In order to trigger a state transition it is sufficient if one condition is met			

## Indicating the Operating State via Signal Outputs

### Overview


Information on the operating state is available via the signal outputs.  
 The table below provides an overview.

Operating state	Signal output function	
	"Output No Fault"	"Output Active"
1 Start	0	0
2 Not Ready To Switch On	0	0
3 Switch On Disabled	0	0
4 Ready To Switch On	1	0
5 Switched On	1	0
6 Operation Enabled	1	1
7 Quick Stop Active	0	0
8 Fault Reaction Active	0	0
9 Fault	0	0

## Indication of the Operating State via Fieldbus

### Overview

The operating state is indicated with the word "driveStat".



Bit	Name	Meaning
0 ... 3	STATE	Operating state (binary coded) <b>1</b> Start <b>2</b> Not Ready To Switch On <b>3</b> Switch On Disabled <b>4</b> Ready To Switch On <b>5</b> Switched On <b>6</b> Operation Enabled <b>7</b> Quick Stop Active <b>8</b> Fault Reaction Active <b>9</b> Fault
4 ... 5	-	Reserved
6	ERROR	Error detected (error classes 1 ... 3)
7	WARN	Error detected (error class 0)
8	HALT	"Halt" is active
9 ... 12	-	Reserved
13	X_INFO	Operating mode-specific information
14	X_END	0: Operating mode started 1: Operating mode terminated
15	X_ERR	0: No error detected 1: Error detected

## Changing the Operating State via Signal Inputs

### Overview

It is possible to switch between operating states via the signal inputs.

- Signal input function "Input Enable"
- Signal input function "Input Fault Reset"

### Signal Input Function "Input Enable"

The power stage is enabled by means of the signal input function "Input Enable".

"Input Enable"	State transition
Rising edge	Enable power stage (T3)
Falling edge	Disabling the power stage (T9 and T12)

If you want to enable the power stage via the signal input, you must first parameterize the signal input function "Enable", refer to chapter Parameterization of the Signal Input Functions and the Signal Output Functions ([see page 110](#)).

### Signal Input Function "Input Fault Reset"

The signal input function "Input Fault Reset" is used to reset an error.


"Input Fault Reset"	State transition
Rising edge	Resetting an error (T15 and T16)

If you want to reset an error via the signal input, you must first parameterize the signal input function "Input Fault Reset", refer to chapter Parameterization of the Signal Input Functions and the Signal Output Functions ([see page 110](#)).

## Changing the Operating State via Fieldbus

### Overview

The operating state can be set with the byte “driveControl”.



Bit	Name	Meaning	Operating state
0	DS	Disable the power stage	<b>6</b> Operation Enabled -> <b>4</b> Ready To Switch On
1	EN	Enable the power stage	<b>4</b> Ready To Switch On -> <b>6</b> Operation Enabled
2	QS	Perform “Quick Stop”	<b>6</b> Operation Enabled -> <b>7</b> Quick Stop Active
3	FR	Perform “Fault Reset”	<b>7</b> Quick Stop Active -> <b>6</b> Operation Enabled <b>9</b> Fault -> <b>4</b> Ready To Switch On
4	-	Reserved	-
5	SH	Perform “Halt”	<b>6</b> Operation Enabled
6	CH	Clear “Halt”	<b>6</b> Operation Enabled
7	CU	Resume operating mode interrupted by “Halt”	<b>6</b> Operation Enabled

In the case of a write access, the bits respond to a transition from 0 to 1 to trigger the corresponding function.

If a request for changing the operating state is not successful, this request is ignored. There is no error response.

If the bits 0 ... 7 are set to 0, the power stage is disabled.

Ambivalent bit combinations are treated in accordance with the following priority list (highest priority bit 0, lowest priority bit 6 and bit 7):

- Bit 0 (disable power stage) takes precedence over bit 1 (enable power stage)
- Bit 2 (perform “Quick Stop”) takes precedence over bit 3 (perform “Fault Reset”)
- Bit 5 (perform “Halt”) takes precedence over bit 6 (clear “Halt”) and bit 7 (resume operating mode interrupted by “Halt”)

If an error of error class 2 or error class 3 is detected, a “Fault Reset” can only be performed if the value of bit 1 (enable power stage) is 0.

## Section 7.2

### Indicating, Starting and Changing an Operating Mode

---

#### What Is in This Section?


This section contains the following topics:

Topic	Page
Indicating the Operating Mode	123
Starting and Changing an Operating Mode	124

## Indicating the Operating Mode

### Overview

The byte "modeStat" is used to indicate the set operating mode.




Bit	Name	Description
0 ... 3	MODE	Indicates the set operating mode Value 1: Jog Value 2: Homing Value 3: Profile Position Value 4: Profile Velocity
4	-	Reserved
5	ref_ok	Zero point is valid.
6	ME	The bit "ME" (Mode Error) relates to parameters that depend on the bit "MT" (Mode Toggle). The bit "ME" (Mode Error) is set to 1 if a request (for example, starting an operating mode) was rejected.
7	MT	Bit "MT" (Mode Toggle)

## Starting and Changing an Operating Mode

### Starting and Changing an Operating Mode

The byte “modeControl” is used to set the operating mode.



Bit	Name	Description
0 ... 3	MODE	Operating Mode Value 1: Jog Value 2: Homing Value 3: Profile Position Value 4: Profile Velocity
4 ... 6	ACTION	Operating mode-dependent
7	MT	Bit “MT” (Mode Toggle)

The operating mode can be activated or target values can be modified by supplying or setting the following values:

- Target values, depending on required operating mode
- Operating mode in “modeControl”, bits 0 ... 3 (MODE).
- Action for this operating mode, bits 4 ... 6 (ACTION)
- Toggle bit 7 (MT)

The following chapters describe the available operating modes, functions, and the corresponding target values.

---

## Section 7.3

### Operating Mode Jog

---

#### What Is in This Section?

This section contains the following topics:

Topic	Page
Overview	126
Parameterization	129
Additional Settings	130

## Overview

### Description

In the operating mode Jog, a movement is made from the actual motor in the specified direction.

A movement can be made using one of two methods:


- Continuous movement
- Step movement

In addition, the drive provides two parameterizable velocities.


### Continuous Movement

As long as the signal for the direction is available, a continuous movement is made in the required direction.

The illustration below provides an example of continuous movement via the signal inputs:



The illustration below provides an example of continuous movement via the fieldbus:




### Step Movement

If the signal for the direction is available for a short period of time, a movement with a parameterizable number of user-defined units is made in the required direction.


If the signal for the direction is available continuously, a movement with a parameterizable number of user-defined units is made in the required direction. After this movement, the motor stops for a defined period of time. Then a continuous movement is made in the required direction.

The illustration below provides an example of step movement via the signal inputs:



- 1 Slow movement in positive direction with a parameterizable number of user-defined units  $JOGstepusr$
- 2 Waiting time  $JOGtime$
- 3 Slow continuous movement in positive direction
- 4 Fast continuous movement in positive direction

The illustration below provides an example of step movement via the fieldbus:



- 1 Slow movement in positive direction with a parameterizable number of user-defined units  $JOGstepusr$
- 2 Waiting time  $JOGtime$
- 3 Slow continuous movement in positive direction
- 4 Fast continuous movement in positive direction

### Starting the Operating Mode

The operating mode can be started via the signal inputs or via the fieldbus.

If you want to start the operating mode via the signal inputs, you must first parameterize the signal input functions "Input Enable", "Input Fault Reset", "Input Jog Negative" and "Input Jog Positive", refer to chapter Parameterization of the Signal Input Functions and the Signal Output Functions (*see page 110*).

Signal input	Signal input function
DI0	"Input Enable" Enable and disable the power stage
DI1	"Input Fault Reset" Resetting an error message

Signal input	Signal input function
DI2	"Input Jog Negative" Operating mode Jog: Movement in negative direction
DI3	"Input Jog Positive" Operating mode Jog: Movement in positive direction

If you want to start the operating mode via the fieldbus, you must first set the operating mode in the byte "modeControl". Writing the value in "modeControl" activates the operating mode. Writing the value in "Ref\_16" starts the movement.

modeControl Bits 0 ... 6 MODE+ACTION	Ref_16	Ref_32
Value 01 hex	As JOGactivate	-

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
JOGactivate	Activation of operating mode Jog. Bit 0 = 1: Positive direction of rotation Bit 1 = 1: Negative direction of rotation Bit 2 = 0: Slow velocity Bit 2 = 1: Fast velocity  If both bits for the direction of rotation are activated at the same time, no movement is started. If a jog movement is running, the simultaneous activation of the bits for the direction of rotation has no effect. Modified settings become active immediately.	- 0 0 7	UINT16 R/W - -	-

### Status Information

The word "driveStat" provides information on the operating mode.

Bit	Name	Meaning
13	X_INFO	Reserved
14	X_END	0: Operating mode started 1: Operating mode terminated
15	X_ERR	0: No error detected 1: Error detected

### Terminating the Operating Mode

The operating mode is terminated when the motor is at a standstill and one of the following conditions is met:

- Signal inputs "Input Jog Positive" and "Input Jog Negative" are set to 0
- Value 0 in "Ref\_16"
- Stop caused by "Halt" or "Quick Stop"
- Stop caused by a detected error

## Parameterization

### Switching Between Velocities Via a Signal Input

The drive provides the signal input function "Input Jog Fast/Slow". This signal input function allows you to switch between two velocities via a signal input.

If you want to switch between the two velocities, you must first parameterize the signal input function "Input Jog Fast/Slow", refer to chapter Parameterization of the Signal Input Functions and the Signal Output Functions (*see page 110*).

### Setting the Velocities

Two parameterizable velocities are available.

- Set the values with the parameters JOGn\_slow and JOGn\_fast.

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
JOGn_slow	Velocity for slow movement. The adjustable value is internally limited to the parameter setting in RAMPn_max. Modified settings become active immediately.	RPM 1 60 3000	UINT16 R/W per. -	Modbus 10504 CIP 141.1.4
JOGn_fast	Velocity for fast movement. The adjustable value is internally limited to the parameter setting in RAMPn_max. Modified settings become active immediately.	RPM 1 180 3000	UINT16 R/W per. -	Modbus 10506 CIP 141.1.5

### Setting the Step Movement

The parameters JOGstepusr and JOGtime are used to set the number of user-defined units and the time for which the motor is stopped.

- Set the values with the parameters JOGstepusr and JOGtime.

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
JOGstepusr	Distance for step movement. Modified settings become active the next time the motor moves.	usr 0 20 2147483647	INT32 R/W per. -	Modbus 10510 CIP 141.1.7
JOGtime	Wait time for step movement. Modified settings become active the next time the motor moves.	ms 1 500 32767	UINT16 R/W per. -	Modbus 10512 CIP 141.1.8

### Changing the Motion Profile for the Velocity

It is possible to modify the parameterization of the Motion Profile for the Velocity (*see page 155*).

## Additional Settings

### Overview

The following functions can be used for target value processing:

- Chapter Stopping Movement with Halt (*see page 158*)
- Chapter Stopping Movement with Quick Stop (*see page 159*)
- Chapter Setting a Signal Output via Parameter (*see page 160*)
- Chapter Position Capture via Signal Input (*see page 161*)

The following functions can be used for monitoring the movement:

- Chapter Limit Switches (*see page 164*)
- Chapter Software Limit Switches (*see page 167*)

---

## Section 7.4

### Operating Mode Profile Velocity

---

#### What Is in This Section?

This section contains the following topics:

Topic	Page
Overview	132
Parameterization	133
Additional Settings	134

## Overview

### Description

In the operating mode Profile Velocity, a movement is made with a specified target velocity.  
The motion profile for velocity is active in this operating mode.

### Starting the Operating Mode

The operating mode can be started via the fieldbus.

The operating mode must be set in the byte “modeControl”. Writing the value in “modeControl” activates the operating mode. Writing the value in “Ref\_16” starts the movement.

modeControl Bits 0 ... 6 MODE+ACTION	Ref_16	Ref_32
Value 04 hex	As PVn_target	-

### Status Information

The word “driveStat” provides information on the operating mode.

Bit	Name	Meaning
13	X_INFO	0: Target velocity not reached 1: Target velocity reached
14	X_END	0: Operating mode started 1: Operating mode terminated
15	X_ERR	0: No error detected 1: Error detected

### Terminating the Operating Mode

The operating mode is terminated when the motor is at a standstill and one of the following conditions is met:

- Stop caused by “Halt” or “Quick Stop”
- Stop caused by a detected error

## Parameterization

### Target Velocity

The parameter `PVn_target` allows you to set the target velocity.

- Set the target velocity with the parameter `PVn_target`.

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
<code>PVn_target</code>	Target velocity of operating mode Profile Velocity. The adjustable value is internally limited to the setting in <code>RAMPn_max</code> . Modified settings become active immediately.	RPM -3000 - 3000	INT32 R/W - -	-

### Modifying the Motion Profile for the Velocity

It is possible to modify the parameterization of the Motion Profile for the Velocity (*see page 155*).

## Additional Settings

### Overview

The following functions can be used for target value processing:

- Chapter Stopping Movement with Halt (*see page 158*)
- Chapter Stopping Movement with Quick Stop (*see page 159*)
- Chapter Setting a Signal Output via Parameter (*see page 160*)
- Chapter Position Capture via Signal Input (*see page 161*)

The following functions can be used for monitoring the movement:

- Chapter Limit Switches (*see page 164*)
- Chapter Software Limit Switches (*see page 167*)

---

## Section 7.5

### Operating Mode Profile Position

---

#### What Is in This Section?

This section contains the following topics:

Topic	Page
Overview	136
Parameterization	138
Additional Settings	139

## Overview

### Description


In the operating mode Profile Position, a movement to a target position is performed.

Two types of movements are available:

- Relative movement
- Absolute movement


### Relative Movement

In the case of a relative movement, the movement is relative with reference to the previous target position or the actual position of the motor.



### Absolute Movement

In the case of an absolute movement, the movement is absolute with reference to the zero point.



A zero point must be defined with the operating mode Homing prior to the first absolute movement.

### Starting the Operating Mode

The operating mode can be started via the fieldbus.

The operating mode must be set in the byte “modeControl”. Writing the value in “modeControl” activates the operating mode.

Method	modeControl Bits 0 ... 6 MODE+ACTION	Ref_16	Ref_32
Absolute	03 hex	As PPn_target	As Ppp_absusr
Relative with reference to the currently set target position	13 hex	As PPn_target	As Ppp_relprefusr
Relative with reference to the current motor position	23 hex	As PPn_target	As Ppp_relpactusr

### Status Information

The word “driveStat” provides information on the operating mode.

bit	Name	Meaning
13	X_INFO	0: Target position not reached 1: Target position reached
14	X_END	0: Operating mode started 1: Operating mode terminated
15	X_ERR	0: No error detected 1: Error detected

### Terminating the Operating Mode

The operating mode is terminated when the motor is at a standstill and one of the following conditions is met:

- Target position reached
- Stop caused by “Halt” or “Quick Stop”
- Stop caused by a detected error

## Parameterization

### Target Velocity

The parameter `PPn_target` allows you to set the target velocity.

- Set the target velocity with the parameter `PPn_target`.

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
<code>PPn_target</code>	Target velocity for operating mode Profile Position. The adjustable value is internally limited to the parameter setting in <code>RAMPn_max</code> . Modified settings become active immediately.	RPM 1 60 3000	UINT16 R/W - -	-

### Target Position

The parameters `PPp_absusr`, `PPp_relprefusr`, and `PPp_relpactusr` allow you to enter the target position.

- Set the required target position with the parameters `PPp_absusr`, `PPp_relprefusr`, and `PPp_relpactusr`.

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
<code>PPp_absusr</code>	Target position absolute for operating mode Profile Position. Minimum and maximum values depend on: - Scaling factor - Software limit switches (if they are activated) Modified settings become active immediately.	usr - - -	INT32 R/W - -	-
<code>PPp_relprefusr</code>	Target position relative to the currently set target position. Minimum and maximum values depend on: - Scaling factor - Software limit switches (if they are activated)  In the case of active positioning in operating mode Profile Position, relative positioning refers to the target position of the ongoing movement. The absolute user position limits can only be overrun if the drive is at standstill when the movement starts ( <code>x_end=1</code> ). In this case, implicit position setting to position 0 is performed. Modified settings become active immediately.	usr - - -	INT32 R/W - -	-
<code>PPp_relpactusr</code>	Target position relative to motor position. Minimum and maximum values depend on: - Scaling factor - Software limit switches (if they are activated)  In the case of active positioning in operating mode Profile Position, relative positioning refers to the motor position. The absolute user position limits can only be overrun if the drive is at standstill when the movement starts ( <code>x_end=1</code> ). In this case, implicit position setting to position 0 is performed. Modified settings become active immediately.	usr - - -	INT32 R/W - -	-

### Modifying the Motion Profile for the Velocity

It is possible to modify the parameterization of the Motion Profile for the Velocity (*see page 155*).

## Additional Settings

### Overview

The following functions can be used for target value processing:

- Chapter Stopping Movement with Halt (*see page 158*)
- Chapter Stopping Movement with Quick Stop (*see page 159*)
- Chapter Setting a Signal Output via Parameter (*see page 160*)
- Chapter Position Capture via Signal Input (*see page 161*)

The following functions can be used for monitoring the movement:

- Chapter Limit Switches (*see page 164*)
- Chapter Software Limit Switches (*see page 167*)

## Section 7.6

### Operating Mode Homing

---

#### What Is in This Section?

This section contains the following topics:

Topic	Page
Overview	141
Parameterization	143
Reference Movement to a Limit Switch	146
Reference Movement to the Reference Switch in Positive Direction	147
Reference Movement to the Reference Switch in Negative Direction	148
Reference Movement to the Index Pulse	149
Position Setting	150
Additional Settings	151

## Overview

### Description

In the operating mode Homing, a reference is generated between a mechanical position and the position of the motor as determined by the encoder.

A reference between a mechanical position and the encoder position of the motor is generated by means of a reference movement or by means of position setting.

A successful reference movement or position setting homes the motor and the zero point becomes valid. The zero point is the point of reference for absolute movements in the operating mode Profile Position.

### Methods

A movement can be made using different methods:

- Reference movement to a limit switch
 

In the case of a reference movement to a limit switch, a movement to the negative limit switch or the positive limit switch is performed.

When the limit switch is reached, the motor is stopped and a movement is made back to the switching point of the limit switch.

From the switching point of the limit switch, a movement is made to the next index pulse of the motor or to a parameterizable distance from the switching point.

The position of the index pulse or the position of the parameterizable distance from the switching point is the reference point.
- Reference movement to the reference switch
 

In the case of a reference movement to the reference switch, a movement to the reference switch is performed.

When the reference switch is reached, the motor is stopped and a movement is made back to the switching point of the reference switch.

From the switching point of the reference switch, a movement is made to the next index pulse of the motor or to a parameterizable distance from the switching point.

The position of the index pulse or the position of the parameterizable distance from the switching point is the reference point.
- Reference movement to the index pulse
 

In the case of a reference movement to the index pulse, a movement is made from the actual position to the next index pulse. The position of the index pulse is the reference point.
- Position setting
 

In the case of position setting, the actual position of the motor is set to a specific position value.

A reference movement must be terminated without interruption for the new zero point to be valid. If the reference movement is interrupted, it must be started again.

### Starting the Operating Mode

The operating mode can be started via the fieldbus.

The operating mode must be set in the byte "modeControl". Writing the value in "modeControl" activates the operating mode.

Method	modeControl Bits 0 ... 6 MODE+ACTION	Ref_16	Ref_32
Reference movement	12 hex	As HMmethod	-
Position setting	02 hex	-	As HMp_setpusr

### Status Information

The word "driveStat" provides information on the operating mode.

bit	Name	Meaning
13	X_INFO	Reserved
14	X_END	0: Operating mode started 1: Operating mode terminated
15	X_ERR	0: No error detected 1: Error detected

### Terminating the Operating Mode

The operating mode is terminated when the motor is at a standstill and one of the following conditions is met:

- Homing successful
- Stop caused by "Halt" or "Quick Stop"
- Stop caused by a detected error

## Parameterization

### Setting Limit Switches and Reference Switches

The limit switches and reference switches must be set to meet the application requirements. Refer to the chapter Limit Switches (*see page 164*) and to the chapter Reference Switch (*see page 166*) for details.

### Selection of the Method

The operating mode Homing establishes an absolute position reference between the motor position and a defined axis position. There are various Homing methods which can be selected via the parameter `HMmethod`.

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
HMmethod	<p>Homing method.</p> <p>1: LIMN with index pulse 2: LIMP with index pulse 7: REF+ with index pulse, inv., outside 8: REF+ with index pulse, inv., inside 9: REF+ with index pulse, not inv., inside 10: REF+ with index pulse, not inv., outside 11: REF- with index pulse, inv., outside 12: REF- with index pulse, inv., inside 13: REF- with index pulse, not inv., inside 14: REF- with index pulse, not inv., outside 17: LIMN 18: LIMP 23: REF+, inv., outside 24: REF+, inv., inside 25: REF+, not inv., inside 26: REF+, not inv., outside 27: REF-, inv., outside 28: REF-, inv., inside 29: REF-, not inv., inside 30: REF-, not inv., outside 33: Index pulse neg. direction 34: Index pulse pos. direction 35: Position setting</p> <p>Abbreviations: REF+: Search movement in positive direction REF-: Search movement in negative direction inv.: Invert direction in switch not inv.: Direction not inverted in switch outside: Index pulse / distance outside switch inside: Index pulse / distance inside switch Modified settings become active immediately.</p>	- 0 - 35	UINT16 R/W - -	-

### Setting the Distance from the Switching Point

A distance to the switching point of the limit switch or the reference switch must be parameterized for a reference movement without index pulse. The parameter `HMdisusr` lets you set the distance to the switching point of the limit switch or of the reference switch.

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
HMdisusr	Distance from switching point. The distance from the switching point is defined as the reference point.  The parameter is only effective during a reference movement without index pulse. Modified settings become active the next time the motor moves.	usr 1 200 2147483647	INT32 R/W per. -	Modbus 10254 CIP 140.1.7

### Defining the Zero Point

The parameter `HMp_homeusr` is used to specify a position value which is set at the reference point after a successful reference movement. The position value at the reference point defines the zero point.

If the value 0 is used, the zero point corresponds to the reference point.

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
HMp_homeusr	Position at reference point. After a successful reference movement, this position is automatically set at the reference point. Modified settings become active the next time the motor moves.	usr -2147483648 0 2147483647	INT32 R/W per. -	Modbus 10262 CIP 140.1.11

### Setting Monitoring

The parameters `HMoutdisusr` and `HMsrchdisusr` allow you to activate monitoring of the limit switches and the reference switch.

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
HMoutdisusr	Maximum distance for search for switching point. Value 0: Monitoring of distance inactive Value >0: Maximum distance  After detection of the switch, the drive starts to search for the defined switching point. If the defined switching point is not found within the distance defined here, the reference movement is canceled and an error is detected. Modified settings become active the next time the motor moves.	usr 0 0 2147483647	INT32 R/W per. -	Modbus 10252 CIP 140.1.6
HMsrchdisusr	Maximum search distance after overtravel of switch. Value 0: Search distance monitoring disabled Value >0: Search distance  The switch must be activated again within this search distance, otherwise the reference movement is canceled. Modified settings become active the next time the motor moves.	usr 0 0 2147483647	INT32 R/W per. -	Modbus 10266 CIP 140.1.13

### Reading the Position Distance

The position distance between the switching point and index pulse can be read with the parameter `HMdisREFtoIDX`.

The distance between the switching point and the index pulse must be greater than 0.05 revolutions for reproducible reference movements with index pulse.

If the index pulse is too close to the switching point, the limit switch or reference switch can be moved mechanically.

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
HMdisREFtoIDX	Distance from switching point to index pulse. Allows you to verify the distance between the index pulse and the switching point and serves as a criterion for determining whether the reference movement with index pulse can be reproduced. In increments of 0.0001 revolution.	revolution - - -	INT32 R/- - -	Modbus 10264 CIP 140.1.12

### Setting Velocities

The parameters `HMn` and `HMn_out` are used to set the velocities for searching the switch and for moving away from the switch.

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
HMn	Target velocity for searching the switch. The adjustable value is internally limited to the setting in <code>RAMPn_max</code> . Modified settings become active the next time the motor moves.	RPM 1 60 3000	UINT16 R/W per. -	Modbus 10248 CIP 140.1.4
HMn_out	Target velocity for moving away from switch. The adjustable value is internally limited to the setting in <code>RAMPn_max</code> . Modified settings become active the next time the motor moves.	RPM 1 6 3000	UINT16 R/W per. -	Modbus 10250 CIP 140.1.5


### Modifying the Motion Profile for the Velocity

It is possible to modify the parameterization of the Motion Profile for the Velocity (*see page 155*).

## Reference Movement to a Limit Switch

### Overview

The following figure illustrates a reference movement to a limit switch  
Reference movement to a limit switch:



- 1 Movement to limit switch at velocity  $HM_n$
- 2 Movement to the switching point of the limit switch at velocity  $HM_{n\_out}$
- 3 Movement to index pulse or movement to a distance from the switching point at velocity  $HM_{n\_out}$

### Type A

Method 1: Movement to the index pulse.

Method 17: Movement to distance from switching point.

### Type B


Method 2: Movement to the index pulse.

Method 18: Movement to distance from switching point.

## Reference Movement to the Reference Switch in Positive Direction

### Overview

The following figure illustrates a reference movement to the reference switch in positive direction  
Reference movement to the reference switch in positive direction:



- 1 Movement to reference switch at velocity  $HM_n$
- 2 Movement to the switching point of the reference switch at velocity  $HM_{n\_out}$
- 3 Movement to index pulse or movement to a distance from the switching point at velocity  $HM_{n\_out}$

### Type A

Method 7: Movement to the index pulse.  
Method 23: Movement to distance from switching point.

### Type B

Method 8: Movement to the index pulse.  
Method 24: Movement to distance from switching point.

### Type C

Method 9: Movement to the index pulse.  
Method 25: Movement to distance from switching point.


### Type D

Method 10: Movement to the index pulse.  
Method 26: Movement to distance from switching point.

## Reference Movement to the Reference Switch in Negative Direction

### Overview

The following figure illustrates a reference movement to the reference switch in negative direction  
 Reference movement to the reference switch in negative direction:



- 1 Movement to reference switch at velocity  $HM_n$
- 2 Movement to the switching point of the reference switch at velocity  $HM_{n\_out}$
- 3 Movement to index pulse or movement to a distance from the switching point at velocity  $HM_{n\_out}$

### Type A

Method 11: Movement to the index pulse.  
 Method 27: Movement to distance from switching point.

### Type B

Method 12: Movement to the index pulse.  
 Method 28: Movement to distance from switching point.

### Type C

Method 13: Movement to the index pulse.  
 Method 29: Movement to distance from switching point.


### Type D

Method 14: Movement to the index pulse.  
 Method 30: Movement to distance from switching point.


## Reference Movement to the Index Pulse

### Overview

The following figure illustrates a reference movement to the index pulse  
Reference movement to the index pulse:



HMmethod = 33



HMmethod = 34

- 1 Width of the index pulse
- 2 Movement to falling edge of the index pulse at velocity  $HMn\_out$

## Position Setting

### Description

By means of position setting, the actual position is set to the position value in parameter `HMp_setpusr`. This also defines the zero point.


Position setting is only possible when the motor is at a standstill. Any active position deviation remains active and can be compensated for by the position controller after position setting.

### Setting the Position for Position Setting

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
<code>HMp_setpusr</code>	Position for Position Setting. Action object: write access triggers position setting. Only possible if the motor is at standstill. Position scaling is not considered. Modified settings become active immediately.	usr -2147483648 - 2147483647	INT32 R/W - -	-

### Example

Movement by 4000 user-defined units with position setting:



- 1 The motor is positioned by 2000 user-defined units.
- 2 By means of position setting to 0, the actual position is set to position value 0 which, at the same time, defines a new zero point.
- 3 When a new movement by 2000 user-defined units is triggered, the new target position is 2000 user-defined units.

## Additional Settings

### Overview

The following functions can be used for target value processing:

- Chapter Stopping Movement with Halt (*see page 158*)
- Chapter Stopping Movement with Quick Stop (*see page 159*)
- Chapter Setting a Signal Output via Parameter (*see page 160*)
- Chapter Position Capture via Signal Input (*see page 161*)

The following functions can be used for monitoring the movement:

- Chapter Limit Switches (*see page 164*)
- Chapter Software Limit Switches (*see page 167*)



---

# Chapter 8

## Functions for Operation

---

### What Is in This Chapter?

This chapter contains the following sections:

Section	Topic	Page
8.1	Functions for Target Value Processing	154
8.2	Functions for Monitoring Movements	163
8.3	Functions for Monitoring Internal Device Signals	169

## Section 8.1

### Functions for Target Value Processing

---

#### What Is in This Section?

This section contains the following topics:

Topic	Page
Motion Profile for the Velocity	155
Stopping a Movement with Halt	158
Stopping a Movement with Quick Stop	159
Setting a Signal Output via Parameter	160
Position Capture Via Signal Input	161

## Motion Profile for the Velocity

### Description

Target position and target velocity are input values you specify. A motion profile for the velocity is calculated on the basis of these values.

The motion profile for the velocity consists of an acceleration, a deceleration, and a maximum velocity.

The settings for the motion profile for the velocity are valid for both directions of movement.

### Type of Acceleration Ramp and Deceleration Ramp

The integrated drive provides a linear ramp and a motor-optimized ramp for acceleration and deceleration.

The motor-optimized ramp is used to compensate for the typical torque drop of a stepper motor at increasing velocities by reducing the acceleration.

A linear ramp is used for Quick Stop, regardless of the set ramp.

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
RAMP_TypeSel	Selection of ramp type. <b>0 / Linear:</b> Linear ramp <b>-1 / Motoroptimized:</b> Motor-optimized ramp Modified settings become active the next time the power stage is enabled.	- - - -	INT16 R/W per. -	Modbus 1574 CIP 106.1.19

### Start-Stop Velocity

Stepper motors offer fast acceleration from standstill, adjustable as the start-stop velocity.

Depending on the external load, the start-stop velocity can be set to up to 60 RPM.

If the value for the start-stop velocity is too low, the stepper motor may develop mechanical resonances with low external damping. If the value for the start-stop velocity is too high, the values you can set for acceleration and deceleration are reduced.

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
RAMPnstart0	Start/stop velocity. Start/stop velocity of motion profile for velocity Modified settings become active the next time the power stage is enabled.	RPM - - -	UINT16 R/W per. -	Modbus 1570 CIP 106.1.17

### Availability


The availability of the motion profile for the velocity depends on the operating mode.

The motion profile for the velocity is available in the following operating modes:

- Jog
- Profile Position
- Profile Velocity
- Homing

### Ramp Slope

The ramp slope determines the velocity changes of the motor per time unit. The ramp slope can be set for acceleration and deceleration.




Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
RAMPn_max	Maximum velocity of the motion profile for velocity. The parameter is active in the following operating modes: - Profile Position - Profile Velocity - Homing - Jog  If a greater reference velocity is set in one of these operating modes, it is automatically limited to RAMPn_max. This way, commissioning at limited velocity is easier to perform. Setting can only be modified if power stage is disabled. Modified settings become active the next time the motor moves.	RPM 60 13200 13200	UINT16 R/W per. -	Modbus 1554 CIP 106.1.9
RAMPacc	Acceleration of the motion profile for velocity. Modified settings become active the next time the motor moves.	RPM/s 1 600 3000000	UINT32 R/W per. -	Modbus 1556 CIP 106.1.10
RAMPdecel	Deceleration of the motion profile for velocity. Modified settings become active the next time the motor moves.	RPM/s 200 750 3000000	UINT32 R/W per. -	Modbus 1558 CIP 106.1.11

**Jerk Limitation**

Jerk limitation smoothes sudden acceleration changes to allow for smooth transitions.

The following figure illustrates the profile without jerk limitation (dashed line) and with jerk limitation (solid line):



Jerk limitation is activated and set via the parameter RAMP\_TAUjerk.

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
RAMP_TAUjerk	<p>Jerk limitation of the motion profile for velocity.</p> <p><b>0 / Off:</b> Off  <b>1 / 1:</b> 1 ms  <b>2 / 2:</b> 2 ms  <b>4 / 4:</b> 4 ms  <b>8 / 8:</b> 8 ms  <b>16 / 16:</b> 16 ms  <b>32 / 32:</b> 32 ms  <b>64 / 64:</b> 64 ms  <b>128 / 128:</b> 128 ms</p> <p>Adjustments can only be made if the operating mode is inactive (<math>x_{end}=1</math>).  Modified settings become active the next time the motor moves.</p>	ms 0 0 128	UINT16 R/W per. -	Modbus 1562 CIP 106.1.13

## Stopping a Movement with Halt

### Description

You can stop a movement with a Halt. The movement is resumed when the Halt is cleared.

A Halt can be triggered via a digital signal input or a fieldbus command.

In order to interrupt a movement with a Halt via a signal input, you must first parameterize the signal input function "Input Halt", see chapter Parameterization of the Signal Input Functions and the Signal Output Functions (*see page 110*).

If the Halt request is cleared while the deceleration is still being performed, the deceleration is continued until the motor has reached a standstill. After that, the motor accelerates to the original velocity.

### Setting the Deceleration Ramp

The deceleration ramp set with the parameter `RAMPdecel` for the Motion Profile for the Velocity (*see page 155*) is used for a Halt.

## Stopping a Movement with Quick Stop

### Description

You can stop a movement with a Quick Stop.

A Quick Stop can be triggered via a fieldbus command or in response to a detected error of error classes 1 or 2.

You can set the operating state to transition to after standstill has been reached:

- Remain in operating state **7** Quick Stop Active
- Transition to operating state **9** Fault

### Setting the Type of Operating State Transition

The parameter `LIM_QStopReact` lets you set the type of operating state transition.

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
LIM_QStopReact	<p>Quick Stop option code.</p> <p><b>-1 / Deceleration Ramp (Fault):</b> Use deceleration ramp and transition to operating state 9 Fault</p> <p><b>6 / Deceleration ramp (Quick Stop):</b> Use deceleration ramp and remain in operating state 7 Quick Stop Active</p> <p>Setting of deceleration ramp with parameter RAMPquickstop.</p> <p>Setting of torque ramp with parameter LIM_I_maxQSTP.</p> <p>The deceleration ramp is only available for operating modes with motion profile for velocity. The torque ramp is used in the operating modes without motion profile for velocity. Modified settings become active immediately.</p>	- -1 6 6	INT16 R/W per. -	Modbus 1584 CIP 106.1.24

### Setting the Deceleration Ramp

The parameter `RAMPquickstop` lets you set the deceleration ramp.

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
RAMPquickstop	<p>Deceleration ramp for Quick Stop.</p> <p>Deceleration ramp for a software stop or an error with error class 1 or 2.</p> <p>Modified settings become active the next time the motor moves.</p>	RPM/s 200 6000 3000000	UINT32 R/W per. -	Modbus 1572 CIP 106.1.18

## Setting a Signal Output via Parameter

### Description

The digital signal outputs can be set via the fieldbus.

In order to set the digital signal outputs via the parameter, you must first parameterize the signal output function "Output Free Available", see chapter Parameterization of the Signal Input Functions and the Signal Output Functions (*see page 110*).

If one or more of the outputs are not set to "Output Free Available", write access to that or those outputs is ignored.

The parameter `IO_LO_set` lets you set the digital signal outputs.

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
<code>IO_LO_set</code>	Setting the digital outputs directly. Bit 0 corresponds to the first output, bit 1 corresponds to the second output, and so on.	- - - -	UINT16 R/W - -	Modbus 2082 CIP 108.1.17

## Position Capture Via Signal Input

### Description

The motor position can be captured when a signal is detected at a Capture input.

### Number of Capture Inputs

Two Capture inputs are available.

- LIO1 (CAP1)
- LIO2 (CAP2)

### Method

The motor position can be captured in two ways:

- One-time position capture  
One-time capture means that the position is captured at the first edge.
- Continuous motor position capture  
Continuous capture means that the motor position is captured anew at every edge.

The motor position can be captured when the edge at the Capture input rises or falls.

### Setting the Edge

The following parameters let you set the edge for position capture.

- Set the required edge with the parameters `Cap1Config` and `Cap2Config`.

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
Cap1Config	Capture input 1 configuration. <b>0 / 1-&gt;0:</b> Position capture at falling edge <b>1 / 0-&gt;1:</b> Position capture at rising edge Modified settings become active immediately.	- 0 0 1	UINT16 R/W - -	Modbus 2564 CIP 110.1.2
Cap2Config	Capture input 2 configuration. <b>0 / 1-&gt;0:</b> Position capture at falling edge <b>1 / 0-&gt;1:</b> Position capture at rising edge Modified settings become active immediately.	- 0 0 1	UINT16 R/W - -	Modbus 2566 CIP 110.1.3

### Starting Position Capture

The following parameters let you start position capture.

- Set the method with the parameters `Cap1Activate` and `Cap2Activate`.

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
Cap1Activate	Capture input 1 start/stop. <b>0 / Capture stop:</b> Cancel capture function <b>1 / Capture once:</b> Start one-time capture <b>2 / Capture continuous:</b> Start continuous capture In the case of one-time capture, the function is terminated when the first value is captured. In the case of continuous capture, the function continues to run. Modified settings become active immediately.	- 0 - 2	UINT16 R/W - -	Modbus 2568 CIP 110.1.4

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
Cap2Activate	Capture input 2 start/stop. <b>0 / Capture stop:</b> Cancel capture function <b>1 / Capture once:</b> Start one-time capture <b>2 / Capture continuous:</b> Start continuous capture In the case of one-time capture, the function is terminated when the first value is captured. In the case of continuous capture, the function continues to run. Modified settings become active immediately.	- 0 - 2	UINT16 R/W - -	Modbus 2570 CIP 110.1.5

### Status Messages

The parameter CapStatus indicates the capture status.

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
CapStatus	Status of the capture inputs. Read access: Bit 0: Position captured via input CAP1 Bit 1: Position captured via input CAP2	- - - -	UINT16 R/- - -	Modbus 2562 CIP 110.1.1

### Captured Position

The captured position can be read via the following parameters:

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
Cap1Pos	Capture input 1 captured position. Captured position at the time of the "capture signal". The captured position is re-calculated after "Position Setting" or "Reference Movement".	usr - - -	INT32 R/- - -	Modbus 2572 CIP 110.1.6
Cap2Pos	Capture input 2 captured position. Captured position at the time of the "capture signal". The captured position is re-calculated after "Position Setting" or "Reference Movement".	usr - - -	INT32 R/- - -	Modbus 2574 CIP 110.1.7
Cap1Count	Capture input 1 event counter. Counts the capture events. The event counter is reset when capture input 1 is activated.	- - - -	UINT16 R/- - -	Modbus 2576 CIP 110.1.8
Cap2Count	Capture input 2 event counter. Counts the capture events. The event counter is reset when capture unit 2 is activated.	- - - -	UINT16 R/- - -	Modbus 2578 CIP 110.1.9

---

## Section 8.2

### Functions for Monitoring Movements

---

#### What Is in This Section?

This section contains the following topics:

Topic	Page
Hardware Limit Switches	164
Reference Switch	166
Software Limit Switches	167

## Hardware Limit Switches

### Description

The use of limit switches can help protect against some hazards (for example, collision with mechanical stop caused by incorrect reference values).

 **WARNING**

**LOSS OF CONTROL**

- Ensure that limit switches are installed as determined by your risk assessment.
- Verify correct connection of the limit switches.
- Verify that the limit switches are sufficiently distant from the mechanical end to allow an adequate stopping distance.
- Verify correct parameterization and function of the limit switches.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

Movements can be monitored with hardware limit switches. A positive hardware limit switch and a negative hardware limit switch can be used for monitoring.

If the positive or negative hardware limit switch is triggered, the movement is stopped with a Quick Stop. The drive responds with a detected error of error class 1. The error message can be reset by means of a "Fault Reset".

The response of the drive to a Quick Stop can be adjusted via the parameter `LIM_QStopReact`. Refer to the chapter Stopping a Movement with Quick Stop (*see page 159*) for additional information.

The movement can continue, however, only in the opposite direction. For example, if the positive hardware limit switch was triggered, further movement is only possible in negative direction. In the case of further movement in positive direction, the drive responds with a new detected error of error class 1.

The parameters `IOsigLimP` and `IOsigLimN` are used to set the type of hardware limit switch.

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
<code>IOsigLimP</code>	Signal evaluation for positive limit switch. <b>0 / Inactive:</b> Inactive <b>1 / Normally Closed:</b> Normally closed NC <b>2 / Normally Open:</b> Normally open NO Setting can only be modified if power stage is disabled. Modified settings become active the next time the power stage is enabled.	- 0 1 2	UINT16 R/W per. -	Modbus 1568 CIP 106.1.16
<code>IOsigLimN</code>	Signal evaluation for negative limit switch. <b>0 / Inactive:</b> Inactive <b>1 / Normally Closed:</b> Normally closed NC <b>2 / Normally Open:</b> Normally open NO Setting can only be modified if power stage is disabled. Modified settings become active the next time the power stage is enabled.	- 0 1 2	UINT16 R/W per. -	Modbus 1566 CIP 106.1.15

If you want to use hardware limit switches, you must first parameterize the signal input functions "Input Positive Limit Switch (LIMP)" and/or "Input Negative Limit Switch (LIMN)". Refer to chapter Parameterization of the Signal Input Functions and the Signal Output Functions (*see page 110*) for details.

### Temporary Deactivation of Hardware Limit Switches

The parameter `SPV_HW_Deactiv` can be used to temporarily deactivate the hardware limit switches, for example, for commissioning, or machine setup.

## ⚠ WARNING

### UNINTENDED EQUIPMENT OPERATION

Implement all measures identified in your risk assessment to avoid hazardous conditions that could result from temporary deactivation of limit switches.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
SPV_HW_Deactiv	<p>Temporary deactivation of hardware limit switches.</p> <p><b>0 / None:</b> No limit switch deactivated</p> <p><b>1 / Deactivate LIMP:</b> Deactivate positive limit switch</p> <p><b>2 / Deactivate LIMN:</b> Deactivate negative limit switch</p> <p><b>3 / Deact. LIMP+LIMN:</b> Deactivate both limit switches</p> <p>With this parameter, a PLC can temporarily deactivate hardware limit switches. This is useful if a homing procedure controlled by a PLC is to use a limit switch as a reference switch without any error response of the drive.</p> <p>Modified settings become active immediately.</p> <p>Available with firmware version <math>\geq</math>V1.010.</p>	- 0 0 3	UINT16 R/W - -	Modbus 1610 CIP 106.1.37

## Reference Switch

### Description

The reference switch is only active in the operating mode Homing.

The parameter `IOsigRef` lets you set the type of reference switch.

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
<code>IOsigRef</code>	Signal evaluation for reference switch. <b>1 / Normally Closed:</b> Normally closed NC <b>2 / Normally Open:</b> Normally open NO The reference switch is only active while a reference movement to the reference switch is processed. Setting can only be modified if power stage is disabled. Modified settings become active the next time the power stage is enabled.	- 1 1 2	UINT16 R/W per. -	Modbus 1564 CIP 106.1.14

If you want to use the reference switch, you must first parameterize the signal input function “Input Reference Switch (REF)”. Refer to chapter Parameterization of the Signal Input Functions and the Signal Output Functions ([see page 110](#)) for details.

## Software Limit Switches

### Description

Movements can be monitored with software limit switches. A positive position limit and a negative position limit can be set for monitoring.

If the positive or negative software limit switch is triggered, the movement is stopped with a Quick Stop. The integrated drive responds with a detected error of error class 1. The error message can be reset by means of a "Fault Reset".

The response of the drive to a Quick Stop can be adjusted via the parameter `LIM_QStopReact`. Refer to the chapter Stopping a Movement with Quick Stop (*see page 159*) for additional information.

The movement can continue, however, only in the opposite direction. For example, if the positive position limit was reached, further movement is only possible in negative direction. In the case of further movement in positive direction, the drive responds with a new detected error of error class 1.

### Prerequisite

Software limit switch monitoring only works with a valid zero point, refer to chapter Size of the Movement Range (*see page 107*).

### Behavior in Operating Modes with Target Positions

In operating modes with target positions, the movement is started even if the target position is beyond the positive position limit or the negative position limit. A Quick Stop is triggered so that the motor comes to a standstill at the position limit.

In the following operating modes, the target position is verified prior to the start of a movement so that the position limit is not exceeded regardless of the target position.

- Jog (step movement)
- Profile Position

### Behavior in Operating Modes Without Target Positions

In operating modes without target positions, a Quick Stop is triggered at the position limit.

- Jog (continuous movement)
- Profile Velocity

### Activation

The software limit switches are activated via the parameter `SPV_SW_Limits`.

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
<code>SPV_SW_Limits</code>	Activation of software limit switches. <b>0 / None:</b> Deactivated <b>1 / SWLIMP:</b> Activation of software limit switch positive direction <b>2 / SWLIMN:</b> Activation of software limit switch negative direction <b>3 / SWLIMP+SWLIMN:</b> Activation of software limit switches both directions Software limit switches can only be activated if the zero point is valid. Modified settings become active immediately.	- 0 0 3	UINT16 R/W per. -	Modbus 1542 CIP 106.1.3

### Setting Position Limits

The position limits of the software limit switches are set via the parameters `SPV_swLimP` and `SPV_swLimN`.

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
SPVswLimPusr	Positive position limit for software limit switch. If a user-defined value entered is outside of the permissible range, the limit switch limits are automatically set to the maximum user-defined value. Setting can only be modified if power stage is disabled. Modified settings become active the next time the power stage is enabled.	usr - 2147483647 -	INT32 R/W per. -	Modbus 1544 CIP 106.1.4
SPVswLimNusr	Negative position limit for software limit switch. Refer to description of parameter SPVswLimPusr. Setting can only be modified if power stage is disabled. Modified settings become active the next time the power stage is enabled.	usr - -2147483648 -	INT32 R/W per. -	Modbus 1546 CIP 106.1.5

---

## Section 8.3

### Functions for Monitoring Internal Device Signals

---

#### What Is in This Section?

This section contains the following topics:

Topic	Page
Temperature Monitoring	170
Stall Detection	171

## Temperature Monitoring

### Temperature of Power Stage

The parameter `_Temp_act_PA` contains the temperature value of the power stage.

The parameter `PA_T_warn` contains the threshold value for an error of error class 0.

The parameter `PA_T_max` contains the maximum temperature value of the power stage . If the temperature exceeds the limit value for more than five seconds, an error of error class 3 is detected.

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
<code>_Temp_act_PA</code>	Temperature of power stage.	°C - - -	INT16 R/- - -	Modbus 7200 CIP 128.1.16
<code>PA_T_warn</code>	Temperature limit of power stage for error class 0.	°C - - -	INT16 R/- per. -	Modbus 4108 CIP 116.1.6
<code>PA_T_max</code>	Maximum permissible temperature of power stage.	°C - - -	INT16 R/- per. -	Modbus 4110 CIP 116.1.7

## Stall Detection

### Description

The stall detection function monitors whether a stepper motor stalls. If a stepper motor stalls, the motor shaft is displaced in relation to the rotating magnetic field by an angle corresponding to one or several pairs of poles. One pair of poles corresponds to 1/50 of a motor shaft revolution.

Constraints:

- After the power stage is enabled, stall detection start to operate as soon as the index pulse is reached. Stalling is detected from this point on.
- If the motor stalls during deceleration immediately before reaching a standstill, this is detected when the index pulse is reached the next time. This means that this condition may only be detected during the next movement.
- If the movement range of the application is less than one motor revolution, the index pulse may be outside of the movement. In such a case, stalling of the motor is not detected.
- Stall detection does not detect rotation of the motor shaft by external forces when the motor is at a standstill.

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
CTRLS_stallDet	Stall detection via index pulse. <b>0 / Inactive:</b> Inactive <b>1 / Active:</b> Active The default value for drives with index pulse is "Active". Modified settings become active the next time the power stage is enabled.	- 0 - 1	UINT16 R/W per. -	Modbus 5146 CIP 120.1.13




# Chapter 9

## Examples

### Wiring Example

#### Overview

In the following wiring example, the limit switches and the reference switch are supplied via the internal 24 V power supply.



The UBC60 braking resistor controller is available as an accessory, refer to the chapter Accessories and Spare Parts ([see page 217](#)).



---

# Chapter 10

## Diagnostics and Troubleshooting

---

### What Is in This Chapter?

This chapter contains the following sections:

Section	Topic	Page
10.1	Diagnostics via LEDs	176
10.2	Diagnostics via the Fieldbus	179
10.3	Error Messages	188

## Section 10.1

### Diagnostics via LEDs

---

#### What Is in This Section?



This section contains the following topics:

Topic	Page
Operating State LEDs	177
Fieldbus Status LEDs	178

## Operating State LEDs

### Overview

The integrated drive has a green and a red LED on the printed circuit board. The two LEDs indicate the operating states and detected errors.




- A Operating states **1 Start** and **2 Not Ready To Switch On**
- B Operating state **3 Switch On Disabled**
- C Operating states **4 Ready To Switch On** and **5 Switched On**
- D Operating state **6 Operation Enabled**
- E Operating states **7 Quick Stop Active** and **8 Fault Reaction Active**
- F Operating state **9 Fault**
- G Firmware not available
- H Internal error

## Fieldbus Status LEDs

### Overview

The LEDs indicate the EtherNet/IP communication status of the drive and the EtherNet/IP communication status of the network.



LED	Description
1	Communication status of the drive
2	Communication status of the network

LED communication status of the drive:

LED code	Description
Steady off	No power is supplied.
Steady green	The drive is operational.
Flashing green	The drive has not been configured.
Flashing red	The drive has detected a recoverable error, for example, an incorrect configuration.
Steady red	The drive has detected a non-recoverable error.
Flashing green / red	The drive is performing a self-test.

LED communication status of the network:

LED code	Description
Steady off	The drive does not have an IP address (or is powered off).
Steady green	The drive has no established connections, but has obtained an IP address.
Flashing green	The drive has at least one connection (this includes the Message Router).
Flashing red	One or more of the connections in which this drive is the target has timed out. This status is left only if the timed out connections are reestablished or if the drive is reset.
Steady red	The drive has detected that its IP address is already in use.
Flashing green / red	The drive is performing a self-test.

---

## Section 10.2

### Diagnostics via the Fieldbus

---

#### What Is in This Section?

This section contains the following topics:

Topic	Page
Fieldbus Communication Error Diagnostics	180
Most Recent Detected Error - Status Bits	181
Most Recent Detected Error - Error Code	183
Error Memory	184
Error Response to Incorrect Realtime Ethernet Data	186
Synchronous Errors	187

## Fieldbus Communication Error Diagnostics

### Verifying Connections

A properly operating fieldbus is essential for evaluating status and error messages.

If the product cannot be addressed via the fieldbus, first verify the connections.

Verify the following connections:

- System power supply
- Supply connections
- Fieldbus cables and wiring
- Fieldbus connection

### Fieldbus Function Test

If the connections are correct, verify that you can address the product on the fieldbus.

## Most Recent Detected Error - Status Bits

### Error Bits

The parameters `_WarnLatched` and `_SigLatched` contain information on errors of error class 0 and errors of error classes 1 ... 4.

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
<code>_WarnLatched</code>	<p>Saved errors of error class 0, bit-coded. The bits are set to 0 in the case of a Fault Reset. Bits 10, 11, and 13 are set to 0 automatically.</p> <p>Signal state: 0: Not activated 1: Activated</p> <p>Bit assignments: Bit 0: General (see <code>_LastWarning</code>) Bit 1: Temperature of power stage high Bit 2: Temperature of motor high Bit 3: Reserved Bit 4: Power stage overload (<math>I^2t</math>) Bit 5: Motor overload (<math>I^2t</math>) Bit 6: Braking resistor overload (<math>I^2t</math>) Bit 7: CAN Bit 8: Motor encoder Bit 9: RS485 protocol Bit 10: Inputs STO Bit 11: DC bus undervoltage/mains phase not present Bit 12: Profibus Bit 13: Position not yet valid (position capture still running) Bit 14: Ethernet Bit 15: Reserved</p> <p>Monitoring functions are product-dependent.</p>	- - - -	UINT16 R/- - -	Modbus 7192 CIP 128.1.12

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
_SigLatched	<p>Saved status of monitoring signals.</p> <p>Signal state: 0: Not activated 1: Activated</p> <p>Bit assignments: Bit 0: General error detected Bit 1: Hardware limit switches (LIMP/LIMN/REF) Bit 2: Out of range (software limit switches, tuning) Bit 3: Quick Stop via fieldbus Bit 4: Inputs STO are 0 Bit 5: Reserved Bit 6: RS485 Bit 7: CAN Bit 8: Ethernet Bit 9: Frequency of reference signal too high Bit 10: Operating mode Bit 11: Reserved Bit 12: Profibus Bit 13: Reserved Bit 14: Undervoltage DC bus Bit 15: Overvoltage DC bus Bit 16: Mains phase Bit 17: Motor connection Bit 18: Motor overcurrent/short circuit Bit 19: Motor encoder Bit 20: Undervoltage 24VDC Bit 21: Overtemperature (power stage, motor) Bit 22: Position deviation exceeded Bit 23: Maximum velocity exceeded Bit 24: Inputs STO different Bit 25: Reserved Bit 26: Reserved Bit 27: Reserved Bit 28: Reserved Bit 29: Nonvolatile memory error Bit 30: System booting (hardware or parameter) Bit 31: System (for example, Watchdog)</p> <p>Monitoring functions are product-dependent.</p>	<p>- - - -</p>	<p>UINT32 R/- - -</p>	<p>Modbus 7184 CIP 128.1.8</p>

## Most Recent Detected Error - Error Code

### Description

If the master controller receives information concerning a detected error via the process data communication, the following parameters can be used to read the error code.

The list of the error messages sorted by error code can be found in the chapter Error Messages (*see page 188*).

### Most Recent Detected Error with Error Class 0

The parameter `_LastWarning` allows you to read the error number of the last detected error with error class 0.

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
<code>_LastWarning</code>	Code of most recent error of error class 0. If the error is no longer active, the code is stored until the next Fault Reset. Value 0: No error of error class 0	- - - -	UINT16 R/- - -	Modbus 7186 CIP 128.1.9

### Most Recent Detected Error with Error Class 1 ... 4

The parameter `_StopFault` allows you to read the error number of the last detected error with error class 1 ... 4.

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
<code>_StopFault</code>	Detected error causing a stop (error classes 1 to 4). Error code of the most recent detected error.	- - 0 -	UINT16 R/- - -	Modbus 7178 CIP 128.1.5

## Error Memory

### General

The error memory is an error history of the last 10 error messages. It is not cleared even if the product is powered off. The error memory allows you to read and evaluate past events.

The following information on the events is stored:

- Error class
- Error code
- Motor current
- Number of power on cycles
- Additional error information (for example, parameter numbers)
- Product temperature
- Power stage temperature
- Time the error was detected (with reference to operating hours counter)
- DC Bus Voltage
- Velocity
- Number of Enable cycles after powering on
- Time from Enable until detection of the error

The stored information relates to the situation at the point in time the error was detected.

The list of the error messages sorted by error code can be found in the chapter Error Messages (*see page 188*).

### Reading the Error Memory

The error memory can only be read sequentially. The parameter `FLT_MemReset` must be used to reset the read pointer. Then the first error entry can be read. The read pointer is automatically set to the next entry. A new read access delivers the next error entry. If the error code 0 is returned, there is no additional error entry.

Position of the entry	Meaning
1	First error message (oldest message).
2	Second error message (later message).
...	...
10	Tenth error message. In the case of ten error messages, the most recent error message is contained here.

An error entry consists of several pieces of information which can be read using different parameters. When you read an error entry, the error code must be read first with the parameter `_FLT_err_num`.

The following parameters allow you to manage the error memory:

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
<code>FLT_class</code>	Error class. Value 0: Error class 0 Value 1: Error class 1 Value 2: Error class 2 Value 3: Error class 3 Value 4: Error class 4	- 0 - 4	UINT16 R/- - -	Modbus 15364 CIP 160.1.2
<code>FLT_err_num</code>	Error code. Reading this parameter copies the entire entry for the detected error (error class, time of detection of error, ...) to an intermediate memory from which the elements of the detected error can then be read.  In addition, the read pointer of the error memory is automatically set to the next error entry.	- 0 - 65535	UINT16 R/- - -	Modbus 15362 CIP 160.1.1

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
FLT_Idq	Motor current at the time the error was detected. In increments of 0.01 A.	A - - -	UINT16 R/- - -	Modbus 15378 CIP 160.1.9
FLT_powerOn	Number of power on cycles.	- 0 - 4294967295	UINT32 R/- - -	Modbus 15108 CIP 159.1.2
FLT_Qual	Additional information on detected error. This entry contains additional information on the detected error, depending on the error number. Example: a parameter address	- 0 - 65535	UINT16 R/- - -	Modbus 15368 CIP 160.1.4
FLT_Temp_DEV	Temperature of device at the time the error was detected.	°C - - -	INT16 R/- - -	Modbus 15382 CIP 160.1.11
FLT_Temp_PA	Temperature of power stage at the time the error was detected.	°C - - -	INT16 R/- - -	Modbus 15380 CIP 160.1.10
FLT_Time	Error time. With reference to operating hours counter	s 0 - 536870911	UINT32 R/- - -	Modbus 15366 CIP 160.1.3
FLT_UDC	DC bus voltage at the time the error was detected. In increments of 0.1 V.	V - - -	UINT16 R/- - -	Modbus 15374 CIP 160.1.7
FLT_n	Motor velocity at the time the error was detected.	RPM - - -	INT16 R/- - -	Modbus 15376 CIP 160.1.8
FLTAmpOnCyc	Number of cycles of enabling the power stage at error time. Number of cycles of enabling the power stage from the time the power supply (control voltage) was switched on to the time the error occurred.	- - - -	UINT16 R/- - -	Modbus 15370 CIP 160.1.5
FLTAmpOnTime	Time between enabling of power stage and detection of the error.	s - - -	UINT16 R/- - -	Modbus 15372 CIP 160.1.6
FLT_MemReset	Reset error memory read pointer. Value 1: Set error memory read pointer to oldest error entry. Modified settings become active immediately.	- 0 - 1	UINT16 R/W - -	Modbus 15114 CIP 159.1.5
FLT_del_err	Clear error memory. Value 1: Delete entries in the error memory  The clearing process is completed if a 0 is returned after a read access. Modified settings become active immediately.	- 0 - 1	UINT16 R/W - -	Modbus 15112 CIP 159.1.4

## Error Response to Incorrect Realtime Ethernet Data

### Description

The parameter `EthErrBehv` allows you to set the error class for an attempt to write incorrect realtime Ethernet data.

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
<code>EthErrBehv</code>	Error class for incorrect realtime Ethernet data. <b>0 / Warning:</b> Error class 0 <b>1 / ErrorClass1:</b> Error class 1 (Quick Stop) Modified settings become active immediately.	- 0 0 1	UINT16 R/W per. -	Modbus 6412 CIP 125.1.6

## Synchronous Errors

### Error Response to Explicit Messages

If a request transmitted via an Explicit Message cannot be processed by the slave, the master receives an error message in the associated response to the Explicit Message.

This response contains two bytes:

- General error code
- Additional error code

Detected errors can be read with object 100.1.1. If the general error code has the value 1F hex, the byte “additional error code” contains vendor-specific error numbers in coded form.

### Response During I/O Connection

The slave responds to an incorrect I/O command in the next I/O response by setting bit 6 (`ME, ModeError`) in the byte `modeStat` to 1. This does not interrupt the current process. To determine the cause of the detected error, the master can read the error number with the object 100.1.1 by means of an explicit access.

The error indication is reset during the next valid data transmission.

### General Status Codes as per CIP

Refer to the “General Status Code” as defined by the ODVA in the CIP (Common Industrial Protocol), The CIP Networks Library, Volume 1, Appendix B-1.1 for information on status and error codes.

## Section 10.3

### Error Messages

---

#### What Is in This Section?

This section contains the following topics:

Topic	Page
Description of Error Messages	189
Table of Error Messages	190

## Description of Error Messages

### Description

If monitoring functions of the drive detect an error, the drive generates an error message. Each error message is identified by an error code.

The following information is available for each error message:

- Error code
- Error class
- Description of error
- Possible causes
- Possible remedies

### Range of Error Messages

The table below summarizes the error codes classified by range.

Error code	Range
E 1xxx	General
E 2xxx	Overcurrent
E 3xxx	Voltage
E 4xxx	Temperature
E 5xxx	Hardware
E 6xxx	Software
E 7xxx	Interface, wiring
E 8xxx	Fieldbus
E Axxx	Motor movement
E Bxxx	Communication

### Error Class of Error Messages

The error messages are classified according to the following error classes:

Error class	State transition <sup>1)</sup>	Error response	Resetting the error message
0	-	No interruption of the movement	Function "Fault Reset"
1	T11	Stop movement with "Quick Stop"	Function "Fault Reset"
2	T13, T14	Stop movement with "Quick Stop" and disable the power stage when the motor has come to a standstill	Function "Fault Reset"
3	T13, T14	Disable the power stage immediately without stopping the movement first	Function "Fault Reset"
4	T13, T14	Disable the power stage immediately without stopping the movement first	Power cycle
<b>(1)</b> See chapter Operating State ( <a href="#">see page 114</a> )			

## Table of Error Messages

### List of the Error Messages Sorted by Error Code

Error code (hex)	Error class	Description	Cause	Correctives
E 1100	0	Parameter out of permissible range	The value entered was outside of the permissible value range for this parameter.	The entered value must be within the permissible value range.
E 1101	0	Parameter does not exist	Error detected by parameter management: Parameter (index) does not exist.	Select a different parameter (index).
E 1102	0	Parameter does not exist	Error detected by parameter management: Parameter (subindex) does not exist.	Select a different parameter (subindex).
E 1103	0	Parameter write not permissible (read-only)	Write access to read only parameter.	Write only to parameters that are not read-only.
E 1104	0	Write access denied (no access authorization)	Parameter only accessible at expert level.	Write access level expert is required.
E 1106	0	Command not permissible while power stage is active	Command not permissible while the power stage is enabled (operating state Operation Enabled or Quick Stop Active).	Disable the power stage and repeat the command.
E 1107	0	Access via other interface blocked	Access occupied by another channel (for example: Commissioning software is active and fieldbus access was tried at the same time).	Verify the channel that blocks the access.
E 110B	3	Configuration error detected (additional info=Modbus register address) Parameter_SigLatched Bit 30	Error detected during parameter check (for example, reference velocity value for operating mode Profile Position is greater than maximum permissible velocity of drive).	Value in additional error information shows the Modbus register address of the parameter where the initialization error was detected.
E 110E	0	Parameter value modified that requires a restart of the drive	Only displayed by the commissioning software. A parameter modification requires the drive to be powered off and on.	Restart the drive to activate the parameter functionality. See the chapter Parameters for the parameter that requires a restart of the drive.
E 110F	0	Function not available for this type of device	The function or parameter value is not supported.	Verify whether you have the correct device (type of motor, type of encoder, holding brake).
E 1110	0	Function not available	-	-
E 1300	3	Safety-related function STO activated ( $\overline{STO\_A}$ , $\overline{STO\_B}$ ) Parameter_SigLatched Bit 4	The safety function STO was activated in the operating state Operation Enabled.	Verify correct wiring of the inputs of the safety-related function STO and reset the error.
E 1301	4	$\overline{STO\_A}$ and $\overline{STO\_B}$ different level Parameter_SigLatched Bit 24	The levels of the inputs $\overline{STO\_A}$ and $\overline{STO\_B}$ were different for more than 1 second.	Verify correct wiring of the inputs of the safety-related function STO.
E 1312	0	Limit switch or reference switch signal not defined for signal input function	Reference movements require limit switches. These limit switches are not assigned to inputs.	Assign the signal input functions Positive Limit Switch, Negative Limit Switch and Reference Switch.
E 2300	3	Power stage overcurrent Parameter_SigLatched Bit 18	Motor short circuit and disabling of the power stage. Motor phases are inverted.	Verify correct motor power connection.
E 3200	3	DC bus overvoltage Parameter_SigLatched Bit 15	Excessive regeneration during braking.	Verify correct deceleration ramp, rating of drive and braking resistor.
E 3201	3	DC bus undervoltage (shutdown threshold) Parameter_SigLatched Bit 14	Power outage, insufficient power supply.	Verify mains supply.
E 3202	2	DC bus undervoltage (Quick Stop threshold) Parameter_SigLatched Bit 14	Power outage, insufficient power supply.	Verify mains supply.

Error code (hex)	Error class	Description	Cause	Correctives
E 4100	3	Power stage overtemperature Parameter <code>_SigLatched</code> Bit 21	Transistors overtemperature: Ambient temperature is too high, fan is inoperative, dust.	Verify the fan, improve the heat dissipation in the cabinet.
E 4101	0	Power stage overtemperature (error class 0) Parameter <code>_WarnLatched</code> Bit 1	Transistors overtemperature: Ambient temperature is too high, fan is inoperative, dust.	Verify the fan, improve the heat dissipation in the cabinet.
E 4302	0	Motor overload (I2t) (error class 0) Parameter <code>_WarnLatched</code> Bit 5	The current has exceeded the nominal value for an extended period of time.	-
E 610D	0	Error detected in selection parameter	Incorrect parameter value selected.	Verify the value to be written.
E 7328	4	Motor encoder: Position evaluation error detected Parameter <code>_SigLatched</code> Bit 19	-	Contact your Schneider Electric representative or replace the motor.
E 7329	0	Motor encoder error detected (error class 0) Parameter <code>_WarnLatched</code> Bit 8	EMI, encoder signals internal error detected.	Contact your Schneider Electric representative or replace the motor.
E 7500	0	RS485/Modbus: Overflow error detected Parameter <code>_WarnLatched</code> Bit 9	EMI; incorrect wiring.	Verify cables.
E 7501	0	RS485/Modbus: Framing error detected Parameter <code>_WarnLatched</code> Bit 9	EMI; incorrect wiring.	Verify cables.
E 7502	0	RS485/Modbus: Parity error detected Parameter <code>_WarnLatched</code> Bit 9	EMI; incorrect wiring.	Verify cables.
E 7503	0	RS485/Modbus: Receive error detected Parameter <code>_WarnLatched</code> Bit 9	EMI; incorrect wiring.	Verify cables.
E A300	0	Deceleration after HALT request still active	HALT was removed too soon. New command was sent before motor standstill was reached after a HALT request.	Wait for complete stop before removing HALT signal. Wait until motor has come to a complete standstill.
E A301	0	Drive in operating state Quick Stop Active	Error with error class 1 was detected. Drive stopped with Quick Stop command.	-
E A302	1	Stop by positive limit switch Parameter <code>_SigLatched</code> Bit 1	The positive limit switch was activated because movement range was exceeded, incorrect of limit switch or signal disturbance.	Verify application. Verify correct limit switch function and connection.
E A303	1	Stop by negative limit switch Parameter <code>_SigLatched</code> Bit 1	The negative limit switch was activated because movement range was exceeded, incorrect operation of limit switch or signal disturbance.	Verify application. Verify correct limit switch function and connection.
E A305	0	Power stage cannot be enabled in the operating state Not Ready To Switch On	Fieldbus: An attempt was made to enable the power stage in the operating state Not Ready To Switch On.	Refer to the state diagram.
E A306	1	Stop by user-initiated software stop Parameter <code>_SigLatched</code> Bit 3	Drive is in operating state Quick Stop Active due to a software stop request. The activation of a new operating mode is not possible, the error code is sent as the response to the activation command.	Perform a Fault Reset.
E A307	0	Stop by internal software stop	In the operating modes Homing and Jog, the movement is internally interrupted by an internal software stop. The activation of a new operating mode is not possible, the error code is sent as the response to the activation command.	Perform a Fault Reset.

Error code (hex)	Error class	Description	Cause	Correctives
E A308	0	Drive is in operating state Fault or Fault Reaction Active	Error with error class 2 or higher detected.	Read the error code (HMI or commissioning software), remove error condition and perform a Fault Reset.
E A309	0	Drive not in operating state Operation Enabled	A command was sent that requires the drive to be in the operating state Operation Enabled (for example, a command to activate a different operating mode).	Set drive to operating state Operation Enabled and repeat the command.
E A310	0	Power stage not enabled	Command cannot be used because the power stage is not enabled (operating state Operation Enabled or Quick Stop Active).	Set drive to an operating state in which the power stage is enabled, refer to the state diagram.
E A313	0	Movement range limits were exceeded, zero point is no longer valid (ref_ok=0)	The movement range limits were exceeded and the zero point is no longer valid. An absolute movement requires a valid zero point.	Define a new zero point by means of the operating mode Homing.
E A314	0	No valid zero point	Command needs a defined zero point (ref_ok=1).	Define a new zero point by means of the operating mode Homing.
E A315	0	Homing active	Command cannot be used while the operating mode Homing is active.	Wait until reference movement is finished.
E A317	0	Motor is not at a standstill	Command sent which is not permissible when the motor is not at a standstill. For example: - Modification to software limit switches - Modification to handling of monitoring signals - Setting of zero point - Teach in of data set	Wait until the motor has come to a standstill (x_end = 1).
E A318	0	Operating mode active (x_end=0)	Activation of a new operating mode is not possible while the current operating mode is still active.	Wait until the command in the operating mode has finished (x_end=1) or terminate active operating mode with HALT command.
E A31B	0	HALT requested	Command not permissible while a HALT is requested.	Clear HALT request and repeat command.
E A31C	0	Invalid position setting with software limit switch	Value for negative (positive) software limit switch is greater (less) than value for positive (negative) software limit switch.	Set correct position values.
E A31D	0	Velocity range exceeded (CTRL_n_max)	The velocity was set to a value greater than the maximum permissible velocity in parameter CTRL_n_max.	Increase the value of parameter CTRL_n_max or reduce the velocity value.
E A31E	1	Stop by positive software limit switch Parameter_SigLatched Bit 2	Not possible to execute command because positive software limit switch was triggered.	Return to the permissible movement range.
E A31F	1	Stop by negative software limit switch Parameter_SigLatched Bit 2	Not possible to execute command because negative software limit switch was triggered.	Return to the permissible movement range.
E A324	1	Error detected during homing (additional info = detailed error number) Parameter_SigLatched Bit 10	Homing movement was stopped in response to a detected error, the detailed reason is indicated by the additional info in the error memory.	Possible sub-error codes: E A325, E A326, E A327, E A328 or E A329.
E A325	1	Limit switch to be approached not enabled Parameter_SigLatched Bit 10	Homing to positive limit switch or negative limit switch is disabled.	Enable limit switch via 'IOsigLimP' or 'IOsigLimN'.
E A326	1	Reference switch not found between positive limit switch and negative limit switch Parameter_SigLatched Bit 10	Reference switch inoperative or not correctly connected.	Verify correct operation and wiring of the reference switch.

Error code (hex)	Error class	Description	Cause	Correctives
E A327	1	Reference movement to reference switch without reversal of direction results in triggering of limit switch Parameter <code>_SigLatched</code> Bit 10	Search for reference switch without reversal of direction in positive (negative) direction with positive limit switch (negative limit switch) triggered.	Verify correct operation and wiring of the positive limit switch (negative limit switch).
E A328	1	Reference movement to reference switch without reversal of direction results in triggering of limit switch Parameter <code>_SigLatched</code> Bit 10	Search of reference switch without reversal of direction with limit switch or reference switch triggered.	Reduce velocity for reference movement (parameter <code>HMn</code> ) or increase deceleration (parameter <code>RAMPdecel</code> ). Verify correction operation and wiring of positive limit switch, negative limit switch and reference switch.
E A329	1	More than one signal positive limit switch/negative limit switch/reference switch signal active Parameter <code>_SigLatched</code> Bit 10	Reference switch or limit switch not connected correctly or supply voltage for switches too low.	Verify correct wiring and 24 VDC supply voltage.
E A32A	1	Positive limit switch triggered with negative direction of movement Parameter <code>_SigLatched</code> Bit 10	Start reference movement with negative direction (for example, reference movement to negative limit switch) and activate the positive limit switch (switch in opposite direction of movement).	Verify correct connection and operation of limit switch. Activate a jog movement with negative movement (target limit switch must be connected to the negative limit switch).
E A32B	1	Negative limit switch triggered with positive direction of movement Parameter <code>_SigLatched</code> Bit 10	Start reference movement with positive direction (for example, reference movement to positive limit switch) and activate the negative limit switch (switch in opposite direction of movement).	Verify correct connection and operation of limit switch. Activate a jog movement with positive movement (target limit switch must be connected to the positive limit switch).
E A32C	1	Reference switch error detected (switch signal briefly enabled or switch overtraveled) Parameter <code>_SigLatched</code> Bit 10	Switch signal disturbance. Motor subjected to vibration or shock when stopped after activation of the switch signal.	Verify correct supply voltage, wiring and operation of switch. Verify motor response after stopping and optimize control loop settings.
E A32D	1	Positive limit switch error detected (switch signal briefly enabled or switch overtraveled) Parameter <code>_SigLatched</code> Bit 10	Switch signal disturbance. Motor subjected to vibration or shock when stopped after activation of the switch signal.	Verify correct supply voltage, wiring and operation of switch. Verify motor response after stopping and optimize control loop settings.
E A32E	1	Negative limit switch error detected (switch signal briefly enabled or switch overtraveled) Parameter <code>_SigLatched</code> Bit 10	Switch signal disturbance. Motor subjected to vibration or shock when stopped after activation of the switch signal.	Verify correct supply voltage, wiring and operation of switch. Verify motor response after stopping and optimize control loop settings.
E A330	0	Reference movement to index pulse cannot be reproduced. Index pulse is too close to the switch	The position difference between the index pulse and the switching point is insufficient.	Increase the distance between the index pulse and the switching point. If possible, the distance between the index pulse and the switching point should be a half motor revolution.
E A332	1	Error detected in operating mode Jog (additional info = detailed error number) Parameter <code>_SigLatched</code> Bit 10	Jog movement was stopped in response to a detected error.	For additional info, see the detailed error number in the error memory.
E A337	0	Operating mode cannot be continued Parameter <code>_WarnLatched</code> Bit 10	Continuation of interrupted movement in operating mode Profile Position is not possible because another operating mode had been active in the meantime. In the operating mode Motion Sequence, continuation is not possible if a motion blend was interrupted.	Restart the operating mode.
E A33A	0	No valid zero point ( <code>ref_ok=0</code> )	No zero point defined by means of operating mode Homing. Zero point no longer valid due to movement beyond permissible movement range.	Use operating mode Homing to define a valid zero point. Use motor with multturn encoder (does not require homing).

Error code (hex)	Error class	Description	Cause	Correctives
E A33B	3	Motor stalled or external load is too high. Parameter _SigLatched Bit 22	Brushless DC motor: Stall detection with parameter SPV_t_block. Stepper motor: Stall detection with index pulse detected a deviation of magnetic field and rotor angle.	Reduce acceleration/deceleration values. Reduce load. Verify correct motor current settings.
E A346	0	Motor has no index pulse	-	-
E B100	0	RS485/Modbus: Indeterminable service Parameter _WarnLatched Bit 9	Unsupported Modbus service was received.	Verify application on the Modbus master.
E B200	0	RS485/Modbus: Protocol error detected Parameter _WarnLatched Bit 9	Logical protocol error detected: Incorrect length or unsupported subfunction.	Verify application on the Modbus master.
E B201	2	RS485/Modbus: Nodeguard error detected Parameter _SigLatched Bit 6	Connection monitoring (parameter MBnode_guard) is $\neq$ 0 ms and a nodeguard event was detected.	Verify application on the Modbus master or modify value (set to 0 ms or increase the value of the parameter MBnode_guard monitoring time).
E B202	0	RS485/Modbus: Nodeguard alert Parameter _WarnLatched Bit 9	Connection monitoring (parameter MBnode_guard) is $\neq$ 0 ms and a nodeguard event was detected.	Verify application on the Modbus master or modify value (set to 0 ms or increase the value of the parameter MBnode_guard monitoring time).
E B600	4	Ethernet: Initialization error detected Parameter _SigLatched Bit 8	-	-
E B601	1	Ethernet: Realtime data error detected Parameter _SigLatched Bit 8	-	-
E B602	0	Ethernet: Realtime data alert Parameter _WarnLatched Bit 14	-	-
E B603	2	Ethernet: Protocol error detected Parameter _SigLatched Bit 8	Can be caused by a connection timeout or an interruption of the Ethernet link.	Verify wiring, network devices and master controller connection.
E B604	0	Ethernet: Protocol-related alert Parameter _WarnLatched Bit 14	-	-
E B605	2	Indeterminable Ethernet error detected Parameter _SigLatched Bit 8	-	-
E B607	0	Ethernet: Another request is currently being processed Parameter _WarnLatched Bit 14	-	-
E B608	2	Ethernet: Realtime Hot-Reset Parameter _SigLatched Bit 8	An NMT Reset was sent while the power stage was enabled. A Modbus TCP channel was reset while the power stage was enabled.	-
E B609	2	Ethernet: Realtime Hot-Stop Parameter _SigLatched Bit 8	-	-
E B60A	0	Ethernet: Timeout in internal communication Parameter _WarnLatched Bit 14	-	-
E B60B	0	Ethernet: Error detected in internal communication Parameter _WarnLatched Bit 14	-	-
E B60C	4	Ethernet Module Incompatible Parameter _SigLatched Bit 8	The firmware of the drive is not compatible with the communication firmware of the Ethernet module.	-

---

# Chapter 11

## Parameters

---

### What Is in This Chapter?

This chapter contains the following topics:

Topic	Page
Representation of the Parameters	196
List of Parameters	198

## Representation of the Parameters

### Description

This chapter provides an overview of the parameters which can be used for operating the product. Unsuitable parameter values or unsuitable data may trigger unintended movements, trigger signals, damage parts and disable monitoring functions. Some parameter values or data do not become active until after a restart.

 <b>WARNING</b>
<p><b>UNINTENDED EQUIPMENT OPERATION</b></p> <ul style="list-style-type: none"> <li>● Only start the system if there are no persons or obstructions in the zone of operation.</li> <li>● Do not operate the drive system with undetermined parameter values or data.</li> <li>● Never modify a parameter value unless you fully understand the parameter and all effects of the modification.</li> <li>● Restart the drive and verify the saved operational data and/or parameter values after modifications.</li> <li>● Carefully run tests for all operating states and potential error situations when commissioning, upgrading or otherwise modifying the operation of the drive.</li> <li>● Verify the functions after replacing the product and also after making modifications to the parameter values and/or other operational data.</li> </ul> <p><b>Failure to follow these instructions can result in death, serious injury, or equipment damage.</b></p>

### Overview

The way parameters are shown provides information required for unique identification, the default values and the properties of a parameter.

Structure of the parameter representation:

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
ABCDE	Short description Selection values <b>1 / Abc1</b> : Explanation 1 <b>2 / Abc2</b> : Explanation 2 Description and details	A 0.00 3.00 300.00	UINT32 R/W per. -	Fieldbus 1234

#### Field "Parameter Name"

The parameter name uniquely identifies a parameter.

#### Field "Description"

Short description:

Provides a short description of the parameter.

Selection values:

In the case of parameters which offer a selection of settings, the value to be entered via the fieldbus and the designation of the value for entry via the commissioning software are specified.

**1** = Value for input via fieldbus

**Abc1** = Entry in the drop-down menu of the commissioning software

Description and details:

Provides further information on the parameter.

#### Field "Unit"

The unit of the value.

#### Field "Minimum Value"

The minimum value which can be entered.

**Field "Factory Settings"**

Settings when the product is shipped.

**Field "Maximum Value"**

The maximum value which can be entered.

**Field "Data Type"**

If the minimum and the maximum values are not explicitly indicated, the valid range of values is determined by the data type.

Data type	Minimum value	Maximum value
INT8	-128	127
UINT8	0	255
INT16	-32768	32767
UINT16	0	65535
INT32	-2147483648	2147483647
UINT32	0	4294967295

**Field "R/W"**

Indicates read and/or write values.

"R/" values can only be read.

"R/W" values can be read and written.

**Field "Persistent"**

"per." indicates whether the value of the parameter remains in the nonvolatile memory after the drive is powered off.

When a value of a persistent parameter is modified via the commissioning software or the fieldbus, you must explicitly store the modified value in the nonvolatile memory.

**Field "Expert"**

The value of parameters with "expert" can only be modified in Expert mode of the commissioning software. Expert mode requires access to the commissioning software via a password.

**Field "Parameter Address"**

Each parameter has a unique parameter address. The parameter address is used to access the parameter via the fieldbus.

**Decimal Numbers Entered via the Fieldbus**

Please note that parameter values are entered via the fieldbus without a decimal point. All decimal places must be entered.

Input examples:

Value	Commissioning software	Fieldbus
20	20	20
5.0	5.0	50
23.57	23.57	2357
1.000	1.000	1000

## List of Parameters

### List of the Parameters Sorted by Parameter Name

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
_acc_pref	Acceleration of reference value for profile generator. Sign according to the changed velocity value:  Increased velocity: Positive sign Reduced velocity: Negative sign	RPM/s - - -	INT32 R/- - -	Modbus 7954 CIP 131.1.9
_AccessInfo	Access channel information. Low byte: Exclusive access Value 0: No Value 1: Yes  High byte: Access channel Value 0: Reserved Value 1: I/O Value 2: HMI Value 3: Modbus RS485 Value 4: CANopen Value 5: CANopen via second SDO channel Value 6: Profibus Value 7: DeviceNet Value 8: Reserved Value 9: Ethernet Values 10 ... 15: Modbus TCP	- - - -	UINT16 R/- - -	Modbus 280 CIP 101.1.12
_actionStatus	Action word. Signal state: 0: Not activated 1: Activated  Bit 0: Error class 0 Bit 1: Error class 1 Bit 2: Error class 2 Bit 3: Error class 3 Bit 4: Error class 4 Bit 5: Reserved Bit 6: Motor is at standstill ( $\_n\_act < 9$ RPM) Bit 7: Motor movement in positive direction Bit 8: Motor movement in negative direction Bit 9: Reserved Bit 10: Reserved Bit 11: Profile generator idle (reference velocity is 0) Bit 12: Profile generator decelerates Bit 13: Profile generator accelerates Bit 14: Profile generator moves at constant speed Bit 15: Reserved	- - - -	UINT16 R/- - -	Modbus 7176 CIP 128.1.4
_ethMacAdr1	Ethernet MAC address part 1. Bytes 1 ... 2 of the MAC address ( XX-XX-__-__-__-__ ) XX are the bytes used. Example: MAC address: 11-22-33-44-55-66 The value stored in this case is 00001122h.	- - 0 -	UINT32 R/- - -	Modbus 6672 CIP 126.1.8
_ethMacAdr2	Ethernet MAC address part 2. Bytes 3 ... 6 of the MAC address ( __-__-XX-XX-XX-XX ) XX are the bytes used. Example: MAC address: 11-22-33-44-55-66 The value stored in this case is 33445566h.	- - - -	UINT32 R/- - -	Modbus 6674 CIP 126.1.9

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
_IO_LIO_act	Status of digital inputs/outputs. Coding of the individual signals: Bit 0: LIO1 Bit 1: LIO2 ...	- - - -	UINT16 R/- - -	Modbus 2090 CIP 108.1.21
_IO_STO_con	Status of the inputs for the safety-related function STO. <b>0 / Not Available:</b> Inputs not available <b>1 / Not Connected:</b> Inputs available, but not connected (jumped) <b>3 / Connected:</b> Inputs available and connected (safety-related function STO active)	- 0 - 3	UINT16 R/- - -	Modbus 2088 CIP 108.1.20
_LastWarning	Code of most recent error of error class 0. If the error is no longer active, the code is stored until the next Fault Reset. Value 0: No error of error class 0	- - - -	UINT16 R/- - -	Modbus 7186 CIP 128.1.9
_n_act	Actual velocity of motor.	RPM - - -	INT16 R/- - -	Modbus 7696 CIP 130.1.8
_n_actRAMP	Actual velocity of profile generator.	RPM - - -	INT32 R/- - -	Modbus 7948 CIP 131.1.6
_n_pref	Velocity of reference value for profile generator.	RPM - - -	INT32 R/- - -	Modbus 7950 CIP 131.1.7
_n_targetRAMP	Target velocity of profile generator.	RPM - - -	INT32 R/- - -	Modbus 7946 CIP 131.1.5
_OpHours	Operating hours counter.	s - - -	UINT32 R/- - -	Modbus 7188 CIP 128.1.10
_p_act	Actual position in internal units.	Inc - - -	INT32 R/- - -	Modbus 7700 CIP 130.1.10
_p_actRAMPusr	Actual position of profile generator.	usr - - -	INT32 R/- - -	Modbus 7940 CIP 131.1.2
_p_actusr	Actual position in user-defined units.	usr - - -	INT32 R/- - -	Modbus 7706 CIP 130.1.13
_p_ref	Reference position in internal units.	Inc - - -	INT32 R/- - -	Modbus 7698 CIP 130.1.9
_p_refusr	Reference position in user-defined units.	usr - - -	INT32 R/- - -	Modbus 7704 CIP 130.1.12
_p_tarRAMPusr	Target position of profile generator. Absolute position value of the profile generator, calculated on the basis of the relative and absolute position values received.	usr - - -	INT32 R/- - -	Modbus 7938 CIP 131.1.1

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
_prgNoCOM	Program number of communication module. Example: PR840.1 The value is provided as a decimal value: 8401	- - - -	UINT16 R/- - -	Modbus 6676 CIP 126.1.10
_prgNoDEV	Firmware number of device. Example: PR840.1 The value is provided as a decimal value: 8401	- - - -	UINT16 R/- - -	Modbus 258 CIP 101.1.1
_prgVerCOM	Firmware version of communication module. Example: V4.201 The value is provided as a decimal value: 4201	- - - -	UINT16 R/- - -	Modbus 6678 CIP 126.1.11
_prgVerDEV	Firmware version of device. Example: V4.201 The value is provided as a decimal value: 4201	- - - -	UINT16 R/- - -	Modbus 260 CIP 101.1.2
_serialNoDEV	Device serial number. Unique number for identification of the product Setting can only be modified if power stage is disabled.	- 0 - 4294967295	UINT32 R/- per. -	Modbus 302 CIP 101.1.23
_SigActive	Status of monitoring signals. See parameter _SigLatched for more details on the bit codes.	- - - -	UINT32 R/- - -	Modbus 7182 CIP 128.1.7
_SigLatched	Saved status of monitoring signals. Signal state: 0: Not activated 1: Activated  Bit assignments: Bit 0: General error detected Bit 1: Hardware limit switches (LIMP/LIMN/REF) Bit 2: Out of range (software limit switches, tuning) Bit 3: Quick Stop via fieldbus Bit 4: Inputs STO are 0 Bit 5: Reserved Bit 6: RS485 Bit 7: CAN Bit 8: Ethernet Bit 9: Frequency of reference signal too high Bit 10: Operating mode Bit 11: Reserved Bit 12: Profibus Bit 13: Reserved Bit 14: Undervoltage DC bus Bit 15: Overvoltage DC bus Bit 16: Mains phase Bit 17: Motor connection Bit 18: Motor overcurrent/short circuit Bit 19: Motor encoder Bit 20: Undervoltage 24VDC Bit 21: Overtemperature (power stage, motor) Bit 22: Position deviation exceeded Bit 23: Maximum velocity exceeded Bit 24: Inputs STO different Bit 25: Reserved Bit 26: Reserved Bit 27: Reserved Bit 28: Reserved Bit 29: Nonvolatile memory error Bit 30: System booting (hardware or parameter) Bit 31: System (for example, Watchdog)  Monitoring functions are product-dependent.	- - - -	UINT32 R/- - -	Modbus 7184 CIP 128.1.8

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
_StopFault	Detected error causing a stop (error classes 1 to 4). Error code of the most recent detected error.	- - 0 -	UINT16 R/- - -	Modbus 7178 CIP 128.1.5
_Temp_act_PA	Temperature of power stage.	°C - - -	INT16 R/- - -	Modbus 7200 CIP 128.1.16
_UDC_act	Voltage at DC bus. Supply voltage VDC. In increments of 0.1 V.	V - - -	UINT16 R/- - -	Modbus 7198 CIP 128.1.15
_UserAppMem1	User-specific data 1. This parameter can be used to store user-specific data.	- - 0 -	UINT32 R/W per. -	Modbus 318 CIP 101.1.31
_UserAppMem2	User-specific data 2. This parameter can be used to store user-specific data.	- - 0 -	UINT32 R/W per. -	Modbus 320 CIP 101.1.32
_UserAppMem3	User-specific data 3. This parameter can be used to store user-specific data.	- - 0 -	UINT32 R/W per. -	Modbus 322 CIP 101.1.33
_UserAppMem4	User-specific data 4. This parameter can be used to store user-specific data.	- - 0 -	UINT32 R/W per. -	Modbus 324 CIP 101.1.34
_VoltUtil	Degree of utilization of DC bus voltage. With a value of 100 %, the drive operates at the voltage limit.	% - - -	INT16 R/- - -	Modbus 7718 CIP 130.1.19
_WarnActive	Active errors of error class 0, bit-coded. See parameter _WarnLatched for more details on the bits.	- - - -	UINT16 R/- - -	Modbus 7190 CIP 128.1.11

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
_WarnLatched	<p>Saved errors of error class 0, bit-coded. The bits are set to 0 in the case of a Fault Reset. Bits 10, 11, and 13 are set to 0 automatically.</p> <p>Signal state: 0: Not activated 1: Activated</p> <p>Bit assignments: Bit 0: General (see _LastWarning) Bit 1: Temperature of power stage high Bit 2: Temperature of motor high Bit 3: Reserved Bit 4: Power stage overload (I<sup>2</sup>t) Bit 5: Motor overload (I<sup>2</sup>t) Bit 6: Braking resistor overload (I<sup>2</sup>t) Bit 7: CAN Bit 8: Motor encoder Bit 9: RS485 protocol Bit 10: Inputs STO Bit 11: DC bus undervoltage/mains phase not present Bit 12: Profibus Bit 13: Position not yet valid (position capture still running) Bit 14: Ethernet Bit 15: Reserved</p> <p>Monitoring functions are product-dependent.</p>	- - - -	UINT16 R/- - -	Modbus 7192 CIP 128.1.12
AbsHomeRequest	<p>Absolute positioning only after homing. <b>0 / No:</b> No <b>1 / Yes:</b> Yes Modified settings become active immediately.</p>	- 0 0 1	UINT16 R/W per. -	Modbus 1580 CIP 106.1.22
AccessLock	<p>Locking other access channels. Value 0: Allow control via other access channels Value 1: Lock control via other access channels</p> <p>With this parameter, the fieldbus can lock active access to the device via the following access channels: - Input signals - Commissioning software</p> <p>Processing of the input signal HALT cannot be locked. Modified settings become active immediately.</p>	- 0 - 1	UINT16 R/W - -	Modbus 316 CIP 101.1.30
BRK_release	<p>Manual operation of the holding brake. <b>0 / Close:</b> Automatic processing <b>1 / Open:</b> Manual release of holding brake The holding brake can only be manually released in the operating states Switch On Disabled or Ready To Switch On.</p> <p>If the power stage is enabled, the value is automatically set to 0. Modified settings become active immediately.</p>	- 0 0 1	UINT16 R/W - -	Modbus 2068 CIP 108.1.10
BRK_status	<p>Status of holding brake. Value 0: Applied Value 1: Released Value 2: Not available Modified settings become active immediately.</p>	- 0 0 2	UINT16 R/- - -	Modbus 2070 CIP 108.1.11

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
Cap1Activate	Capture input 1 start/stop. <b>0 / Capture stop:</b> Cancel capture function <b>1 / Capture once:</b> Start one-time capture <b>2 / Capture continuous:</b> Start continuous capture In the case of one-time capture, the function is terminated when the first value is captured. In the case of continuous capture, the function continues to run. Modified settings become active immediately.	- 0 - 2	UINT16 R/W - -	Modbus 2568 CIP 110.1.4
Cap1Config	Capture input 1 configuration. <b>0 / 1-&gt;0:</b> Position capture at falling edge <b>1 / 0-&gt;1:</b> Position capture at rising edge Modified settings become active immediately.	- 0 0 1	UINT16 R/W - -	Modbus 2564 CIP 110.1.2
Cap1Count	Capture input 1 event counter. Counts the capture events. The event counter is reset when capture input 1 is activated.	- - - -	UINT16 R/- - -	Modbus 2576 CIP 110.1.8
Cap1Pos	Capture input 1 captured position. Captured position at the time of the "capture signal". The captured position is re-calculated after "Position Setting" or "Reference Movement".	usr - - -	INT32 R/- - -	Modbus 2572 CIP 110.1.6
Cap2Activate	Capture input 2 start/stop. <b>0 / Capture stop:</b> Cancel capture function <b>1 / Capture once:</b> Start one-time capture <b>2 / Capture continuous:</b> Start continuous capture In the case of one-time capture, the function is terminated when the first value is captured. In the case of continuous capture, the function continues to run. Modified settings become active immediately.	- 0 - 2	UINT16 R/W - -	Modbus 2570 CIP 110.1.5
Cap2Config	Capture input 2 configuration. <b>0 / 1-&gt;0:</b> Position capture at falling edge <b>1 / 0-&gt;1:</b> Position capture at rising edge Modified settings become active immediately.	- 0 0 1	UINT16 R/W - -	Modbus 2566 CIP 110.1.3
Cap2Count	Capture input 2 event counter. Counts the capture events. The event counter is reset when capture unit 2 is activated.	- - - -	UINT16 R/- - -	Modbus 2578 CIP 110.1.9
Cap2Pos	Capture input 2 captured position. Captured position at the time of the "capture signal". The captured position is re-calculated after "Position Setting" or "Reference Movement".	usr - - -	INT32 R/- - -	Modbus 2574 CIP 110.1.7
CapStatus	Status of the capture inputs. Read access: Bit 0: Position captured via input CAP1 Bit 1: Position captured via input CAP2	- - - -	UINT16 R/- - -	Modbus 2562 CIP 110.1.1
CTRLS_I_Const%	Percentage of phase current during constant movement. 100 % correspond to the value in SM_I_nom. Modified settings become active immediately.	% 1 100 100	UINT16 R/W per. -	Modbus 5144 CIP 120.1.12
CTRLS_I_Ramp%	Percentage of phase current during acceleration/deceleration. 100 % correspond to the value in SM_I_nom. Modified settings become active immediately.	% 1 100 100	UINT16 R/W per. -	Modbus 5142 CIP 120.1.11
CTRLS_I_Stand%	Percentage of phase current at standstill. 100 % correspond to the value in SM_I_nom. Modified settings become active immediately.	% 1 70 100	UINT16 R/W per. -	Modbus 5140 CIP 120.1.10

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
CTRLS_stallDet	Stall detection via index pulse. <b>0 / Inactive:</b> Inactive <b>1 / Active:</b> Active The default value for drives with index pulse is "Active". Modified settings become active the next time the power stage is enabled.	- 0 - 1	UINT16 R/W per. -	Modbus 5146 CIP 120.1.13
CTRLS_toggle	Toggle of motor when power stage is enabled. <b>0 / Inactive:</b> Inactive <b>1 / Active:</b> Active Modified settings become active immediately.	- - - -	UINT16 R/W per. -	Modbus 5136 CIP 120.1.8
EthErrBehv	Error class for incorrect realtime Ethernet data. <b>0 / Warning:</b> Error class 0 <b>1 / ErrorClass1:</b> Error class 1 (Quick Stop) Modified settings become active immediately.	- 0 0 1	UINT16 R/W per. -	Modbus 6412 CIP 125.1.6
EthGateway	Stored Ethernet network gateway. Default is 192.168.100.254 Modified settings become active the next time the product is powered on.	- - - -	UINT32 R/W per. -	Modbus 6662 CIP 126.1.3
EthGatewayAct	Ethernet network gateway used. Default is 192.168.100.254	- - - -	UINT32 R/- - -	Modbus 6668 CIP 126.1.6
EthIpAddr	Stored IP address. Default is 192.168.100.10 Modified settings become active the next time the product is powered on.	- - - -	UINT32 R/W per. -	Modbus 6658 CIP 126.1.1
EthIpAddrAct	IP address used.	- - - -	UINT32 R/- - -	Modbus 6664 CIP 126.1.4
EthIPConfInfo	IP configuration information. <b>2000 / Device Name:</b> Device Name <b>2001 / Bootp:</b> Bootp <b>2002 / Stored:</b> Stored in nonvolatile memory <b>2003 / Build from MAC:</b> Build from MAC <b>2004 / EtherNet/IP default:</b> EtherNet/IP default <b>2005 / Powerlink:</b> Powerlink <b>2006 / EtherCAT:</b> EtherCAT The IP configuration can be set with the switches in the connector housing.	- 0 - 65535	UINT16 R/- - -	Modbus 6694 CIP 126.1.19
EthSubMask	Stored subnet mask. Default is 255.255.255.0 Modified settings become active the next time the product is powered on.	- - - -	UINT32 R/W per. -	Modbus 6660 CIP 126.1.2
EthSubMaskAct	Subnet mask used. Default is 255.255.255.0	- - - -	UINT32 R/- - -	Modbus 6666 CIP 126.1.5
FLT_class	Error class. Value 0: Error class 0 Value 1: Error class 1 Value 2: Error class 2 Value 3: Error class 3 Value 4: Error class 4	- 0 - 4	UINT16 R/- - -	Modbus 15364 CIP 160.1.2
FLT_del_err	Clear error memory. Value 1: Delete entries in the error memory  The clearing process is completed if a 0 is returned after a read access. Modified settings become active immediately.	- 0 - 1	UINT16 R/W - -	Modbus 15112 CIP 159.1.4

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
FLT_err_num	Error code. Reading this parameter copies the entire entry for the detected error (error class, time of detection of error, ...) to an intermediate memory from which the elements of the detected error can then be read.  In addition, the read pointer of the error memory is automatically set to the next error entry.	- 0 - 65535	UINT16 R/- - -	Modbus 15362 CIP 160.1.1
FLT_Idq	Motor current at the time the error was detected. In increments of 0.01 A.	A - - -	UINT16 R/- - -	Modbus 15378 CIP 160.1.9
FLT_MemReset	Reset error memory read pointer. Value 1: Set error memory read pointer to oldest error entry. Modified settings become active immediately.	- 0 - 1	UINT16 R/W - -	Modbus 15114 CIP 159.1.5
FLT_n	Motor velocity at the time the error was detected.	RPM - - -	INT16 R/- - -	Modbus 15376 CIP 160.1.8
FLT_powerOn	Number of power on cycles.	- 0 - 4294967295	UINT32 R/- - -	Modbus 15108 CIP 159.1.2
FLT_Qual	Additional information on detected error. This entry contains additional information on the detected error, depending on the error number. Example: a parameter address	- 0 - 65535	UINT16 R/- - -	Modbus 15368 CIP 160.1.4
FLT_Temp_DEV	Temperature of device at the time the error was detected.	°C - - -	INT16 R/- - -	Modbus 15382 CIP 160.1.11
FLT_Temp_PA	Temperature of power stage at the time the error was detected.	°C - - -	INT16 R/- - -	Modbus 15380 CIP 160.1.10
FLT_Time	Error time. With reference to operating hours counter	s 0 - 536870911	UINT32 R/- - -	Modbus 15366 CIP 160.1.3
FLT_UDC	DC bus voltage at the time the error was detected. In increments of 0.1 V.	V - - -	UINT16 R/- - -	Modbus 15374 CIP 160.1.7
FLTAmpOnCyc	Number of cycles of enabling the power stage at error time. Number of cycles of enabling the power stage from the time the power supply (control voltage) was switched on to the time the error occurred.	- - - -	UINT16 R/- - -	Modbus 15370 CIP 160.1.5
FLTAmpOnTime	Time between enabling of power stage and detection of the error.	s - - -	UINT16 R/- - -	Modbus 15372 CIP 160.1.6
HMdisREFTtoIDX	Distance from switching point to index pulse. Allows you to verify the distance between the index pulse and the switching point and serves as a criterion for determining whether the reference movement with index pulse can be reproduced. In increments of 0.0001 revolution.	revolution - - -	INT32 R/- - -	Modbus 10264 CIP 140.1.12

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
HMdisusr	Distance from switching point. The distance from the switching point is defined as the reference point.  The parameter is only effective during a reference movement without index pulse. Modified settings become active the next time the motor moves.	usr 1 200 2147483647	INT32 R/W per. -	Modbus 10254 CIP 140.1.7
HMmethod	Homing method. 1: LIMN with index pulse 2: LIMP with index pulse 7: REF+ with index pulse, inv., outside 8: REF+ with index pulse, inv., inside 9: REF+ with index pulse, not inv., inside 10: REF+ with index pulse, not inv., outside 11: REF- with index pulse, inv., outside 12: REF- with index pulse, inv., inside 13: REF- with index pulse, not inv., inside 14: REF- with index pulse, not inv., outside 17: LIMN 18: LIMP 23: REF+, inv., outside 24: REF+, inv., inside 25: REF+, not inv., inside 26: REF+, not inv., outside 27: REF-, inv., outside 28: REF-, inv., inside 29: REF-, not inv., inside 30: REF-, not inv., outside 33: Index pulse neg. direction 34: Index pulse pos. direction 35: Position setting  Abbreviations: REF+: Search movement in positive direction REF-: Search movement in negative direction inv.: Invert direction in switch not inv.: Direction not inverted in switch outside: Index pulse / distance outside switch inside: Index pulse / distance inside switch Modified settings become active immediately.	- 0 - 35	UINT16 R/W - -	-
HMn	Target velocity for searching the switch. The adjustable value is internally limited to the setting in RAMPn_max. Modified settings become active the next time the motor moves.	RPM 1 60 3000	UINT16 R/W per. -	Modbus 10248 CIP 140.1.4
HMn_out	Target velocity for moving away from switch. The adjustable value is internally limited to the setting in RAMPn_max. Modified settings become active the next time the motor moves.	RPM 1 6 3000	UINT16 R/W per. -	Modbus 10250 CIP 140.1.5
HMoutdisusr	Maximum distance for search for switching point. Value 0: Monitoring of distance inactive Value >0: Maximum distance  After detection of the switch, the drive starts to search for the defined switching point. If the defined switching point is not found within the distance defined here, the reference movement is canceled and an error is detected. Modified settings become active the next time the motor moves.	usr 0 0 2147483647	INT32 R/W per. -	Modbus 10252 CIP 140.1.6

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
HMp_homeusr	Position at reference point. After a successful reference movement, this position is automatically set at the reference point. Modified settings become active the next time the motor moves.	usr -2147483648 0 2147483647	INT32 R/W per. -	Modbus 10262 CIP 140.1.11
HMp_setpusr	Position for Position Setting. Action object: write access triggers position setting. Only possible if the motor is at standstill. Position scaling is not considered. Modified settings become active immediately.	usr -2147483648 - 2147483647	INT32 R/W - -	-
HMsrchdisusr	Maximum search distance after overtravel of switch. Value 0: Search distance monitoring disabled Value >0: Search distance  The switch must be activated again within this search distance, otherwise the reference movement is canceled. Modified settings become active the next time the motor moves.	usr 0 0 2147483647	INT32 R/W per. -	Modbus 10266 CIP 140.1.13
IO_AutoEnable	Enabling the power stage at PowerOn. <b>0 / Off:</b> A rising edge with the signal input function "Enable" enables the power stage <b>1 / On:</b> An active signal input with the signal input function "Enable" enables the power stage <b>2 / AutoOn:</b> The power stage is automatically enabled Modified settings become active the next time the power stage is enabled.	- 0 0 2	UINT16 R/W per. -	Modbus 1292 CIP 105.1.6
IO_LO_set	Setting the digital outputs directly. Bit 0 corresponds to the first output, bit 1 corresponds to the second output, and so on.	- - - -	UINT16 R/W - -	Modbus 2082 CIP 108.1.17
IOfunct_LIO1	Function Input/Output LIO1. <b>1 / Input Free available:</b> Available as required <b>2 / Input Fault reset:</b> Reset fault (local control mode only) <b>3 / Input Enable:</b> Enable (local control mode only) <b>4 / Input Halt:</b> Halt <b>9 / Input Jog positive:</b> Jog positive <b>10 / Input Jog negative:</b> Jog negative <b>11 / Input Jog fast/slow:</b> Jog fast/slow <b>20 / Input Reference switch (REF):</b> Reference switch (REF) <b>21 / Input Positive limit switch (LIMP):</b> Positive limit switch (LIMP) <b>101 / Output Free available:</b> Available as required <b>102 / Output No fault:</b> No fault <b>103 / Output Active:</b> Ready Setting can only be modified if power stage is disabled. Modified settings become active the next time the product is powered on.	- - - -	UINT16 R/W per. -	Modbus 1826 CIP 107.1.17

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
IOfunct_LIO2	Function Input/Output LIO2. <b>1 / Input Free available:</b> Available as required <b>2 / Input Fault reset:</b> Reset fault (local control mode only) <b>3 / Input Enable:</b> Enable (local control mode only) <b>4 / Input Halt:</b> Halt <b>9 / Input Jog positive:</b> Jog positive <b>10 / Input Jog negative:</b> Jog negative <b>11 / Input Jog fast/slow:</b> Jog fast/slow <b>20 / Input Reference switch (REF):</b> Reference switch (REF) <b>22 / Input Negative limit switch (LIMN):</b> Negative limit switch (LIMN) <b>101 / Output Free available:</b> Available as required <b>102 / Output No fault:</b> No fault <b>103 / Output Active:</b> Ready Setting can only be modified if power stage is disabled. Modified settings become active the next time the product is powered on.	- - - -	UINT16 R/W per. -	Modbus 1828 CIP 107.1.18
IOfunct_LIO3	Function Input/Output LIO3. <b>1 / Input Free available:</b> Available as required <b>2 / Input Fault reset:</b> Reset fault (local control mode only) <b>3 / Input Enable:</b> Enable (local control mode only) <b>4 / Input Halt:</b> Halt <b>9 / Input Jog positive:</b> Jog positive <b>10 / Input Jog negative:</b> Jog negative <b>11 / Input Jog fast/slow:</b> Jog fast/slow <b>20 / Input Reference switch (REF):</b> Reference switch (REF) <b>101 / Output Free available:</b> Available as required <b>102 / Output No fault:</b> No fault <b>103 / Output Active:</b> Ready Setting can only be modified if power stage is disabled. Modified settings become active the next time the product is powered on.	- - - -	UINT16 R/W per. -	Modbus 1830 CIP 107.1.19
IOfunct_LIO4	Function Input/Output LIO4. <b>1 / Input Free available:</b> Available as required <b>2 / Input Fault reset:</b> Reset fault (local control mode only) <b>3 / Input Enable:</b> Enable (local control mode only) <b>4 / Input Halt:</b> Halt <b>9 / Input Jog positive:</b> Jog positive <b>10 / Input Jog negative:</b> Jog negative <b>11 / Input Jog fast/slow:</b> Jog fast/slow <b>20 / Input Reference switch (REF):</b> Reference switch (REF) <b>101 / Output Free available:</b> Available as required <b>102 / Output No fault:</b> No fault <b>103 / Output Active:</b> Ready Setting can only be modified if power stage is disabled. Modified settings become active the next time the product is powered on.	- - - -	UINT16 R/W per. -	Modbus 1832 CIP 107.1.20
IOsigLimN	Signal evaluation for negative limit switch. <b>0 / Inactive:</b> Inactive <b>1 / Normally Closed:</b> Normally closed NC <b>2 / Normally Open:</b> Normally open NO Setting can only be modified if power stage is disabled. Modified settings become active the next time the power stage is enabled.	- 0 1 2	UINT16 R/W per. -	Modbus 1566 CIP 106.1.15

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
IOsigLimP	Signal evaluation for positive limit switch. <b>0 / Inactive:</b> Inactive <b>1 / Normally Closed:</b> Normally closed NC <b>2 / Normally Open:</b> Normally open NO Setting can only be modified if power stage is disabled. Modified settings become active the next time the power stage is enabled.	- 0 1 2	UINT16 R/W per. -	Modbus 1568 CIP 106.1.16
IOsigRef	Signal evaluation for reference switch. <b>1 / Normally Closed:</b> Normally closed NC <b>2 / Normally Open:</b> Normally open NO The reference switch is only active while a reference movement to the reference switch is processed. Setting can only be modified if power stage is disabled. Modified settings become active the next time the power stage is enabled.	- 1 1 2	UINT16 R/W per. -	Modbus 1564 CIP 106.1.14
JOGactivate	Activation of operating mode Jog. Bit 0 = 1: Positive direction of rotation Bit 1 = 1: Negative direction of rotation Bit 2 = 0: Slow velocity Bit 2 = 1: Fast velocity  If both bits for the direction of rotation are activated at the same time, no movement is started. If a jog movement is running, the simultaneous activation of the bits for the direction of rotation has no effect. Modified settings become active immediately.	- 0 0 7	UINT16 R/W - -	-
JOGn_fast	Velocity for fast movement. The adjustable value is internally limited to the parameter setting in RAMPn_max. Modified settings become active immediately.	RPM 1 180 3000	UINT16 R/W per. -	Modbus 10506 CIP 141.1.5
JOGn_slow	Velocity for slow movement. The adjustable value is internally limited to the parameter setting in RAMPn_max. Modified settings become active immediately.	RPM 1 60 3000	UINT16 R/W per. -	Modbus 10504 CIP 141.1.4
JOGstepusr	Distance for step movement. Modified settings become active the next time the motor moves.	usr 0 20 2147483647	INT32 R/W per. -	Modbus 10510 CIP 141.1.7
JOGtime	Wait time for step movement. Modified settings become active the next time the motor moves.	ms 1 500 32767	UINT16 R/W per. -	Modbus 10512 CIP 141.1.8
LIM_QStopReact	Quick Stop option code. <b>-1 / Deceleration Ramp (Fault):</b> Use deceleration ramp and transition to operating state 9 Fault <b>6 / Deceleration ramp (Quick Stop):</b> Use deceleration ramp and remain in operating state 7 Quick Stop Active Setting of deceleration ramp with parameter RAMPquickstop. Setting of torque ramp with parameter LIM_I_maxQSTP.  The deceleration ramp is only available for operating modes with motion profile for velocity. The torque ramp is used in the operating modes without motion profile for velocity. Modified settings become active immediately.	- -1 6 6	INT16 R/W per. -	Modbus 1584 CIP 106.1.24

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
MBadr	Modbus address. Valid addresses: 1 to 247 Modified settings become active immediately.	- 1 1 247	UINT16 R/W per. -	Modbus 5640 CIP 122.1.4
MBbaud	Modbus Baud rate. <b>9600 / 9600</b> : 9600 Baud <b>19200 / 19200</b> : 19200 Baud <b>38400 / 38400</b> : 38400 Baud Modified settings become active the next time the product is powered on.	- 9600 19200 38400	UINT16 R/W per. -	Modbus 5638 CIP 122.1.3
MBdword_order	Modbus word order for double words (32 bit values). <b>0 / HighLow</b> : HighWord-LowWord <b>1 / LowHigh</b> : LowWord-HighWord High word first or low word first  High word first -> Modicon Quantum Low word first -> Premium, HMI (Schneider Electric) Modified settings become active immediately.	- 0 0 1	UINT16 R/W per. -	Modbus 5646 CIP 122.1.7
MBformat	Modbus data format. <b>1 / 8Bit NoParity 1Stop</b> : 8 bits, no parity bit, 1 stop bit <b>2 / 8Bit EvenParity 1Stop</b> : 8 bits, even parity bit, 1 stop bit <b>3 / 8Bit OddParity 1Stop</b> : 8 bits, odd parity bit, 1 stop bit <b>4 / 8Bit NoParity 2Stop</b> : 8 bits, no parity bit, 2 stop bits Modified settings become active the next time the product is powered on.	- 1 2 4	UINT16 R/W per. -	Modbus 5642 CIP 122.1.5
MBnode_guard	Modbus Node Guarding. Value 0: Node Guarding inactive Value >0: Monitoring time Modified settings become active immediately.	ms 0 0 10000	UINT16 R/W - -	Modbus 5644 CIP 122.1.6
MBTCP_FWupdate	Firmware update via Modbus TCP. <b>0 / Off</b> : Disable firmware update via Modbus TCP <b>1 / On</b> : Enable firmware update via Modbus TCP The parameter can only be set via Modbus RTU. After a firmware update the parameter has to be set to 0. Modified settings become active immediately. Available with firmware version $\geq$ V1.102.	- 0 0 1	UINT16 R/W per. expert	Modbus 5656 CIP 122.1.12
MBTCPdword_order	ModbusTCP word order for double words (32 bit values). <b>0 / HighLow</b> : HighWord-LowWord <b>1 / LowHigh</b> : LowWord-HighWord High word first or low word first  High word first -> Modicon Quantum Low word first -> Premium, HMI (Schneider Electric) Modified settings become active the next time the product is powered on.	- 0 0 1	UINT16 R/W per. -	Modbus 6410 CIP 125.1.5

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
MinTimeAckBitLow	<p>Minimum time for acknowledgement bit movement active. Value 0: Disabled. Acknowledgement is generated by movement time itself. Value &gt;0: Minimum time for acknowledgement bit movement active.</p> <p>If the movement time is less than the set time value, the time for the acknowledgement of active movement is increased. If the movement time is greater than the set time value, the acknowledgment bit for active movement is processed based on the movement time only.</p> <p>Example: Movement time = 5 ms Value for minimum time = 20 ms Acknowledgement bit for active movement is set to LOW for 20 ms.</p> <p>This setting is also used for reference movements and position setting (bits 'ref_ok' and 'homing_attained'). Setting can only be modified if power stage is disabled. Modified settings become active immediately. Available with firmware version <math>\geq</math>V1.018.</p>	- 0 0 16383	UINT16 R/W per. -	Modbus 1608 CIP 106.1.36
ModeError	<p>Error code for synchronous errors (ME flag). Manufacturer-specific error code that caused the ModeError flag to be set. Usually, this is an error that was caused by the activation of an operating mode.</p>	- - - -	UINT16 R/- - -	Modbus 6962 CIP 127.1.25
PA_T_max	Maximum permissible temperature of power stage.	°C - - -	INT16 R/- per. -	Modbus 4110 CIP 116.1.7
PA_T_warn	Temperature limit of power stage for error class 0.	°C - - -	INT16 R/- per. -	Modbus 4108 CIP 116.1.6
PA_U_maxDC	Maximum permissible DC bus voltage. In increments of 0.1 V.	V - - -	UINT16 R/- per. -	Modbus 4102 CIP 116.1.3
PA_U_minDC	Minimum permissible DC bus voltage. In increments of 0.1 V.	V - - -	UINT16 R/- per. -	Modbus 4104 CIP 116.1.4
PA_U_minStopDC	DC bus voltage low threshold for Quick Stop. If the threshold is reached, the drive performs a Quick Stop. In increments of 0.1 V.	V - - -	UINT16 R/- per. -	Modbus 4116 CIP 116.1.10
PAReeprSave	<p>Save parameter values to the nonvolatile memory. Value 1: Save persistent parameters</p> <p>The currently set parameters are saved to the nonvolatile memory. The saving process is complete when the parameter is read and 0 is returned. Modified settings become active immediately.</p>	- - - -	UINT16 R/W - -	Modbus 1026 CIP 104.1.1

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
PARfactorySet	Restore factory settings (default values). <b>No:</b> No <b>Yes:</b> Yes The parameters are reset to the factory settings and subsequently saved to the nonvolatile memory. A reset to the factory settings is only possible via the commissioning software. The saving process is complete when the parameter is read and 0 is returned. Setting can only be modified if power stage is disabled. Modified settings become active the next time the product is powered on.	- 0 - 3	UINT16 R/W - -	-
PARuserReset	Reset user parameters. Bit 0: Reset persistent user parameters to default values. The parameters are reset with the exception of: - Communication parameters - Definition of the direction of rotation - Signal selection position interface - I/O functions Bits 1 and 2: Reserved  The new settings are not saved to the nonvolatile memory. Setting can only be modified if power stage is disabled. Modified settings become active the next time the power stage is enabled.	- 0 - 7	UINT16 R/W - -	Modbus 1040 CIP 104.1.8
POSdirOfRotat	Definition of direction of rotation. <b>0 / Clockwise:</b> Clockwise <b>1 / Counter Clockwise:</b> Counter-clockwise With positive reference values, the motor rotates clockwise (as you look at the end of the motor shaft at the flange).  The limit switch which is reached with a movement in positive direction must be connected to the positive limit switch input and vice versa. Setting can only be modified if power stage is disabled. Modified settings become active the next time the product is powered on.	- 0 0 1	UINT16 R/W per. -	Modbus 1560 CIP 106.1.12
POSscaleDenom	Position scaling: Denominator. Refer to numerator (POSscaleNum) for a description.  A new scaling is activated when the numerator value is set. Setting can only be modified if power stage is disabled.	usr 1 16384 2147483647	INT32 R/W per. -	Modbus 1550 CIP 106.1.7

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
POSScaleNum	<p>Position scaling: Numerator. Scaling factor is defined as:</p> <p>Motor revolutions ----- User-defined units [usr]</p> <p>A new scaling is activated when the numerator value is set.</p> <p>User-defined limit values may be reduced due to the calculation of an internal factor. Setting can only be modified if power stage is disabled. Modified settings become active immediately.</p>	revolution 1 1 2147483647	INT32 R/W per. -	Modbus 1552 CIP 106.1.8
PPn_target	<p>Target velocity for operating mode Profile Position. The adjustable value is internally limited to the parameter setting in RAMPn_max. Modified settings become active immediately.</p>	RPM 1 60 3000	UINT16 R/W - -	-
PPp_absusr	<p>Target position absolute for operating mode Profile Position. Minimum and maximum values depend on: - Scaling factor - Software limit switches (if they are activated) Modified settings become active immediately.</p>	usr - - -	INT32 R/W - -	-
PPp_relpactusr	<p>Target position relative to motor position. Minimum and maximum values depend on: - Scaling factor - Software limit switches (if they are activated)</p> <p>In the case of active positioning in operating mode Profile Position, relative positioning refers to the motor position. The absolute user position limits can only be overrun if the drive is at standstill when the movement starts (x_end=1). In this case, implicit position setting to position 0 is performed. Modified settings become active immediately.</p>	usr - - -	INT32 R/W - -	-
PPp_relprefusr	<p>Target position relative to the currently set target position. Minimum and maximum values depend on: - Scaling factor - Software limit switches (if they are activated)</p> <p>In the case of active positioning in operating mode Profile Position, relative positioning refers to the target position of the ongoing movement. The absolute user position limits can only be overrun if the drive is at standstill when the movement starts (x_end=1). In this case, implicit position setting to position 0 is performed. Modified settings become active immediately.</p>	usr - - -	INT32 R/W - -	-
PVn_target	<p>Target velocity of operating mode Profile Velocity. The adjustable value is internally limited to the setting in RAMPn_max. Modified settings become active immediately.</p>	RPM -3000 - 3000	INT32 R/W - -	-

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
RAMP_TAUjerk	Jerk limitation of the motion profile for velocity. <b>0 / Off:</b> Off <b>1 / 1:</b> 1 ms <b>2 / 2:</b> 2 ms <b>4 / 4:</b> 4 ms <b>8 / 8:</b> 8 ms <b>16 / 16:</b> 16 ms <b>32 / 32:</b> 32 ms <b>64 / 64:</b> 64 ms <b>128 / 128:</b> 128 ms Adjustments can only be made if the operating mode is inactive (x_end=1). Modified settings become active the next time the motor moves.	ms 0 0 128	UINT16 R/W per. -	Modbus 1562 CIP 106.1.13
RAMP_TypeSel	Selection of ramp type. <b>0 / Linear:</b> Linear ramp <b>-1 / Motoroptimized:</b> Motor-optimized ramp Modified settings become active the next time the power stage is enabled.	- - - -	INT16 R/W per. -	Modbus 1574 CIP 106.1.19
RAMPacc	Acceleration of the motion profile for velocity. Modified settings become active the next time the motor moves.	RPM/s 1 600 3000000	UINT32 R/W per. -	Modbus 1556 CIP 106.1.10
RAMPaccdec	Acceleration and deceleration for the Drive Profile Lexium. High word: Acceleration Low word: Deceleration  The values are internally multiplied by 10 (example: 1 = 10 RPM/s).  Write access modifies the values of RAMPacc and RAMPdecel. The limit values are verified on the basis of the values indicated for these parameters. If the value cannot be represented as a 16 bit value, the value is set to 65535 (maximum UINT16 value). Modified settings become active the next time the motor moves.	usr - - -	UINT32 R/W - -	-
RAMPdecel	Deceleration of the motion profile for velocity. Modified settings become active the next time the motor moves.	RPM/s 200 750 3000000	UINT32 R/W per. -	Modbus 1558 CIP 106.1.11
RAMPn_max	Maximum velocity of the motion profile for velocity. The parameter is active in the following operating modes: - Profile Position - Profile Velocity - Homing - Jog  If a greater reference velocity is set in one of these operating modes, it is automatically limited to RAMPn_max. This way, commissioning at limited velocity is easier to perform. Setting can only be modified if power stage is disabled. Modified settings become active the next time the motor moves.	RPM 60 13200 13200	UINT16 R/W per. -	Modbus 1554 CIP 106.1.9
RAMPnstart0	Start/stop velocity. Start/stop velocity of motion profile for velocity Modified settings become active the next time the power stage is enabled.	RPM - - -	UINT16 R/W per. -	Modbus 1570 CIP 106.1.17

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
RAMPquickstop	Deceleration ramp for Quick Stop. Deceleration ramp for a software stop or an error with error class 1 or 2. Modified settings become active the next time the motor moves.	RPM/s 200 6000 3000000	UINT32 R/W per. -	Modbus 1572 CIP 106.1.18
RAMPsym	Acceleration/deceleration of the motion profile for velocity. The values are internally multiplied by 10 (example: 1 = 10 RPM/s).  Write access modifies the values of RAMPacc and RAMPdecel. The limit values are verified on the basis of the values indicated for these parameters. Read access returns the value of RAMPacc or RAMPdecel, whichever is greater. If the value cannot be represented as a 16 bit value, the value is set to 65535 (maximum UINT16 value). Modified settings become active the next time the motor moves.	usr - - -	UINT16 R/W - -	Modbus 1538 CIP 106.1.1
ResetWebPass	Reset password of web server. Value 1: The password of the web server is reset to the default value. A new password must be set when a new connection is established. The parameter can only be written via Modbus RTU. Modified settings become active immediately. Available with firmware version $\geq$ V1.102.	- 0 - 1	UINT16 R/W - -	Modbus 6704 CIP 126.1.24
SM_I_nom	Nominal current of motor. In increments of 0.01 A <sub>rms</sub> . Setting can only be modified if power stage is disabled.	A <sub>rms</sub> - - -	UINT16 R/ per. -	Modbus 3596 CIP 114.1.6
SM_n_20%	Velocity at which 20 % of standstill torque is still available. This parameter is automatically set if you select a motor from the list. In this case, the parameter can only be read. If you select "user-defined motor" from the list, you can modify the parameter. Setting can only be modified if power stage is disabled. Modified settings become active the next time the power stage is enabled.	RPM - - -	UINT16 R/ per. -	Modbus 3608 CIP 114.1.12
SM_n_50%	Velocity at which 50 % of standstill torque is still available. This parameter is automatically set if you select a motor from the list. In this case, the parameter can only be read. If you select "user-defined motor" from the list, you can modify the parameter. Setting can only be modified if power stage is disabled. Modified settings become active the next time the power stage is enabled.	RPM - - -	UINT16 R/ per. -	Modbus 3606 CIP 114.1.11
SM_n_90%	Velocity at which 90 % of standstill torque is still available. This parameter is automatically set if you select a motor from the list. In this case, the parameter can only be read. If you select "user-defined motor" from the list, you can modify the parameter. Setting can only be modified if power stage is disabled. Modified settings become active the next time the power stage is enabled.	RPM - - -	UINT16 R/ per. -	Modbus 3604 CIP 114.1.10

Parameter name	Description	Unit Minimum value Factory setting Maximum value	Data type R/W Persistent Expert	Parameter address via fieldbus
SM_n_max	Maximum permissible speed of rotation of motor. Setting can only be modified if power stage is disabled.	RPM 1 3000 3000	UINT16 R/ per. -	Modbus 3592 CIP 114.1.4
SPV_HW_Deactiv	Temporary deactivation of hardware limit switches. <b>0 / None:</b> No limit switch deactivated <b>1 / Deactivate LIMP:</b> Deactivate positive limit switch <b>2 / Deactivate LIMN:</b> Deactivate negative limit switch <b>3 / Deact. LIMP+LIMN:</b> Deactivate both limit switches With this parameter, a PLC can temporarily deactivate hardware limit switches. This is useful if a homing procedure controlled by a PLC is to use a limit switch as a reference switch without any error response of the drive. Modified settings become active immediately. Available with firmware version $\geq V1.010$ .	- 0 0 3	UINT16 R/W - -	Modbus 1610 CIP 106.1.37
SPV_SW_Limits	Activation of software limit switches. <b>0 / None:</b> Deactivated <b>1 / SWLIMP:</b> Activation of software limit switch positive direction <b>2 / SWLIMN:</b> Activation of software limit switch negative direction <b>3 / SWLIMP+SWLIMN:</b> Activation of software limit switches both directions Software limit switches can only be activated if the zero point is valid. Modified settings become active immediately.	- 0 0 3	UINT16 R/W per. -	Modbus 1542 CIP 106.1.3
SPVswLimNusr	Negative position limit for software limit switch. Refer to description of parameter SPVswLimPusr. Setting can only be modified if power stage is disabled. Modified settings become active the next time the power stage is enabled.	usr - -2147483648 -	INT32 R/W per. -	Modbus 1546 CIP 106.1.5
SPVswLimPusr	Positive position limit for software limit switch. If a user-defined value entered is outside of the permissible range, the limit switch limits are automatically set to the maximum user-defined value. Setting can only be modified if power stage is disabled. Modified settings become active the next time the power stage is enabled.	usr - 2147483647 -	INT32 R/W per. -	Modbus 1544 CIP 106.1.4

# Chapter 12

## Accessories and Spare Parts

### Accessories and Spare Parts

#### Accessories

Description	Reference
Braking Resistor Controller UBC60	ACC3EA001
Installation kit	VW3L10111
Insert with cable entry (2 pieces)	VW3L10100N2
Insert with cable entry (10 pieces)	VW3L10100N10
Cable entry for commissioning	VW3L10222
Insert for sealing (10 pieces)	VW3L10000N10
Insert for sealing (20 pieces)	VW3L10000N20
Insert for sealing (50 pieces)	VW3L10000N50
Cable for commissioning interface, other cable end open 3 m	VW3L1R000R30
Cable for commissioning interface, other cable end RJ45 3 m	VW3L1T000R30
PC connection kit, serial connection between drive and PC, USB-A to RJ45	TCSMCNAM3M002P
Insert kit for commissioning	VW3L1R000
Cable kit, power supply, EtherNet/IP, 3m	VW3L2K001R30
Cable kit, STO, 3 m	VW3L20010R30
Cable kit, STO, 5 m	VW3L20010R50
Cable kit, STO, 10 m	VW3L20010R100
Cable kit, STO, 15 m	VW3L20010R150
Cable kit, STO, 20 m	VW3L20010R200
Cable, power supply, 3 m	VW3L30001R30
Cable, power supply, 5 m	VW3L30001R50
Cable, power supply, 10 m	VW3L30001R100
Cable, power supply, 15 m	VW3L30001R150
Cable, power supply, 20 m	VW3L30001R200
Cable, STO, 3 m	VW3L30010R30
Cable, STO, 5 m	VW3L30010R50
Cable, STO, 10 m	VW3L30010R100
Cable, STO, 15 m	VW3L30010R150
Cable, STO, 20 m	VW3L30010R200
Connector kit for EtherNet/IP, 2 x male industrial connector M12, 1 x sealing cap M12	VW3L5K000
Connector kit for I/O, 2 x industrial connector M8	VW3L50200
Connector kit for I/O, 3 x industrial connector M8	VW3L50300
Connector for STO output, 1 x industrial connector M8	VW3L50010
Insert kit, 3 x I/O	VW3L40300
Insert kit, 2 x I/O, 1 x STO input	VW3L40210
Insert kit, 1 x STO input, 1 x STO output	VW3L40020
Insert kit, 4 x I/O, 1 x STO input, 1 x STO output	VW3L40420

#### Gearbox

Description	Reference
Planetary gear for Lexium Integrated Drive ILSxx571, ratio 3:1	GBX060003S571L

Description	Reference
Planetary gear for Lexium Integrated Drive ILSxx571, ratio 5:1	GBX060005S571L
Planetary gear for Lexium Integrated Drive ILSxx571, ratio 8:1	GBX060008S571L
Planetary gear for Lexium Integrated Drive ILSxx572, ratio 3:1	GBX060003S572L
Planetary gear for Lexium Integrated Drive ILSxx572, ratio 5:1	GBX060005S572L
Planetary gear for Lexium Integrated Drive ILSxx572, ratio 8:1	GBX060008S572L
Planetary gear for Lexium Integrated Drive ILSxx573, ratio 3:1	GBX060003S573L
Planetary gear for Lexium Integrated Drive ILSxx573, ratio 5:1	GBX060005S573L
Planetary gear for Lexium Integrated Drive ILSxx573, ratio 8:1	GBX060008S573L
Planetary gear for Lexium Integrated Drive ILSxx851, ratio 3:1	GBX080003S851L
Planetary gear for Lexium Integrated Drive ILSxx851, ratio 5:1	GBX080005S851L
Planetary gear for Lexium Integrated Drive ILSxx851, ratio 8:1	GBX080008S851L
Planetary gear for Lexium Integrated Drive ILSxx852, ratio 3:1	GBX080003S852L
Planetary gear for Lexium Integrated Drive ILSxx852, ratio 5:1	GBX080005S852L
Planetary gear for Lexium Integrated Drive ILSxx852, ratio 8:1	GBX080008S852L
Planetary gear for Lexium Integrated Drive ILSxx853, ratio 3:1	GBX080003S853L
Planetary gear for Lexium Integrated Drive ILSxx853, ratio 5:1	GBX080005S853L
Planetary gear for Lexium Integrated Drive ILSxx853, ratio 8:1	GBX080008S853L

---

# Chapter 13

## Service, Maintenance, and Disposal

---

### What Is in This Chapter?

This chapter contains the following topics:

Topic	Page
Service Addresses	220
Maintenance	221
Replacing the Product	223
Shipping, Storage, Disposal	224

## Service Addresses

### Schneider Electric Automation GmbH

Schneiderplatz 1  
97828 Marktheidenfeld, Germany  
Phone: +49 (0) 9391 / 606 - 0  
Fax: +49 (0) 9391 / 606 - 4000  
Email: info-marktheidenfeld@se.com

### Additional Contact Addresses

See the homepage for additional contact addresses:

<https://www.se.com>

## Maintenance

### Overview

There are no user-serviceable parts within the product.

Either replace the product, or contact your Schneider Electric service representative.

The product may only be repaired by a Schneider Electric service center.

For all service matters, contact your Schneider Electric service representative.

### WARNING

#### UNINTENDED EQUIPMENT OPERATION

- Only use software and hardware components approved by Schneider Electric for use with this equipment.
- Do not attempt to service this equipment outside of authorized Schneider Electric service centers.
- Update your application program every time you change the physical hardware configuration.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

Use only the accessories and mounting parts specified in the present document and no third-party devices or components that have not been expressly approved by Schneider Electric. Do not modify the equipment.

Include the following points in the maintenance plan of your machine.

### Connections and Fastening

- Inspect all connection cables and connectors regularly for damage. Replace damaged cables immediately.
- Verify regularly that all output elements are firmly seated.
- Verify regularly that all mechanical and electrical threaded connections are tightened to the specified torque.

### Cleaning

If the permissible environmental conditions are not respected, external substances from the environment may penetrate the product and cause unintended movement or equipment damage.

### WARNING

#### UNINTENDED EQUIPMENT OPERATION

- Verify that the environmental conditions are respected.
- Keep liquids from getting to the shaft bushing.
- Do not clean the product with a pressure washer.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

Clean dust and dirt off the product at regular intervals. Insufficient heat dissipation to the ambient air may excessively increase the temperature.

Motors are not suitable for cleaning with a pressure washer. The high pressure may force water into the motor.

Care must be taken with cleaning products as some active agents may have deleterious effects on plastics and welds. When using solvents or cleaning agents, verify that the cables, cable entry seals, O-rings and motor paint are not damaged.

## ***NOTICE***

### **CORROSION CAUSED BY CLEANING AGENTS**

- Before using a cleaning agent, carry out a compatibility test in relation to the cleaning agent and the component affected.
- Do not use alkaline cleaning agents.
- Do not use cleaning agents containing chloride.
- Do not use cleaning agents containing sulfuric acid.

**Failure to follow these instructions can result in equipment damage.**

### **Lifetime Safety-Related Function STO**

The safety-related function STO is designed for a lifetime of 20 years. The expiration date is determined by adding 20 years to the DOM (date of manufacture) shown on the nameplate of the product.

- This date must be included in the maintenance plan of your application.  
Do not use the safety-related function STO after this date.

Example:

The DOM on the nameplate of the product is shown in the format DD.MM.YY, for example 31.12.19. (31 December 2019). This means: Do not use the safety-related function STO after December 31, 2039.

## Replacing the Product

### Overview

Unsuitable parameter values or unsuitable data may trigger unintended movements, trigger signals, damage parts and disable monitoring functions. Some parameter values or data do not become active until after a restart.

### WARNING

#### UNINTENDED EQUIPMENT OPERATION

- Only start the system if there are no persons or obstructions in the zone of operation.
- Do not operate the drive system with undetermined parameter values or data.
- Never modify a parameter value unless you fully understand the parameter and all effects of the modification.
- Restart the drive and verify the saved operational data and/or parameter values after modifications.
- Carefully run tests for all operating states and potential error situations when commissioning, upgrading or otherwise modifying the operation of the drive.
- Verify the functions after replacing the product and also after making modifications to the parameter values and/or other operational data.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

Follow the procedure below for replacing devices.

- Save all parameter settings. To do so, save the data to a PC using the commissioning software.
- Power off all supply voltages. Verify that no voltages are present.
- Label all connections and remove all connection cables (unlock connector locks).
- Uninstall the product.
- Note the identification number and the serial number shown on the product nameplate for later identification.
- Install the new product as per chapter Installation ([see page 55](#)).
- If the product to be installed has previously been used in a different system or application, you must restore the factory settings before commissioning the product.
- Commission the product as per chapter Commissioning ([see page 81](#)).

## Shipping, Storage, Disposal

### Shipping

The product must be protected against shocks during transportation. If possible, use the original packaging for shipping.

### Storage

The product may only be stored in spaces where the specified permissible ambient conditions are met. Protect the product from dust and dirt.

### Disposal

The product consists of various materials that can be recycled. Dispose of the product in accordance with local regulations.

Visit <https://www.se.com/green-premium> for information and documents on environmental protection as per ISO 14025 such as:

- EoLi (Product End-of-Life Instructions)
- PEP (Product Environmental Profile)



## A

### Actual value

In control engineering, the actual value is the value of the controlled variable at a given instant (for example, actual velocity, actual torque, actual position, actual current, and so on). An actual value can be a measured value (for example, the actual position can be a value measured by an encoder) or a derived value (for example, the actual torque can be a value derived from the actual current). The actual value is an input value used by the control loops of the drive to reach the reference value. Definition as per IEC 61800-7 series and IEC 60050.

### Attribute

A single value of an object (in a network device) that can be read or written over the network (also see the glossary entries for Class, Instance, Object).

## C

### CIP

**Common Industrial Protocol**

### Class

DeviceNet and EtherNet/IP describe the behavior of a network node in so-called object classes. A class defines the behavior of (related) objects and consists of attributes and so-called services to work with these attributes (read/write). For example: class vehicles, object car, attribute fuel level, service fill (also see the glossary entries for Instance, Object, Attribute).

## D

### DC bus

Circuit that supplies the power stage with energy (direct voltage).

### Degree of protection

The degree of protection is a standardized specification for electrical equipment that describes the protection against the ingress of foreign objects and water (for example: IP 20).

### Direction of movement

In the case of a rotary motor, direction of movement is defined as follows: Positive direction is when the motor shaft rotates clockwise as you look at the end of the protruding motor shaft.

### DOM

**Date of manufacturing:** The nameplate of the product shows the date of manufacture in the format DD.MM.YY or in the format DD.MM.YYYY. For example:

31.12.19 corresponds to December 31, 2019

31.12.2019 corresponds to December 31, 2019

## E

### EDS

**Electronic Data Sheet**

### EMC

Electromagnetic compatibility

### EMI

Electromagnetic interference

### Error

Discrepancy between a detected (computed, measured or signaled) value or condition and the specified or theoretically correct value or condition. Detected by the drive.

**Error class**

Classification of errors into groups. The different error classes allow for specific responses to errors, for example by severity.

**F****Factory settings**

Settings when the product is shipped.

**Fault**

Fault is an operating state. If the monitoring functions detect an error, a transition to this operating state is triggered, depending on the error class. A "Fault Reset" or a power cycle are required to exit this operating state. Prior to this, the cause of the detected error must be removed. Further information can be found in the pertinent standards such as IEC 61800-7, ODVA Common Industrial Protocol (CIP).

**Fault Reset**

Function used to exit the operating state Fault. Before the function is used, the cause of the detected error must be removed.

**I****I<sup>2</sup>t monitoring**

Anticipatory temperature monitoring. The expected temperature rise of components is calculated in advance on the basis of the motor current. If a limit value is exceeded, the drive reduces the motor current.

**Inc**

Increments

**Index pulse**

Signal identifying the position of the rotor. The index pulse is generated once per revolution.

**Instance**

An actual object that is derived from a specific class ((also see the glossary entries for Class, Object, Attribute).

**Internal units**

Resolution at which the motor can be positioned. Internal units are specified in increments.

**M****MAC ID**

Node address (Media Access Control); an address that is unique in the network.

**O****Object**

An object is a member of a specific class. The object 'bicycle' is a member of the class 'vehicles'. The object 'car' is a member of the class 'vehicles' (also see the glossary entries for Class, Instance, Attribute).

**P****Parameter**

Device data and values that can be read and set (to a certain extent) by the user.

**PELV**

Protective Extra Low Voltage, low voltage with isolation. For more information, refer to IEC 60364-4-41

**Persistent**

Indicates whether the value of the parameter remains in the memory after a power cycle.

**Power stage**

The power stage generates current for controlling the motor on the basis of the motion signals from the controller.

**Q****Quick Stop**

The function can be used for fast deceleration of a movement as a response to a detected error or via a command.

**R****RS-485**

Fieldbus interface as per EIA-485 which enables serial data transmission with multiple devices.

**S****Safety-related function**

Safety-related functions are defined in the standard IEC 61800-5-2 (for example, Safe Torque Off (STO), Safe Operating Stop (SOS) or Safe Stop 1 (SS1)).

**Scaling factor**

This factor is the ratio between an internal unit and a user-defined unit.

**U****User-defined unit**

Unit whose relationship to movements can be determined by the user via parameters.





## A

- acceleration ramp
  - motion profile for the velocity, *155*
- access channels, *106*
- ambient conditions
  - operation, *20*
  - transportation and storage, *20*

## B

- before you begin
  - safety information, *7*

## C

- cable entries
  - mounting cables, *64*
  - mounting to drive, *65*
- cable specifications
  - CN1, Vdc supply, *68*
  - CN2, fieldbus, *70*
  - CN3, RS485, *72*
  - CN4, 24 V signal interface, *74*
  - CN5, STO, *76*
- capture
  - captured position, *162*
  - continuous, *161*
  - one-time, *161*
  - overview, *161*
  - rising edge, falling edge, *161*
  - start, stop, *161*
  - status, *162*
- category 0 stop, *38*
- category 1 stop, *38*
- clearances, *59*
- CN1, fieldbus
  - connection, *70*
- CN1, RS485
  - connection, *72*
- CN1, Vdc supply
  - cable specifications, *68*
  - connection, *68*
  - connector specifications, *68*
  - pin assignments industrial connectors, *69*
  - pin assignments printed board connectors, *68*
- CN2, fieldbus
  - cable specifications, *70*
  - connector specifications, *70*
  - pin assignments industrial connectors, *71*
  - pin assignments printed board connectors, *70*
- CN3, RS485
  - address and baud rate, *72*
  - cable specifications, *72*
  - connector specifications, *72*
  - pin assignments printed board connectors, *73*

- CN4, 24 V signal interface
  - cable specifications, *74*
  - connection, *74*
  - connector specifications, *74*
  - pin assignments printed board connectors, *74*
- CN5, STO
  - cable specifications, *76*
  - connection, *76*
  - connector specifications, *76*
  - pin assignments printed board connectors, *77*
- commissioning
  - current limitation, *93*
  - deceleration ramp Halt, *94*
  - deceleration ramp Quick Stop, *94*
  - digital inputs, digital outputs, *95*
  - direction of movement, *100*
  - Halt ramp, *94*
  - holding brake, *98*
  - limit switches, *96*
  - Quick Stop ramp, *94*
  - reference speed of rotation, *93*
  - safety-related function STO, *97*
- components and interfaces, *15*
- connection CN1, *68*
- connection CN2, *70*
- connection CN3, *72*
- connection CN4, *74*
- connection CN5, *76*
- connection, accessories, *78*
- connector specifications
  - CN1, Vdc supply, *68*
  - CN2, fieldbus, *70*
  - CN3, RS485, *72*
  - CN4, 24 V signal interface, *74*
  - CN5, STO, *76*
- current limitation, *93*

## D

- deceleration ramp
  - Halt, *158*
  - motion profile for the velocity, *155*
  - Quick Stop, *159*
- degree of protection, *21*
- dimensions
  - integrated drive size 57, *22*
  - integrated drive size 85, *23*
- direction of movement, *100*
- disposal, *224, 224*

## E

- electrical data, *24*
- electromagnetic compatibility, *26, 26*
- EMC, *26*
- environmental conditions
  - operation, *20*
  - transportation and storage, *20*
- equipotential bonding conductors, *36*
- error class, *116*

error class of error messages, *189*  
 error memory, *184*  
 error messages, *188*  
 error response, *116*  
 explicit messages, *47*  
 external power supply unit, *35*

## F

factory settings, restoring, *103*  
 forces  
   forces for moving components to shaft, *27*  
   radial and axial forces on shaft, *27*  
 fuses, *24*

## H

Halt  
   deceleration ramp, *158*  
   overview, *158*  
 handshake via bit mode toggle, *53*  
 hardware limit switches, *164*  
 holding brake, *98*  
 Homing, operating mode  
   methods, *141*  
   parameterization, *143*  
   position setting, *150*  
   reference movement to index pulse, *149*  
   reference movement to limit switch, *146*  
   reference movement to reference switch, negative direction, *148*  
   reference movement to reference switch, positive direction, *147*  
   starting, *141*  
   status information, *141*  
   terminating, *142*

## I

I/O messages, *47, 49*  
 industrial connectors, *67*  
 input assembly, instance 113, *51*  
 inspection before mounting, *57*  
 installation, electrical  
   accessories, *78*  
   assembling cables, *65*  
   CN1, Vdc supply, *68*  
   CN2, 24 V signal interface, *74*  
   CN2, fieldbus, *70*  
   CN3, RS485, *72*  
   CN5, STO, *76*  
   mounting cable entries to drive, *65*  
   mounting cables to cable entries, *64*  
   mounting connectors, *64*  
   via cable entries, *64*  
   via industrial connectors, *67*  
 installation, mechanical  
   clearances, *59*  
   general information, *58*  
   mounting positions, *59*  
   output components, *59*  
   ventilation, *59*  
 intended use, *8*

IP address  
   derived from MAC address, *89*  
   DHCP based on DeviceName, *88*  
   DHCP/BOOTP based on MAC address, *88*  
   stored in the nonvolatile memory, *87*  
 IP degree of protection, *21*

## J

jerk limitation, *156*  
 Jog, operating mode  
   continuous movement, *126*  
   functions, *130*  
   parameterization, *129*  
   starting, *127*  
   status information, *128*  
   step movement, *127*  
   terminating, *128*

## L

limit switches, hardware, *164*  
 limit switches, software  
   activation, *167*  
   overview, *167*  
   position limits, *167*  
   with target positions, *167*  
   without target positions, *167*  
 load  
   shaft load, *27*

## M

maintenance, *221*  
 mechanical data, *22*  
 mode toggle, *53*  
 monitoring  
   hardware limit switches, *164*  
   reference switch, *166*  
   software limit switches, *167*  
   stall detection, *171*  
   temperature power stage, *170*  
 motion profile for the velocity  
   availability, *155*  
   jerk limitation, *156*  
   overview, *155*  
   ramp slope, *155*  
   start-stop velocity, *155*  
   type of acceleration ramp and deceleration ramp, *155*  
 mounting  
   clearances, *59*  
   output components, *59*  
 mounting positions, *59*  
 mounting surface for flange, *57*  
 movement range, *107*

## N

nameplate, *17*

## O

operating mode  
  change, 124  
  Homing, 141  
  indication, 123  
  Jog, 126  
  Profile Position, 136  
  Profile Velocity, 132  
  start, 124

operating state  
  change via fieldbus, 121  
  change via signal inputs, 120  
  indication via fieldbus, 119  
  indication via signal inputs, 118  
  state description, 115  
  state diagram, 115

operating states, 114

output assembly, instance 103, 50

output components, 59

overview of integrated drive, 14

## P

parameter *\_acc\_pref*, 198

parameter *\_AccessInfo*, 198

parameter *\_actionStatus*, 198

parameter *\_ethMacAdr1*, 198

parameter *\_ethMacAdr2*, 198

parameter *\_IO\_LIO\_act*, 95, 199

parameter *\_IO\_STO\_con*, 199

parameter *\_LastWarning*, 183, 199

parameter *\_n\_act*, 199

parameter *\_n\_actRAMP*, 199

parameter *\_n\_pref*, 199

parameter *\_n\_targetRAMP*, 199

parameter *\_OpHours*, 199

parameter *\_p\_act*, 199

parameter *\_p\_actRAMPusr*, 199

parameter *\_p\_actusr*, 199

parameter *\_p\_ref*, 199

parameter *\_p\_refusr*, 199

parameter *\_p\_tarRAMPusr*, 199

parameter *\_prgNoCOM*, 200

parameter *\_prgNoDEV*, 200

parameter *\_prgVerCOM*, 200

parameter *\_prgVerDEV*, 200

parameter *\_serialNoDEV*, 200

parameter *\_SigActive*, 200

parameter *\_SigLatched*, 182, 200

parameter *\_StopFault*, 183, 201

parameter *\_Temp\_act\_PA*, 170, 201

parameter *\_UDC\_act*, 201

parameter *\_UserAppMem1*, 201

parameter *\_UserAppMem2*, 201

parameter *\_UserAppMem3*, 201

parameter *\_UserAppMem4*, 201

parameter *\_VoltUtil*, 201

parameter *\_WarnActive*, 201

parameter *\_WarnLatched*, 181, 202

parameter *AbsHomeRequest*, 202

parameter *AccessLock*, 106, 202

parameter *BRK\_release*, 99, 202

parameter *BRK\_status*, 202

parameter *Cap1Activate*, 161, 203

parameter *Cap1Config*, 161, 203

parameter *Cap1Count*, 162, 203

parameter *Cap1Pos*, 162, 203

parameter *Cap2Activate*, 162, 203

parameter *Cap2Config*, 161, 203

parameter *Cap2Count*, 162, 203

parameter *Cap2Pos*, 162, 203

parameter *CapStatus*, 162, 203

parameter *CTRLS\_I\_Const%*, 93, 203

parameter *CTRLS\_I\_Ramp%*, 93, 203

parameter *CTRLS\_I\_Stand%*, 93, 203

parameter *CTRLS\_stallDet*, 171, 204

parameter *CTRLS\_toggle*, 204

parameter *EthErrBehv*, 186, 204

parameter *EthGateway*, 204

parameter *EthGatewayAct*, 204

parameter *EthIpAddr*, 204

parameter *EthIpAddrAct*, 204

parameter *EthIPConflInfo*, 204

parameter *EthSubMask*, 204

parameter *EthSubMaskAct*, 204

parameter *FLT\_class*, 184, 204

parameter *FLT\_del\_err*, 185, 204

parameter *FLT\_err\_num*, 184, 205

parameter *FLT\_Idq*, 185, 205

parameter *FLT\_MemReset*, 185, 205

parameter *FLT\_n*, 185, 205

parameter *FLT\_powerOn*, 185, 205

parameter *FLT\_Qual*, 185, 205

parameter *FLT\_Temp\_DEV*, 185, 205

parameter *FLT\_Temp\_PA*, 185, 205

parameter *FLT\_Time*, 185, 205

parameter *FLT\_UDC*, 185, 205

parameter *FLTAmpOnCyc*, 185, 205

parameter *FLTAmpOnTime*, 185, 205

parameter *HMdisREFtoIDX*, 145, 205

parameter *HMdisusr*, 144, 206

parameter *HMmethod*, 143, 206

parameter *HMn*, 145, 206

parameter *HMn\_out*, 145, 206

parameter *HMoutdisusr*, 144, 206

parameter *HMp\_homeusr*, 144, 207

parameter *HMp\_setpusr*, 150, 207

parameter *HMsrchdisusr*, 144, 207

parameter *IO\_AutoEnable*, 207

parameter *IO\_LO\_set*, 160, 207

parameter *IOfunc\_LIO1*, 111, 207

parameter *IOfunc\_LIO2*, 111, 208

parameter *IOfunc\_LIO3*, 111, 208

parameter *IOfunc\_LIO4*, 112, 208

parameter *IOSigLimN*, 164, 208

parameter *IOSigLimP*, 164, 209

parameter *IOSigRef*, 166, 209

parameter *JOGactivate*, 128, 209

parameter *JOGn\_fast*, 129, 209

parameter *JOGn\_slow*, 129, 209

parameter *JOGstepusr*, 129, 209

parameter *JOGtime*, 129, 209

parameter *LIM\_QStopReact*, 159, 209

parameter *MBadr*, 210

parameter *MBbaud*, 210

parameter *MBdword\_order*, 210

parameter *MBformat*, 210

parameter *MBnode\_guard*, 210

parameter *MBTCP\_FWupdate*, 210

parameter *MBTCPdword\_order*, 210

parameter MinTimeAckBitLow, 211  
 parameter ModeError, 211  
 parameter PA\_T\_max, 170, 211  
 parameter PA\_T\_warn, 170, 211  
 parameter PA\_U\_maxDC, 211  
 parameter PA\_U\_minDC, 211  
 parameter PA\_U\_minStopDC, 211  
 parameter PAReeprSave, 211  
 parameter PARfactorySet, 212  
 parameter PARuserReset, 102, 212  
 parameter POSdirOfRotat, 100, 212  
 parameter POSscaleDenom, 109, 212  
 parameter POSscaleNum, 109, 213  
 parameter PPn\_target, 138, 213  
 parameter PPp\_absusr, 138, 213  
 parameter PPp\_relpactusr, 138, 213  
 parameter PPp\_relprefusr, 138, 213  
 parameter PVn\_target, 133, 213  
 parameter RAMP\_TAUjerk, 157, 214  
 parameter RAMP\_TypeSel, 155, 214  
 parameter RAMPacc, 156, 214  
 parameter RAMPaccdec, 214  
 parameter RAMPdecel, 94, 156, 214  
 parameter RAMPn\_max, 94, 156, 214  
 parameter RAMPnstart0, 155, 214  
 parameter RAMPquickstop, 94, 159, 215  
 parameter RAMPsym, 215  
 parameter ResetWebPass, 91, 215  
 parameter SM\_I\_nom, 215  
 parameter SM\_n\_20%, 215  
 parameter SM\_n\_50%, 215  
 parameter SM\_n\_90%, 215  
 parameter SM\_n\_max, 216  
 parameter SPV\_HW\_Deactiv, 165, 216  
 parameter SPV\_SW\_Limits, 167, 216  
 parameter SPVswLimNusr, 168, 216  
 parameter SPVswLimPusr, 168, 216  
 pin assignments industrial connectors  
   CN1, Vdc supply, 69  
   CN2, fieldbus, 71  
 pin assignments printed board connectors  
   CN1, Vdc supply, 68  
   CN2, fieldbus, 70  
   CN3, RS485, 73  
   CN4, 24 V signal interface, 74  
   CN5, STO, 77  
 pollution degree, 21  
 position capture  
   captured position, 162  
   continuous, 161  
   one-time, 161  
   overview, 161  
   rising edge, falling edge, 161  
   start, stop, 161  
   status, 162  
 Profile Position, operating mode  
   absolute movement, 136  
   functions, 139  
   parameterization, 138  
   relative movement, 136  
   starting, 136  
   status information, 136  
   terminating, 136

Profile Velocity, operating mode  
 functions, 134  
 parameterization, 133  
 starting, 132  
 status information, 132  
 terminating, 132

## Q

qualification of personnel, 7  
 Quick Stop  
   deceleration ramp, 159  
   operating state transition, 159  
   overview, 159

## R

ramp slope, motion profile for the velocity, 155  
 receive data, 47  
 reference switch, 166  
 replacing the integrated drive, 223  
 representation of the parameters, 196  
 resetting the user parameters, 102  
 restoring factory settings, 103

## S

safety-related data  
   safety-related function STO, 28  
 scaling, 108  
 scaling factor, 108  
 service addresses, 220  
 shaft  
   forces for mounting, 27  
   shaft load, 27  
 shaft-specific data, 27  
 shipping, 224  
 signal input functions  
   factory assignments, 74, 110  
   overview, 110  
   parameterization, 110  
 signal output functions  
   factory assignments, 74, 110  
   overview, 110  
   parameterization, 110  
 software limit switches  
   activation, 167  
   overview, 167  
   position limits, 167  
   with target positions, 167  
   without target positions, 167  
 stall detection, 171  
 start-stop velocity, 155  
 state diagram, 115  
 state machine, 115  
 state transitions, 116  
 STO  
   safety-related data, 28  
   technical data, 25  
 storage, 224

**T**

## technical data

- 24 V signals CN4, *25*
  - commissioning interface CN3, *25*
  - electrical data, *24*
  - EMC, *26*
  - environmental conditions operation, *20*
  - environmental conditions storage, *20*
  - environmental conditions transportation, *20*
  - fieldbus interface CN2, *24*
  - fuses, *24*
  - power supply, *24*
  - shaft-specific data, *27*
  - STO CN5, CN6, *25*
  - supply voltage, *24*
  - vibration and shock, *20*
- temperature monitoring, *170*
- touch probe, *161*
- transmit data, *47*
- type code, *18*

**U**

- user-defined units, *108*
- usr, *108*

**V**

- ventilation, *59*
- verifying installation, *80*
- vibration and shock, *20*

**W**

- web server, *90*
- wiring example, *173*